

[Manuals.plus](#) /

› [Cybex](#) /

› Cybex Eezy S Twist 2 Stroller User Manual - Model 520004443

Cybex 520004443

Cybex Eezy S Twist 2 Stroller User Manual

Model: 520004443

IMPORTANT SAFETY INFORMATION

Read all instructions carefully before assembly and use of the Cybex Eezy S Twist 2 Stroller. Failure to follow these instructions could result in serious injury to your child. Keep this manual for future reference.

- Never leave your child unattended in the stroller.
- Always use the 5-point harness system to secure your child. Ensure it is correctly fitted and adjusted.
- The stroller is suitable for infants 6 months and older.
- The maximum weight capacity for this stroller is 55 pounds (25 kg). Do not exceed this weight.
- Do not place more than 10 pounds (4.5 kg) in the storage basket.
- Ensure all locking devices are engaged before use.
- Do not use accessories or replacement parts other than those approved by Cybex.
- Avoid placing hot liquids or heavy objects on the stroller's handle.

WHAT'S INCLUDED

Your Cybex Eezy S Twist 2 Stroller package includes the following components:

- Stroller Frame with Seat Unit
- Canopy
- Bumper Bar

SETUP AND ASSEMBLY

Follow these steps to set up your stroller:

1. **Unfolding the Stroller:** Release the folding latch and lift the handlebar until the frame locks into place. Ensure both sides are securely locked.
2. **Attaching the Canopy:** Slide the canopy attachments onto the designated points on the frame until they click.
3. **Attaching the Bumper Bar:** Insert the bumper bar into the slots on either side of the seat unit until it clicks into place. Ensure it is firmly attached.
4. **Travel System Compatibility:** The Eezy S Twist 2 is compatible with Cybex infant car seats or the Cot S. Use the included adapters to attach these components securely to the stroller frame. Refer to the car seat or Cot S manual for specific attachment instructions.



Image: The Cybex Eezy S Twist 2 Stroller configured as a travel system with a compatible infant car seat.

OPERATING INSTRUCTIONS

Familiarize yourself with the stroller's features for optimal use.

360° Rotating Seat

The seat unit can be rotated 360 degrees to switch between parent-facing and front-facing positions. To rotate, locate the release mechanism (usually a button or lever near the seat base), activate it, and swivel the seat until it locks into the desired position. Ensure the seat is fully locked before placing your child in it.




Image: Visual representation of the 360-degree seat rotation capability.



Image: The stroller seat in the process of rotating, demonstrating its versatility.

Video: This video demonstrates the key features of the Cybex Eezy S Twist 2 Stroller, including the 360-degree rotating seat, compact fold, and travel system compatibility.

One-Hand Recline

The seat offers multiple recline positions, including a near-flat position, for your child's comfort. To recline the seat, locate the recline lever or button on the back of the seat unit. Press or lift the mechanism and adjust the seat to the desired angle. Release the mechanism to lock the seat in place. This can be done with one hand in both parent-facing and front-facing modes.



Image: The stroller seat shown in an upright position, ready for active use.



Image: The stroller seat partially reclined, offering a comfortable resting angle.



Image: The stroller seat fully reclined to a near-flat position, suitable for naps.

Compact One-Hand Fold

The Eezy S Twist 2 features a compact, one-hand fold mechanism for easy storage and transport. To fold the stroller, ensure the seat is in the forward-facing position and the canopy is retracted. Locate the folding mechanism on the handlebar or frame, activate it, and push the handlebar downwards until the stroller collapses into a self-standing package. Ensure all locking mechanisms engage.



Image: The stroller shown in its compact, folded configuration, ideal for storage or travel.

Adjustable Leg Rest

The integrated leg rest can be adjusted to provide comfortable and ergonomic support for your child's legs. Locate the adjustment buttons or levers on the sides of the leg rest and move it to the desired position.

Extendable Sun Canopy

The extendable sun canopy provides UPF 50+ sun protection and features a mesh window for ventilation and observation. Extend or retract the canopy as needed to shield your child from the sun.

All-Wheel Suspension

The stroller is equipped with an all-wheel suspension system designed to provide a smooth ride across various surfaces.

MAINTENANCE AND CARE

Proper maintenance ensures the longevity and safety of your stroller.

- **Fabric Care:** Machine wash fabrics separately in cold water, using a mild detergent on a delicate cycle. Hang dry. Do not bleach, tumble dry, or iron.
- **Frame Care:** Wipe the stroller frame and plastic parts with a damp cloth. Do not use abrasive cleaners.
- **Wheel Maintenance:** Regularly check the wheels for debris and ensure they rotate freely.
- **Storage:** Store the stroller in a dry place, away from direct sunlight and extreme temperatures.

TROUBLESHOOTING

If you encounter issues with your stroller, consider the following:

- **Stroller not folding/unfolding smoothly:** Check for any obstructions in the folding mechanism. Ensure all components are correctly aligned.
- **Seat not rotating:** Verify that the rotation release mechanism is fully engaged and there are no obstructions preventing movement.
- **Wheels not moving freely:** Inspect wheels for trapped debris or hair. Clean as necessary.

For persistent issues or concerns not addressed here, please contact Cybex customer support.

SPECIFICATIONS

Feature	Detail
Model Number	520004443
Folded Size	8 x 7 x 5 Inches
Harness Type	5 Point
Stroller Type	Standard Stroller
Car Seat Compatible	Yes
Seating Capacity	1 Child
Additional Features	One-Hand Fold, Adjustable Leg Rest, All-Terrain Wheels, All-Wheel Suspension, Adjustable Height, 360° Rotating Seat
Material Type	Aluminum, Plastic, Polyester
Fabric Type	Polyester
Frame Material	Aluminum
Canopy Material	Polyester
Seat Material	Fabric
Tire Material	Rubber
Age Range	Infant (6 months+)
Maximum Weight Recommendation	55 Pounds (25 kg)
Installation Type	Foldable/Collapsible, Travel System
Certifications	ASTM, JPMA, REACH

WARRANTY AND SUPPORT

The Cybex Eezy S Twist 2 Stroller comes with a **2 Year Limited Warranty** from the date of purchase. This warranty covers manufacturing defects under normal use.

For warranty claims, technical support, or further assistance, please visit the official Cybex website or contact their customer service department. Keep your proof of purchase for warranty validation.

ASK A QUESTION ABOUT THIS MANUAL

Ask about setup, troubleshooting, compatibility, parts, safety, or missing instructions. Manuals+ will review the question and use this page’s manual context to help answer it.

Name

Anonymous

Email

you@example.com

After a successful submission, we securely hash the supplied account or form email before sending it to Microsoft Advertising for conversion attribution. [Privacy details](#).

Question

Example: How do I reset this device or fix this error?

Details

Model number, symptoms, what you tried, or the section of the manual you are using.

Submit question