

Manuals.plus /

- › **Cyberx** /
- › Cyberx Eezy S Twist 2 Stroller User Manual

Cyberx 520004441

Cyberx Eezy S Twist 2 Stroller User Manual

Model: 520004441

1. INTRODUCTION AND OVERVIEW

The Cyberx Eezy S Twist 2 Stroller is engineered for convenience and comfort, making it an ideal companion for parents on the go. Its innovative design allows for a 360° rotating seat, enabling quick changes between parent-facing and front-facing positions without removing the seat. This compact and lightweight stroller is perfect for navigating city streets, public transport, and travel, offering a seamless experience for both child and parent.

Key features include a one-hand compact fold, all-wheel suspension for a smooth ride, an extendable UPF 50+ sun canopy, and an integrated adjustable leg rest. The Eezy S Twist 2 also functions as a versatile travel system, compatible with Cyberx infant car seats and the Cot S (adapters included).



Figure 1.1: The Cybex Eezy S Twist 2 Stroller in its upright position, showcasing its sleek design and compact form factor.

2. SETUP AND INITIAL ASSEMBLY

Upon unboxing your Cybex Eezy S Twist 2 Stroller, ensure all components are present. The stroller comes largely pre-assembled, requiring minimal setup to prepare for first use.

2.1 Unfolding the Stroller

1. Place the folded stroller on a flat surface.
2. Release the folding latch (if engaged).
3. Lift the handlebar firmly until the frame locks into place. You should hear an audible click.
4. Ensure all wheels are properly extended and locked.

2.2 Attaching Accessories

- **Bumper Bar:** Align the bumper bar with the designated slots on the seat unit and push until it clicks securely into place. It can be opened from either side for easy child access.

- **Canopy:** Ensure the extendable sun canopy is properly attached to the seat frame.
- **Travel System Adapters:** For use with a Cybex infant car seat or Cot S, attach the included adapters to the stroller frame as per the instructions provided with the car seat/Cot S.



Figure 2.1: The Eezy S Twist 2 Stroller configured as a travel system with a compatible Cybex infant car seat, demonstrating adapter use.

3. OPERATING THE STROLLER

The Cybex Eezy S Twist 2 offers several intuitive features designed for ease of use and child comfort.

3.1 360° Rotating Seat

The unique 360° rotating seat allows you to quickly change your child's seating direction from front-facing to parent-facing. To rotate the seat:

1. Ensure the child is securely harnessed.
2. Locate the rotation mechanism (typically a button or lever near the seat base).

3. Press the button/lever and gently twist the seat unit to the desired orientation until it locks into place.



Figure 3.1: Visual representation of the 360-degree seat rotation feature, allowing the child to face forward or towards the parent.

3.2 Seat Recline Positions

The seat can be reclined to multiple positions, including a near-flat position, in both front-facing and parent-facing modes. To recline:

1. Locate the recline lever/strap on the back of the seat.
2. Adjust the seat to the desired angle. Ensure it clicks securely into position.



Figure 3.2: The stroller seat demonstrating its various recline positions, from upright to near-flat for napping.

3.3 One-Hand Compact Fold

The Eezy S Twist 2 features a convenient one-hand fold mechanism for compact storage and transport.

1. Ensure the seat is in the forward-facing position and fully upright.
2. Locate the folding button/lever on the handlebar.
3. Press the button/lever and push the handlebar forward and down until the stroller collapses into a self-standing compact package.



Figure 3.3: The Cybex Eezy S Twist 2 Stroller shown in its compact, self-standing folded configuration, ideal for storage and travel.

3.4 Adjustable Leg Rest

The integrated leg rest can be adjusted with one hand to support comfortable and ergonomic sitting or lying positions for your child.



Figure 3.4: The stroller with its adjustable leg rest extended, providing ergonomic support for the child's legs.

3.5 Extendable Sun Canopy

The large, extendable sun canopy provides UPF 50+ sun protection and features a mesh window for ventilation and easy viewing of your child.



Figure 3.5: The stroller with its extendable UPF 50+ sun canopy fully deployed, offering comprehensive sun protection.

4. MAINTENANCE AND CARE

Proper maintenance ensures the longevity and safe operation of your Cybex Eezy S Twist 2 Stroller.

4.1 Fabric Care

- Machine wash fabrics separately in cold water.
- Use a mild detergent.
- Select a delicate cycle.
- Hang dry. Do not tumble dry.

4.2 Frame and Wheels

- Wipe the frame and plastic parts with a damp cloth and mild soap.
- Regularly check wheels for debris and clean as necessary to ensure smooth movement.

- Do not use abrasive cleaners or solvents.

5. TROUBLESHOOTING

This section addresses common issues you might encounter with your stroller.

5.1 Stroller Feels Unstable or Tips Easily

- **Check Weight Distribution:** Ensure weight is evenly distributed. Avoid overloading the storage basket or hanging heavy bags on the handlebar, as this can affect stability.
- **Maximum Weight Limit:** Do not exceed the maximum weight recommendation of 55 pounds for the stroller seat.
- **Proper Unfolding:** Verify that the stroller frame is fully locked into place after unfolding.

5.2 Difficulty Folding/Unfolding

- **Seat Position:** Ensure the seat is in the correct position (typically upright and forward-facing) before attempting to fold.
- **Obstructions:** Check for any obstructions (e.g., blankets, toys) that might be preventing the mechanism from engaging.
- **Mechanism Engagement:** Ensure the folding button/lever is fully pressed or engaged during the folding process.

5.3 Wheels Not Rolling Smoothly

- **Clean Wheels:** Remove any dirt, hair, or debris from the wheel axles and bearings.
- **Lubrication:** Apply a small amount of silicone-based lubricant to the wheel axles if necessary.
- **Brakes:** Ensure the brakes are fully disengaged.

5.4 Storage Basket Capacity

- The storage basket is designed for light items. Avoid overloading it to prevent damage and maintain stroller stability.

6. SPECIFICATIONS

Feature	Detail
Model Number	520004441
Brand	Cybox
Color	Deep Black
Material	Aluminum, Plastic, Polyester
Fabric Type	Polyester
Frame Material	Aluminum
Age Range Description	Infant (6 months and older for seat unit)
Maximum Weight Recommendation	55 Pounds (Stroller Seat)
Folded Size	31.5 x 11.8 x 22 Inches
Harness Type	5 Point
Number of Wheels	4
Car Seat Compatible	Yes (with included adapters)
Included Components	Stroller
Certifications	ASTM, JPMA

7. WARRANTY AND SUPPORT

7.1 Manufacturer's Warranty

The Cybex Eezy S Twist 2 Stroller comes with a **2 Year Limited Warranty** from the manufacturer. Please retain your proof of purchase for warranty claims. This warranty covers manufacturing defects under normal use.

7.2 Customer Support

For further assistance, product registration, or to inquire about replacement parts, please visit the official Cybex store or contact their customer service department.

Official Cybex Store: Visit the [Cybex Store on Amazon](#)