

ZURU 491902608

MAX Build More Building Bricks Accessories and Wheels Value Set Instruction Manual

Model: 491902608 | Brand: ZURU

[Introduction](#) [Safety Information](#) [Package Contents](#) [Setup](#) [Operating](#)
[Instructions](#) [Maintenance](#) [Troubleshooting](#) [Specifications](#) [Warranty & Support](#)

1. INTRODUCTION

This manual provides essential information for the safe and effective use of your ZURU MAX Build More Building Bricks Accessories and Wheels Value Set. This set includes 250 pieces designed for creative construction and is compatible with other major building brick brands. Please read this manual thoroughly before use and retain it for future reference.



Figure 1.1: The MAX Build More 250-piece set, packaged in a red storage box, displaying a variety of colorful building bricks and specialized accessories like wheels.

2. SAFETY INFORMATION

Please observe the following safety guidelines to ensure a safe play environment:

- **Choking Hazard:** This set contains small parts. Not suitable for children under 3 years of age. Adult supervision is recommended for younger children.
- **Ingestion:** Do not put bricks or accessories in the mouth.

- **Storage:** Store all pieces in the provided storage box or a secure container when not in use to prevent loss and keep them away from infants and pets.
- **Cleaning:** Refer to the "Maintenance" section for proper cleaning instructions.

3. PACKAGE CONTENTS

Your ZURU MAX Build More Building Bricks Accessories and Wheels Value Set includes:

- 250x ZURU MAX Build More Building Bricks, Wheels, and Accessories (various colors, sizes, and shapes)
- 1x Storage Box



Figure 3.1: The reverse side of the product packaging, illustrating the variety and approximate count of the 250 building bricks, wheels, and accessories included in the set.

4. SETUP

The MAX Build More set is designed for immediate use. No assembly of the storage box is required.

1. **Unpack:** Carefully open the storage box.
2. **Inspect:** Verify that all 250 pieces are present and undamaged. If any pieces are missing or damaged, refer to the "Warranty & Support" section.
3. **Prepare Play Area:** Ensure a clean, flat, and stable surface for building to prevent loss of small pieces.

5. OPERATING INSTRUCTIONS

The MAX Build More bricks are designed for creative and open-ended play. They are fully compatible with other major building brick brands, allowing for expanded construction possibilities.

5.1 Basic Building

- **Connecting Bricks:** Align the studs on one brick with the holes on another. Press firmly to secure the connection.
- **Disassembling Bricks:** Gently pull bricks apart. Avoid excessive force to prevent damage.

5.2 Using Accessories and Wheels

- **Wheels:** Attach wheel axles to appropriate brick pieces to create vehicles or moving structures. Ensure the wheels spin freely.
- **Specialty Pieces:** Utilize unique accessory pieces to add detail and functionality to your creations.



Figure 5.1: The MAX Build More set in a play setting, showcasing various constructed models and the potential for creative building with the included pieces.



Figure 5.2: A visual representation of the diverse range of bricks, accessories, and wheels available in the set, categorized by color and type.

6. MAINTENANCE

6.1 Cleaning

- **General Cleaning:** Wipe bricks with a damp cloth and mild soap if necessary. Rinse thoroughly with clean water.
- **Drying:** Allow all pieces to air dry completely before storing to prevent mold or mildew. Do not use heat to dry.
- **Avoid Harsh Chemicals:** Do not use abrasive cleaners, solvents, or strong detergents, as these can damage the plastic.

6.2 Storage

- **Storage Box:** Always store the bricks and accessories in the provided storage box to keep them organized and prevent loss.
- **Environment:** Store the set in a cool, dry place away from direct sunlight and extreme temperatures.

7. TROUBLESHOOTING

If you encounter any issues with your MAX Build More set, refer to the following common solutions:

Problem	Possible Cause	Solution
Bricks do not connect securely.	Improper alignment; debris in studs/holes; worn pieces.	Ensure proper alignment and firm pressure. Check for and remove any debris. If pieces are significantly worn, they may need replacement.
Pieces are difficult to separate.	Very tight fit; small pieces.	Gently twist and pull. For small pieces, use a brick separator tool (not included) if available, or seek adult assistance.
Missing pieces.	Pieces misplaced during play or initial inspection.	Thoroughly check the play area and storage box. If pieces were missing upon purchase, contact customer support.

8. SPECIFICATIONS

Product Name	MAX Build More Building Bricks Accessories and Wheels Value Set (250 Pieces)
Brand	ZURU
Model Number	491902608
ASIN	B08BVVLBYD
Total Pieces	250
Product Dimensions	5.91 x 2.76 x 1.57 inches
Item Weight	10.6 ounces
Recommended Age	3 years and up
Compatibility	Compatible with other major building brick brands.

9. WARRANTY & SUPPORT

For information regarding product warranty, returns, or customer support, please refer to the retailer's policy where the product was purchased or visit the official ZURU brand store online.

ZURU Brand Store: [Visit the ZURU Store on Amazon](#)

