HYUNDAI HYLED5519N4KM

Hyundai 55" 4K UHD Smart TV LED Hyled5519N4Km User Manual

Model: HYLED5519N4KM

Contents | Introduction | Safety Information | Package | Setup | Operating | Maintenance | Troubleshooting | Specifications | Warranty & Support

1. Introduction

Thank you for purchasing the Hyundai 55" 4K UHD Smart TV LED Hyled5519N4Km. This television offers a stunning 4K resolution for exceptional image clarity, powered by a fast and stable Linux operating system. Enjoy direct access to popular applications like Netflix, YouTube, and Prime Video, along with a built-in browser. Its extensive connectivity options include multiple HDMI and USB ports, plus Bluetooth for connecting peripheral audio devices. The exclusive borderless design enhances your viewing experience.

This manual provides essential information for setting up, operating, maintaining, and troubleshooting your new television. Please read it thoroughly before use and keep it for future reference.

2. Important Safety Information

Always follow these basic safety precautions when using your television to reduce the risk of fire, electric shock, and injury:

- **Power Source:** Ensure the power supply voltage matches the rating on the TV's label. Do not overload power outlets.
- **Ventilation:** Do not block ventilation openings. Allow adequate space around the TV for proper airflow.
- **Liquid Exposure:** Do not expose the TV to rain or moisture. Do not place objects filled with liquids, such as vases, on the TV.
- **Cleaning:** Unplug the TV before cleaning. Use a soft, dry cloth. Do not use liquid cleaners or aerosol cleaners.

- **Placement:** Place the TV on a stable, level surface. Avoid placing it in direct sunlight or near heat sources.
- **Lightning:** Unplug the TV during lightning storms or when unused for long periods.
- **Servicing:** Do not attempt to service the TV yourself. Refer all servicing to qualified service personnel.
- **Children:** Supervise children to ensure they do not climb on or play with the TV.

3. Package Contents

Please check that all the following items are included in your TV package:

- Hyundai 55" 4K UHD Smart TV
- Remote Control
- Bases (TV Stands) and Screws
- Power Cable
- User Manual and Warranty Card

4. Setup

4.1 Unpacking

Carefully remove the TV from its packaging. It is recommended to keep the original packaging materials for future transport or servicing.

4.2 Stand Installation

If you are not wall-mounting the TV, attach the included bases (stands) to the bottom of the television using the provided screws. Ensure they are securely fastened.



Image: Illustration of attaching the TV stands, emphasizing the borderless screen design.

4.3 Wall Mounting (Optional)

The TV can be wall-mounted using a compatible VESA wall mount (not included). Please refer to the wall mount's instructions for proper installation and ensure it can support the weight of the 55-inch television.

4.4 Connecting Devices

Connect your external devices to the TV using the available ports:

- **HDMI Ports:** Connect Blu-ray players, game consoles, cable boxes, or other HDMI-enabled devices. This TV supports 4K resolution via HDMI.
- **USB Ports:** Insert USB drives for media playback (2 ports available).
- **Antenna/Cable Input:** Connect your antenna or cable TV signal.
- **Power Cable:** Connect the power cable to the TV's power input and then to a wall outlet.

4.5 Initial Power On and Setup Wizard

After connecting all necessary cables, plug in the TV. Press the power button on the remote control or the TV itself. The TV will guide you through an initial setup wizard, where you can select your language, connect to a Wi-Fi network, scan for channels, and agree to terms and conditions.

5. Operating Your TV

5.1 Remote Control Functions

The included remote control allows you to navigate the TV's features. Key buttons include:

- **Power:** Turns the TV on/off.
- **Source/Input:** Switches between connected devices (HDMI, USB, TV).

- **Volume Up/Down:** Adjusts the sound level.
- **Channel Up/Down:** Changes TV channels.
- **Navigation (Arrow) Buttons & OK:** Used to navigate menus and confirm selections.
- **Home/Smart Hub:** Accesses the Smart TV interface.
- **Dedicated App Buttons:** Direct access to Netflix, YouTube, and Prime Video.
- **Back/Exit:** Returns to the previous screen or exits a menu.

5.2 Smart TV Features

Your Hyundai Smart TV runs on a Linux-based operating system, providing a stable and responsive user experience.



Image: The Smart TV home screen, showing pre-installed applications and a vibrant background.



Image: A closer view of the Smart TV's application interface, highlighting various entertainment and utility apps.

- **Pre-installed Applications:** Access Netflix, YouTube, Prime Video, and a web browser directly from the home screen or via dedicated remote buttons.
- **Bluetooth Connectivity:** Connect Bluetooth-enabled audio devices such as soundbars or headphones for an enhanced sound experience.
- **Borderless Design:** The TV features a sleek, borderless display for a more immersive viewing experience, maximizing screen real estate.

5.3 Input Selection

To switch between different input sources (e.g., HDMI 1, HDMI 2, USB, TV), press the 'Source' or 'Input' button on your remote control and select the desired input from the on-screen menu.

5.4 Picture and Sound Settings

Access the TV's settings menu to customize picture and sound. You can adjust brightness, contrast, color, and sharpness for picture quality. For sound, you can select audio modes (e.g., Standard, Movie, Music) and adjust bass/treble settings. The TV supports stereo audio output.

6. Maintenance

6.1 Cleaning the TV

- **Screen:** Gently wipe the screen with a soft, lint-free cloth. For stubborn marks, slightly dampen the cloth with water or a specialized screen cleaner (do not spray directly on the screen).
- **Body:** Use a soft, dry cloth to wipe the TV's frame and stand.
- **Important:** Always unplug the TV before cleaning. Do not use abrasive cleaners, waxes, or solvents.

6.2 Storage

If you need to store the TV for an extended period, unplug it and store it in a cool, dry place, ideally in its original packaging to protect it from dust and physical damage.

6.3 Software Updates

Periodically check for software updates through the TV's settings menu. Updates can improve performance, add new features, or fix bugs. Ensure a stable internet connection during updates.

7. Troubleshooting

If you encounter issues with your TV, try the following solutions before contacting support:

Problem	Possible Solution
No Power	Check if the power cable is securely plugged into the TV and the wall outlet. Try a different outlet.
No Picture, But Sound is Present	Ensure the correct input source is selected. Check cable connections (HDMI, antenna).
No Sound, But Picture is Present	Check volume level and mute status. Verify audio output settings. If using external speakers, check their connections.
Remote Control Not Working	Replace batteries. Ensure no obstructions between the remote and the TV's IR sensor.
Smart Apps Not Loading/Crashing	Check internet connection. Restart the TV by unplugging it for a few minutes. Ensure TV software is up to date.
Poor Picture Quality (4K not showing)	Ensure the source content is 4K. Check HDMI cable quality (use high-speed HDMI cables for 4K). Adjust picture settings.

If the problem persists, please refer to the warranty and support section for further assistance.

8. Specifications

Feature	Detail
Brand	HYUNDAI
Model	HYLED5519N4KM
Screen Size	55 Inches (140 cm)
Display Technology	LED
Resolution	3840 x 2160 pixels (4K UHD)
Refresh Rate	120 Hz
Operating System	Linux
Connectivity	Bluetooth, USB (2 ports), HDMI
Smart Features	Netflix, YouTube, Prime Video, Web Browser
Audio Output Mode	Stereo
Power Source	Wired Electric Power
Approx. Dimensions (Package)	137 x 82 x 15 cm
Approx. Weight (Package)	16.48 kg
Model Year	2020

9. Warranty and Support

9.1 Warranty Information

Your Hyundai TV comes with a manufacturer's warranty. Please refer to the included Warranty Card in your package for specific terms, conditions, and duration of the warranty. Keep your proof of purchase for warranty claims.

9.2 Customer Support

For technical assistance, troubleshooting beyond this manual, or warranty service, please contact Hyundai customer support. You can typically find contact information on the official Hyundai Electronics website or through your retailer.

When contacting support, please have your TV's model number (HYLED5519N4KM) and serial number ready, along with a detailed description of the issue.

© 2024 HYUNDAI. All rights reserved.

Ask a question about this manual

Ask about setup, troubleshooting, compatibility, parts, safety, or missing instructions. Manuals+ will review the question and use this page's manual context to help answer it.

Name

Anonymous

Email

you@example.com

After a successful submission, we securely hash the supplied account or form email before sending it to Microsoft Advertising for conversion attribution. Privacy details.

Question

Example: How do I reset this device or fix this error?

Details

Model number, symptoms, what you tried, or the section of the manual you are using.

Submit question