Seatcraft Headline 88-8216

Seatcraft Headline Home Theater Seating Sofa with Fold Down Table Instruction Manual

Model: Headline 88-8216 | Brand: Seatcraft

Introduction

This manual provides detailed instructions for the setup, operation, and maintenance of your Seatcraft Headline Home Theater Seating Sofa with Fold Down Table. Please read this manual thoroughly before assembly and use to ensure proper function and longevity of your product. The Seatcraft Headline collection is designed for comfort and functionality, featuring power recline, powered headrests, USB-A charging, and a convenient fold-down table.

Safety Information

All foam and upholstered surfaces meet flammability standards. Keep away from open flames or high heat sources. Supervise children and pets to avoid entrapment risks. Ensure all power cords are properly routed to prevent tripping hazards and damage.

Setup Instructions

Carefully unpack all components from the packaging. It is recommended to have at least two people for assembly due to the size and weight of the seating units. Ensure you have adequate space for assembly and placement.

1. Component Identification

Identify all seating sections, backrests, and power cables. Ensure all parts are present before proceeding.

2. Placement Considerations

For full reclining extension, the sofa requires only **6.5 inches of wall clearance**. Measure your intended placement area to ensure sufficient space. The minimum doorframe width required to fit the sofa through (by rotating it 90 degrees before attaching the backrest) is **28 inches**.



Image: Detailed diagram illustrating the dimensions of the Seatcraft Headline sofa, including overall width (91.5"), backrest height (28.5"), arm width (7"), surface width (78"), arm height (25.5"), footprint (43"), seat height (45.5"), surface depth (21.5"), cushion height (21"), full recline depth (74"), and the required 6.5" wall clearance. It also shows a visual guide for rotating the sofa 90 degrees to fit through a 28" minimum doorframe width before attaching the backrest.

3. Assembly

1. Position the base sections of the sofa in your desired location.
2. Carefully slide the backrests onto the corresponding base sections until they securely lock into place. Ensure a firm connection.
3. Connect the power cables from each seating section to the main power supply. Plug the main power supply into a grounded electrical outlet.



Image: The Seatcraft Headline home theater seating sofa, fully assembled and in the upright position, showcasing its black Italian leather upholstery and the central fold-down table.

Operating Instructions

Your Seatcraft Headline sofa features intuitive controls for personalized comfort and convenience. The control panel is typically located on the inner side of the armrest.




Image: A close-up of the Comfort View™ powered recline control guide. It features a central USB charging port, a home button to return the chair to its default position, and buttons for powered recline (forward/backward) and powered headrest (up/down). An ambient light power on/off switch is also visible.

Control Panel Functions:

- **Powered Recline:** Use the left-most buttons to adjust the recline angle of your seat. Press the forward arrow to recline backward and the backward arrow to return to an upright position.
- **Powered Headrest:** Use the right-most buttons to adjust the angle of the headrest. This allows for personalized neck and head support.
- **Home Button:** The central button with a house icon will return the seat to its default, upright position.
- **USB Charging Port:** A USB-A port is integrated into the control panel for convenient charging of your electronic devices.
- **Ambient Light Switch:** The button next to the USB port controls the ambient lighting feature, typically illuminating the cupholders or base.

Fold-Down Table:

The central backrest of the sofa can be folded down to reveal a convenient table surface, complete with cupholders and a power

outlet/USB hub (if equipped). To deploy, gently pull the top of the central backrest forward and down. To stow, lift the table back into the upright position until it locks securely.



Image: The Seatcraft Headline sofa with its central backrest folded down, revealing a table surface with two cupholders and a small tray for accessories. The two outer seats are in an upright position.



Image: The Seatcraft Headline sofa with the fold-down table in use, displaying drinks and a remote control on its surface. The outer seats are in an upright position.

Additional Features:

- **In-Arm Storage:** Lift the armrest covers to access hidden storage compartments, ideal for remotes or small items.
- **Cupholders:** Integrated cupholders are located in the armrests for convenience.

Maintenance

Cleaning Instructions:

Your Seatcraft Headline sofa is upholstered in genuine Italian leather, known for its durability and soft feel. For general cleaning, wipe the upholstery with a clean, damp cloth. Avoid using harsh chemicals, abrasive cleaners, or excessive moisture, as these can damage the leather. For spills, blot immediately with a clean, dry cloth. For specific leather care, consult a professional leather cleaning guide or product.

Mechanism Care:

The power reclining mechanism is designed for durability. Avoid placing heavy objects on the footrest when extended. Periodically check all connections and fasteners to ensure they are secure.

Troubleshooting

If you encounter any issues with your Seatcraft Headline sofa, please refer to the following common solutions:

- **No Power/Mechanism Not Responding:**
  - Ensure the power cord is securely plugged into both the sofa and a functional wall outlet.

- Check if the wall outlet is receiving power by plugging in another device.
- Verify that all internal connections between seating sections are firm.

- **Recline or Headrest Movement is Jerky or Incomplete:**
  - Ensure there are no obstructions preventing the mechanism from moving freely.
  - Check for any loose connections in the power supply.

- **USB Port Not Charging:**
  - Confirm the sofa is powered on and plugged into an active outlet.
  - Try a different USB cable or device to rule out a faulty accessory.

If these steps do not resolve the issue, please contact customer support.

Product Specifications

Brand	Seatcraft
Model Name	Headline
Model Number	88-8216
Color	Black
Material	Italian Leather
Product Dimensions (D x W x H)	43"D x 91.5"W x 45.5"H
Item Weight	350 pounds
Maximum Weight Recommendation	400 pounds per seat
Reclining Position Count	2 (Upright, Full Recline)
Wall Clearance Required	6.5 inches
Included Components	Cup Holders, Fold-Down Table, In-Arm Storage, Storage Console, USB-A charging port
Frame Material	Engineered Wood
Additional Features	2.2 high-resilience foam with memory foam and Cool Gel, Big and Tall design, Power Recline, Powered Headrest

Warranty Information

The Seatcraft Headline Home Theater Seating Sofa is covered by a **1-year limited warranty** from the manufacturer. This warranty covers defects in materials and workmanship under normal use. Please retain your proof of purchase for warranty claims. For full details regarding warranty coverage and exclusions, refer to the official Seatcraft warranty documentation or contact customer support.

Customer Support

For further assistance, technical support, or warranty inquiries, please contact Seatcraft customer service. Refer to the official

Seatcraft website or your purchase documentation for contact details.

Online Resources: Visit the Seatcraft Store on Amazon

© 2024 Seatcraft. All rights reserved.