#### Manuals+

Q & A | Deep Search | Upload

#### manuals.plus /

- Moen /
- Moen Georgene Spot Resist Stainless 1-Handle Deck Mount Pull-Down Handle/Lever Commercial/Residential Kitchen Faucet Instruction Manual

#### Moen 87801srs

# Moen Georgene Kitchen Faucet Instruction Manual

Model: 87801srs

# PRODUCT OVERVIEW

The Moen Georgene Spot Resist Stainless 1-Handle Deck Mount Pull-Down Kitchen Faucet is designed for both commercial and residential use, offering a blend of style and functionality. Its Spot Resist stainless finish helps maintain a cleaner appearance by resisting fingerprints and water spots. The faucet is equipped with the Reflex system for smooth operation, easy movement, and secure docking of the pull-down spray wand, providing flexible water delivery.



Figure 1: Moen Georgene Kitchen Faucet with pull-down sprayer.

# SETUP AND INSTALLATION

This Moen Georgene kitchen faucet is designed for deck mount installation and is suitable for 3-hole sink configurations, with a deck plate included for convenience. The single-handle lever provides easy control over

water temperature and flow.

# **Included Components:**

- Faucet Assembly
- Deck Plate
- Handle
- · Mounting Hardware
- Supply Lines

# **Installation Steps (General):**

- 1. Ensure water supply is turned off at the main shut-off valve.
- 2. Remove existing faucet if applicable.
- 3. Clean the mounting surface thoroughly.
- 4. Install the deck plate (if using) and position the faucet body through the sink holes.
- 5. Secure the faucet from underneath the sink using the provided mounting hardware.
- 6. Connect the hot and cold water supply lines to the corresponding valves.
- 7. Connect the pull-down hose to the main faucet body and attach the weight to the hose as per instructions to ensure proper retraction.
- 8. Turn on the water supply and check for leaks.
- 9. Flush the faucet for a few minutes to clear any debris.



Figure 2: Faucet installed in a kitchen setting, demonstrating its design.

#### **OPERATING INSTRUCTIONS**

The Moen Georgene faucet features a single lever handle for precise control and a versatile pull-down spray wand.

# **Water Flow and Temperature Control:**

- To turn the water on, lift the single lever handle.
- Move the handle to the left for hot water and to the right for cold water.
- Adjust the handle's position to achieve the desired water temperature and flow rate.

#### **Pull-Down Sprayer Functionality:**

• Gently pull the spray wand down from the faucet spout to extend the hose. The Reflex system ensures smooth extension and secure docking.

- The spray wand features a button to switch between a steady stream and a powerful spray. Press the button to toggle between these two modes.
- Some models may include a pause button on the spray wand to temporarily stop water flow without adjusting the main handle.
- Once finished, guide the spray wand back into the spout. The weighted hose will retract it securely into place.



Figure 3: Faucet demonstrating the pull-down spray function.

### **M**AINTENANCE

Proper maintenance will ensure the longevity and optimal performance of your Moen Georgene faucet. The Spot Resist stainless finish is designed to minimize fingerprints and water spots, making cleaning easier.

# Cleaning the Finish:

- For daily cleaning, simply wipe the faucet with a soft, damp cloth.
- For more stubborn spots, use a mild liquid dish soap and warm water. Apply with a soft cloth, then rinse thoroughly and dry immediately to prevent water spots.
- Avoid abrasive cleaners, harsh chemicals, or scouring pads, as these can damage the finish.

#### **Aerator Maintenance:**

- If water flow becomes restricted or uneven, the aerator may need cleaning.
- Unscrew the aerator from the end of the spout.
- Rinse any debris from the screen and internal components. For mineral deposits, soak in a 50/50 solution of white vinegar and water.
- Reassemble the aerator and screw it back onto the spout.

#### **T**ROUBLESHOOTING

This section provides solutions to common issues you might encounter with your Moen Georgene kitchen faucet.

Problem	Possible Cause	Solution
Low Water Flow	Clogged aerator; partially closed shut-off valves; kinked supply lines.	Clean aerator (see Maintenance); ensure shut-off valves are fully open; check supply lines for kinks.
Leaking from Spout	Worn out O-rings or seals; loose connections.	Inspect and replace O-rings/seals if necessary; tighten connections.
Difficulty Retracting Spray Wand	Hose weight dislodged or obstructed; hose kinked.	Ensure hose weight is properly positioned and not obstructed; straighten any kinks in the hose.
Water Temperature Issues	Incorrect hot/cold supply connections; water heater issues.	Verify supply line connections; consult water heater manual or professional.

If these solutions do not resolve the issue, please contact Moen customer support for further assistance.

# **S**PECIFICATIONS

Feature	Detail
Brand	Moen
Model Name	87801srs
Mounting Type	Deck Mount
Finish Type	Spot Resist Stainless
Material	Stainless Steel
Color	Stainless
Number of Handles	1
Included Components	Deck Plate, Handle
Hole Count	3
Special Feature	Pull Down Sprayer
Handle Type	Lever
Installation Type	Single Hole Deck Mount, Single Hole
Item Weight	0.01 Ounces
Product Dimensions	24.5 x 18.25 x 4.5 inches
UPC	026508295380

# WARRANTY AND SUPPORT


Moen products are manufactured with the highest standards of quality and workmanship. For detailed warranty information, please refer to the warranty card included with your product or visit the official Moen website.

For technical support, replacement parts, or any inquiries regarding your Moen Georgene faucet, please contact Moen Customer Service. You can also visit the official Moen store online for additional resources and product information.

Official Moen Store: Visit the Moen Store on Amazon

© 2024 Moen. All rights reserved.

#### Related Documents - 87801srs



#### Moen Adler Two Handle Lavatory Faucet Illustrated Parts List

Detailed illustrated parts list for the Moen Adler Two Handle Lavatory Faucet, providing part numbers, descriptions, and finish options for components like handles, cartridges, and mounting hardware. Includes model numbers 84603 and 84603SRN.




# Moen Ronan One-Handle Lavatory Faucet Illustrated Parts List & Specifications

Detailed illustrated parts list for the Moen Ronan One-Handle Lavatory Faucet (Models 84021BL, 84021SRN). Find part numbers, descriptions, and finishes for your Moen faucet.



#### Moen Hamden 4" Lavatory Faucet Illustrated Parts

Detailed illustrated parts list for the Moen Hamden 4-inch Lavatory Faucet (Model 84300SRN) in Spot Resist Brushed Nickel. Includes part numbers, descriptions, waste assembly details, and deck thickness compatibility.



#### Moen SLEEK™ Single-Handle High Arc Pulldown Kitchen Faucet Illustrated Parts

Official Moen SLEEK<sup>TM</sup> kitchen faucet replacement parts list, featuring part numbers and finishes for models 7864, 7864SRS, 7864BL, and 7864BLS. Includes spout kits, handle kits, cartridges, hoses, and optional accessories.



# Moen 87042SRS Edison One-Handle Kitchen Faucet Installation Guide

Comprehensive installation guide for the Moen 87042SRS Edison one-handle kitchen faucet, including parts list, step-by-step instructions, cleaning recommendations, and warranty information.



# Bokeh 87056 Series Single Handle Kitchen Pull Out Faucet Parts

Illustrated parts list and identification for the Bokeh 87056 Series single handle pull out kitchen faucet by Moen, including finishes like Chrome, Spot Resist Stainless, and Matte Black.