

## Manuals+

[Q & A](#) | [Deep Search](#) | [Upload](#)

manuals.plus /

> [mecor](#) /

> [mecor Queen Size LED Bed Frame Instruction Manual \(Model B08BZW2HKB\)](#)

### mecor B08BZW2HKB

# mecor Queen Size LED Bed Frame Instruction Manual

Model: B08BZW2HKB

[Contents](#) [Setup](#) [Operation](#) [Overview](#) [Safety](#) [Package](#) [Maintenance](#) [Troubleshooting](#) [Specifications](#) [Warranty & Support](#)

## 1. PRODUCT OVERVIEW

The mecor Queen Size LED Bed Frame is a modern platform bed designed for comfort and style. It features an upholstered faux leather finish, solid wooden slats for mattress support, and an integrated LED light system in the headboard. The LED lights offer multiple colors, brightness settings, and lighting patterns, controllable via a remote.



Image: The mecor Queen Size LED Bed Frame with its headboard LED lights illuminated.

## 2. IMPORTANT SAFETY INFORMATION

---

**WARNING: Failure to follow these safety instructions may result in injury or product damage.**

- Always follow the assembly instructions carefully to prevent instability or collapse.
- Be cautious around sharp edges on the wooden frames and metal support bar during assembly.
- Handle the packaged boxes with care during unpacking and assembly to avoid injury.
- Ensure all connections for the LED lighting system are secure before plugging into a power source.
- Do not overload the bed frame beyond its maximum weight capacity of 551 lbs.

## 3. PACKAGE CONTENTS

---

Your mecor LED Bed Frame will arrive in two separate boxes. Please ensure you have received both boxes and all components before beginning assembly. All required tools are included.

Expected components include:

- Headboard with integrated LED lights
- Side rails
- Footboard
- Solid wooden slats
- Center support bar and legs
- Hardware pack (screws, bolts, washers, Allen wrench)
- Wireless remote control for LED lights
- RF controller for LED lights

- Power adapter for LED lights
- Instruction manual



Image: Illustration indicating the bed frame ships in two separate boxes (A and B).

# WIRELESS REMOTE + RF CONTROLLER + POWER ADAPTER



Image: The wireless remote, RF controller, and power adapter for the LED lighting system.

## 4. ASSEMBLY INSTRUCTIONS

Assembly of the mecor LED Bed Frame is designed to be straightforward. Follow the detailed instructions

provided in the included manual. All parts are labeled, and necessary tools are supplied.

1. **Unpack Components:** Carefully remove all parts from both boxes. Lay them out on a clean, soft surface to prevent scratches. Verify all components are present against the parts list in your manual.
2. **Assemble Headboard:** Attach any necessary support brackets or legs to the headboard as per the instructions. Ensure the LED strip is securely in place.
3. **Attach Side Rails:** Connect the side rails to the headboard and footboard using the provided hardware. Do not tighten screws completely until all major components are aligned.
4. **Install Center Support:** Place the metal center support bar and its legs into position. Secure them to the headboard and footboard or side rails as instructed.
5. **Place Wooden Slats:** Lay the solid wooden slats across the bed frame. Many slats are designed to fit into pre-drilled holes or use Velcro for secure placement. Ensure they are evenly spaced and firmly seated.
6. **Connect LED System:** Connect the LED strip from the headboard to the RF controller, and then connect the RF controller to the power adapter. Ensure these connections are snug.
7. **Final Tightening:** Once all parts are correctly aligned and in place, fully tighten all screws and bolts.

**Tip:** When installing screws, do not screw one side tightly before the other. Loosen one side, then screw the other side, and then tighten both evenly for best alignment.




Image: Detailed views of the bed frame's legs, wooden slats, and metal support structure.

Video: An official product video demonstrating the Mecor Upholstered Faux Leather Platform Bed with LED Light, showcasing its features and potentially assembly steps.

## 5. OPERATING THE LED LIGHTS

The integrated LED lights in the headboard can be controlled using the provided wireless remote.

- **Power On/Off:** Use the power button on the remote to turn the LED lights on or off.
- **Color Selection:** The remote allows you to choose from 8 different colors. Press the corresponding color button to change the light color.
- **Brightness Adjustment:** Adjust the brightness of the LED lights using the designated brightness control buttons. There are 6 brightness settings available.
- **Lighting Patterns:** Select from 4 different lighting patterns (e.g., flash, jump, fade) to create various ambient effects.




Image: The bed frame with its LED lights displaying various colors, alongside the remote control for operation.



Image: The bed frame illuminated with blue LED lights, demonstrating an ambient lighting option.

## 6. CARE AND MAINTENANCE

- **Cleaning the Upholstery:** For the faux leather upholstery, wipe clean with a soft, damp cloth. Avoid harsh chemicals or abrasive cleaners, as these can damage the material.
- **Cleaning LED Lights:** Gently wipe the LED strip with a dry, soft cloth to remove dust. Ensure the power is disconnected before cleaning.
- **Frame Inspection:** Periodically check all bolts and screws to ensure they remain tight. Re-tighten if necessary to maintain the bed frame's stability.
- **Slats Care:** Ensure the wooden slats are free from moisture and excessive weight to prevent warping or damage.

## 7. TROUBLESHOOTING

Problem	Possible Cause	Solution
LED lights do not turn on.	Power adapter unplugged, loose connection, remote battery dead.	Check if the power adapter is securely plugged into an outlet and the RF controller. Ensure all connections are tight. Replace remote battery if needed.
LED lights flicker or display incorrect colors.	Loose connection, faulty LED strip, remote interference.	Check all connections. Try repositioning the remote or moving potential sources of interference. If the issue persists, contact customer support for a possible replacement LED strip.

Problem	Possible Cause	Solution
Bed frame feels unstable or squeaks.	Loose hardware, uneven assembly.	Re-tighten all bolts and screws. Ensure the bed frame is on a level surface. Review assembly steps to confirm correct installation.
Missing parts during assembly.	Packaging error.	Contact mecor customer support immediately with your purchase details and a list of missing parts.

## 8. PRODUCT SPECIFICATIONS

**Model:** B08BZW2HKB

**Size:** Queen

**Product Dimensions:** 86.6"L x 62.6"W x 42.5"H

**Material:** Faux Leather, Wood Slats, LED Lights

**Color:** White

**Max Weight Capacity:** 551 lbs

**LED Features:** 8 Colors, 6 Brightness Settings, 4 Lighting Patterns

**Assembly Required:** Yes

**Box Spring Required:** No



Image: A diagram illustrating the length, width, and height dimensions of the bed frame, along with its maximum weight capacity.

## 9. WARRANTY AND SUPPORT

---

For warranty information, product support, or to order replacement parts, please contact mecor customer service. Refer to your purchase documentation for specific warranty terms and contact details. You can typically find support contact information on the mecor official website or through the retailer where you purchased the product.