Q & A | Deep Search | Upload

MAYTRONICS DOLPHIN S200 IG

Maytronics Dolphin S200 Robotic Pool Cleaner User Manual

Model: DOLPHIN S200 IG

INTRODUCTION

This manual provides essential information for the safe and efficient operation and maintenance of your Maytronics Dolphin S200 Robotic Pool Cleaner. Please read it thoroughly before first use.



Image: The Maytronics Dolphin S200 Robotic Pool Cleaner, a compact and efficient device designed for automated pool cleaning.

SETUP

Setting up your Dolphin S200 is a straightforward process, as no assembly is required.

- 1. **Power Connection:** Plug the Dolphin S200 into a suitable power source. Ensure the power outlet is protected and appropriate for outdoor use.
- 2. Placement in Pool: Carefully place the cleaner into the pool. Allow it to sink to the bottom.
- 3. Initiate Cleaning: The cleaner is designed for automatic operation once powered on and submerged.

The unit operates on 24 Volts and is designed for ease of use with a touch control method.

OPERATING INSTRUCTIONS

The Dolphin S200 is designed for automated cleaning cycles. Once initiated, it will navigate and clean your pool surfaces efficiently.

- Automatic Operation: The robotic cleaner will automatically clean the pool floor and walls.
- Cleaning Cycle: Allow the cleaner to complete its full cleaning cycle for optimal results.
- Removal: Once the cycle is complete, carefully remove the cleaner from the pool using its handle.

MAINTENANCE

Regular maintenance ensures the longevity and optimal performance of your Dolphin S200.

- 1. Filter Cleaning: After each cleaning cycle, remove the filter from the top of the unit and empty any collected debris.
- 2. Rinsing: Rinse the filter thoroughly with a hose to remove fine particles before the next use.
- 3. Storage: Store the device in a cool, dry place when not in use to protect its components.
- 4. Pre-use Check: Before and after each use, visually inspect the cleaner for any signs of damage or wear.

TROUBLESHOOTING

This section provides guidance for common issues you might encounter.

Problem	Possible Cause	Solution
Cleaner not moving	Power supply issue, tangled cable, debris in brushes.	Check power connection, untangle cable, clean brushes.
Poor cleaning performance	Full or dirty filter, worn brushes.	Clean or replace filter, inspect and replace brushes if necessary.
Cleaner floating	Air trapped inside, insufficient water saturation.	Submerge cleaner fully and gently shake to release trapped air.

SPECIFICATIONS

Feature	Detail
Brand	MAYTRONICS
Model Name	DOLPHIN S200 IG
Item Model Number	DOLPHIN S200 IG
ASIN	B08C1B23FD

Feature	Detail
UPC	724131497941
Assembly Required	No
Control Method	Touch
Voltage	24 Volts
Efficiency	Energy-efficient
Installation Type	Robotic
Material	ABS (Acrylonitrile Butadiene Styrene), Plastic
Power Source	Battery Powered
Special Feature	Lightweight
Item Weight	17 pounds
Package Dimensions	22 x 18 x 14 inches

WARRANTY INFORMATION

The Maytronics Dolphin S200 Robotic Pool Cleaner comes with a*Limited Warranty*. For specific terms and conditions, please refer to the warranty card included with your product or contact Maytronics customer service.

CUSTOMER SUPPORT

For further assistance, technical support, or spare parts, please contact Maytronics customer service. Refer to the product packaging or the official Maytronics website for contact details.

You can also visit the product page on Amazon for additional information and customer reviews.

© 2023 Maytronics. All rights reserved.