

Manuals+

[Q & A](#) | [Deep Search](#) | [Upload](#)

[manuals.plus](#) /

› [VAVA](#) /

› **VAVA Baby Monitor with 2 Cameras and Two-Way Audio, Split IPS Screen 720P 5" HD Video , 900ft Range, 4500 mAh Battery, One-Click Zoom, Night Vision**

VAVA VA-IH009

VAVA Baby Monitor User Manual

Model: VA-IH009 | Brand: VAVA

INTRODUCTION

This user manual provides comprehensive instructions for the VAVA Baby Monitor, designed to offer a clear and secure way to monitor your child. Featuring a 5-inch 720P HD display, two-way audio, and night vision, this monitor ensures you stay connected with your little one. Please read this manual thoroughly before use to ensure proper operation and safety.

WHAT'S IN THE BOX

- VAVA Baby Monitor Parent Unit (5" 720P HD Display)
- VAVA Baby Camera Unit (x2)
- Power Adapters (for Parent Unit and Camera Units)
- User Manual



Image: The VAVA Baby Monitor system, showing the parent unit with a split screen displaying two babies, and two camera units. The parent unit features control buttons for menu, zoom, auto-pilot, and talk.

SETUP

- 1. Charge the Parent Unit:** Connect the parent unit to a power outlet using the provided power adapter. Charge fully before first use. The 4500mAh battery provides up to 12 hours of display mode or 24 hours with the display off.
- 2. Position the Camera Units:** Place each camera unit in your child's room, ensuring a clear view of the crib or play area. The cameras can be wall-mounted or placed on a flat surface. Ensure the camera is out of reach of children and cords are secured.
- 3. Power On Cameras:** Connect each camera unit to a power outlet using its respective power adapter.
- 4. Pairing (if necessary):** The units are typically pre-paired. If pairing is required, navigate to the 'Camera Management' section in the parent unit's menu and follow the on-screen instructions to add or re-pair cameras. The monitor uses a secure, non-Wi-Fi connection for enhanced privacy.

OPERATING INSTRUCTIONS

Parent Unit Controls

The parent unit features intuitive buttons for easy navigation and control:

- **Menu Button:** Access settings and options.
- **Zoom Button:** Magnify the view (2X, 4X zoom).
- **Directional Pad (Auto-Pilot/OK):** Navigate menus and control camera pan/tilt. Press 'OK' to confirm selections or activate auto-pilot panoramic mode.
- **Talk Button:** Activate two-way audio to speak to your child through the camera.

Key Features

- **Split Screen Monitoring:** View feeds from both cameras simultaneously on the 5-inch HD display. This feature is ideal for monitoring two children or different areas of a single room.
- **Two-Way Audio:** Press and hold the 'Talk' button on the parent unit to communicate with your child through the camera's speaker. Release the button to hear your child.
- **Night Vision:** The cameras automatically switch to greyscale infrared night vision in low-light conditions, providing a clear view of your child even in complete darkness.
- **Temperature Monitoring:** An external thermostat on the camera provides real-time room temperature readings displayed on the parent unit.
- **VOX Mode (Voice Activated):** The monitor can be set to activate the screen and sound when noise is detected in the child's room, conserving battery life.
- **Long Range Connectivity:** Maintain a stable connection within a 480ft - 900ft range, allowing you to monitor from various locations within your home.

MAINTENANCE

- **Cleaning:** Use a soft, dry cloth to clean the parent unit and camera lenses. Do not use abrasive cleaners or solvents.
- **Battery Care:** To prolong battery life, avoid extreme temperatures and store the parent unit in a cool, dry place when not in use for extended periods.
- **Storage:** If storing the unit for a long time, fully charge the parent unit and then turn it off.

TROUBLESHOOTING

Problem	Solution
No image/Poor connection	Ensure both camera and parent units are powered on and within range. Re-pair the camera if necessary (refer to Setup section). Check for obstructions between units.
No sound/Static noise	Adjust volume on the parent unit. Ensure camera microphone is not blocked. Move units closer to reduce interference.
Parent unit battery drains quickly	Reduce screen brightness. Use VOX mode to turn off the display when no sound is detected. Ensure the battery is fully charged.
Camera not panning/tilting	Ensure the camera is powered on and connected. Use the directional pad on the parent unit to control movement.

SPECIFICATIONS

Model Number: VA-IH009

Display Size: 5 Inches

Video Capture Resolution: 720p

Connectivity Technology: Wireless (Non-Wi-Fi)

Power Source: Battery Powered (Parent Unit), AC Powered (Camera Units)

Battery Capacity (Parent Unit): 4500 mAh

Range: 480ft - 900ft (line of sight)

Special Features: Night Vision, Two-Way Audio, Split Screen, Temperature Monitoring, VOX Mode, One-Click Zoom

Indoor/Outdoor Usage: Indoor

Item Weight: 3.17 pounds

UPC: 757817222841

WARRANTY AND SUPPORT

For warranty information, product registration, or technical support, please visit the official VAVA website or contact their customer service. Keep your purchase receipt for warranty claims.

For additional assistance, you may refer to the [VAVA brand page on Amazon](#).