

Manuals+

[Q & A](#) | [Deep Search](#) | [Upload](#)

manuals.plus /

› [VIMAR](#) /

› [Vimar K40955 Wi-Fi 7 Inch Touch-Screen LCD 1-Family Video Door Entry Kit Instruction Manual](#)

VIMAR K40955

Vimar K40955 Wi-Fi 7 Inch Touch-Screen LCD 1-Family Video Door Entry Kit Instruction Manual

Model: K40955

1. INTRODUCTION

This manual provides comprehensive instructions for the installation, operation, and maintenance of your Vimar K40955 Wi-Fi 7 Inch Touch-Screen LCD 1-Family Video Door Entry Kit. Please read these instructions carefully before beginning installation or operation to ensure proper functionality and safety.

The Vimar K40955 kit is a surface-mounted video entry system designed for single-family residences. It includes a hands-free 7-inch touch-screen LCD monitor with Wi-Fi connectivity, a 1-button audio/video entrance panel with a rain cover, and a power supply unit. The system allows for remote management via a smartphone application.



Image 1.1: Overview of the Vimar K40955 Wi-Fi 7 Inch Touch-Screen LCD 1-Family Video Door Entry Kit components.

2. PACKAGE CONTENTS

Verify that all components listed below are present in your package:

- 1x 7-inch Hands-Free Touch-Screen LCD Video Entry Monitor with Wi-Fi
- 1x 1-Button Audio/Video Entrance Panel with Rain Cover
- 1x Power Supply Unit (Model 40103)
- 1x Fixing Bracket for monitor installation



Image 2.1: All components of the Vimar K40955 kit, including the monitor, outdoor panel, and power supply.

3. SETUP AND INSTALLATION

The Vimar K40955 kit is designed for straightforward installation. The components are pre-configured and do not require special programming for basic operation. For detailed wiring diagrams and advanced installation procedures, refer to the official VIMAR website for specific instructions and tutorials.

3.1. Wiring Considerations

- The maximum recommended distance between the outdoor entrance panel and the furthest indoor monitor is up to **100 meters** when using a **1 mm²** cable.
- Ensure all connections are secure and follow local electrical codes.

3.2. Mounting the Outdoor Panel

Mount the 1-button audio/video entrance panel in a suitable outdoor location, ensuring it is protected by the included rain cover. The panel has an IP44 rating for protection against solid objects larger than 1 mm and splashing water, and an IK07 rating for protection against mechanical impacts.




Image 3.1: Example of the outdoor entrance panel installed next to a door.

3.3. Mounting the Indoor Monitor

Install the 7-inch touch-screen LCD monitor indoors using the provided fixing bracket. Ensure the monitor is within Wi-Fi range for optimal performance and smartphone app connectivity.

Kit videocitofonico monofamiliare Wi-Fi

Wi-Fi 1-family video door entry kit



APP VIEW DOOR PER IL CONTROLLO DA SMARTPHONE E TABLET
VIEW DOOR APP FOR CONTROL FROM SMARTPHONES AND TABLETS

Scarica su  **App Store**

DISPONIBILE SU  **Google Play**




<p>WI-FI PER INOLTRO CHIAMATA WI-FI FOR CALL FORWARDING</p> 	<p>TARGA IN METALLO PRESSOFUSO DIE-CAST METAL PLATE</p> 
<p>POSTI INTERNI INTERCOMUNICANTI (NELLA STESSA UNITÀ ABITATIVA) INTERCOMMUNICATING INNER UNITS (IN THE SAME HOUSING UNIT)</p> 	<p>TELECAMERA GRANDANGOLO 120° 120° WIDE-ANGLE CAMERA</p> 
<p>REGISTRAZIONE VIDEO E IMMAGINI VIDEO/PICTURE RECORDING</p> 	<p>TELECAMERA TVCC COLLEGABILE CONNECTABLE CCTV CAMERA</p> 
<p>MICRO SD CARD DA 8 GB A 128 GB (NON INCLUSA) MICRO SD CARD FROM 8 GB TO 128 GB (NOT SUPPLIED)</p> 	<p>IP44 GRADO DI PROTEZIONE IP IP PROTECTION RATING</p> 
<p>MENÙ MULTILINGUA MULTILINGUAGE MENU</p> 	<p>IK07 GRADO DI ROBUSTEZZA IK PROTECTION AGAINST MECHANICAL IMPACTS</p> 

Image 3.2: The indoor monitor mounted on a wall, showing Wi-Fi connectivity.

4. OPERATION

4.1. Basic Functions

- **Answering Calls:** When a visitor presses the call button on the outdoor panel, the indoor monitor will ring and display the visitor's image. Touch the screen to answer.
- **Door Release:** During a call, an icon on the monitor allows you to remotely open an electric lock (if connected).
- **Intercom Function:** The system supports intercommunication between multiple indoor monitors within the same family unit (up to 3 monitors can be associated with each call button).

4.2. Monitor Settings

The 7-inch touch-screen LCD monitor provides various adjustable settings:

- **Volume Control:** Adjust the communication volume and ringtone volume.
- **Display Settings:** Adjust brightness, color, and contrast of the display.
- **Ringtone Selection:** Choose from 6 available melodies.
- **Do Not Disturb:** Activate this function to temporarily silence incoming calls.
- **Multi-language Menu:** The menu supports multiple languages including Italian, English, French, German, Spanish, Portuguese, Greek, and Dutch.

4.3. Wi-Fi Connectivity and Smartphone App

The integrated Wi-Fi allows for call forwarding to your smartphone or tablet via the Vimar View Door app. This enables you to answer calls, view visitors, and open the door remotely, even when you are away from home.




Image 4.1: The Vimar View Door app interface on a smartphone, showing remote control capabilities.

5. MAINTENANCE

To ensure the longevity and optimal performance of your Vimar K40955 video door entry kit, follow these simple maintenance guidelines:

- **Cleaning:** Use a soft, damp cloth to clean the indoor monitor and outdoor panel. Avoid abrasive cleaners, solvents, or harsh chemicals that could damage the surfaces.
- **Outdoor Panel:** Periodically check the outdoor panel for any obstructions to the camera or microphone, and ensure the rain cover is securely in place.
- **Software Updates:** Check the VIMAR website or the View Door app for any available firmware or software updates for your system to ensure you have the latest features and security enhancements.

6. TROUBLESHOOTING

If you encounter issues with your Vimar K40955 kit, refer to the following common problems and solutions:

Problem	Possible Cause	Solution
No image or sound on indoor monitor	Power supply issue, loose wiring, or monitor malfunction.	Check if the power supply is connected and functioning. Verify all wiring connections are secure. Restart the system by disconnecting and reconnecting power.
Wi-Fi connection unstable or not connecting	Weak Wi-Fi signal, incorrect Wi-Fi password, or router issue.	Ensure the monitor is within range of your Wi-Fi router. Re-enter Wi-Fi credentials on the monitor. Restart your Wi-Fi router.
Smartphone app not receiving calls	App not configured correctly, phone notifications disabled, or internet connectivity issue.	Check app settings for call forwarding and notifications. Ensure your smartphone has an active internet connection. Verify the monitor is connected to Wi-Fi.
Outdoor panel button not responding	Button malfunction or wiring issue.	Inspect the button for physical damage. Check the wiring connections to the outdoor panel.

For more complex issues or if the problem persists, please contact VIMAR customer support or consult the detailed troubleshooting guides available on the official VIMAR website.

7. TECHNICAL SPECIFICATIONS

Feature	Specification
Model Number	K40955
Monitor Type	7 Inch Touch-Screen LCD, Hands-Free
Connectivity	Wi-Fi
Family Support	1 Family
Expandability	Up to 3 monitors per call button
Outdoor Panel	1-Button Audio/Video with Rain Cover

Feature	Specification
Power Supply	Included (Model 40103), 120V-240V compatible
Max Wiring Distance	100m (with 1 mm ² cable)
Monitor Dimensions (L x W x H)	18.88 x 1.84 x 11.36 cm
Outdoor Panel Dimensions (L x W x H)	16.24 x 9.44 x 3.43 cm (approximate, based on diagrams)
Product Weight	1.33 kg
IP Rating (Outdoor Panel)	IP44
IK Rating (Outdoor Panel)	IK07
Supported Languages	Italian, English, French, German, Spanish, Portuguese, Greek, Dutch



Image 7.1: Dimensions of the indoor monitor (in mm).




Image 7.2: Dimensions of the outdoor entrance panel (in mm).

8. WARRANTY INFORMATION

Specific warranty details for the Vimar K40955 kit are typically provided with the product packaging or can be found on the official VIMAR website. Please retain your proof of purchase for warranty claims. Information regarding spare parts availability is not provided in this document; please consult the manufacturer's website for details.

9. CUSTOMER SUPPORT

For further assistance, detailed instructions, video tutorials, or technical support, please visit the official VIMAR website. The website provides comprehensive resources to help you with your video door entry system.

VIMAR Official Website: www.vimar.com