

[manuals.plus](#) /› [Sauder](#) /› [Sauder Harvey Park Wall Desk User Manual](#)**Sauder 423704**

Sauder Harvey Park Wall Desk User Manual

MODEL: 423704**Brand:** Sauder

INTRODUCTION

This manual provides comprehensive instructions for the assembly, operation, and maintenance of your Sauder Harvey Park Wall Desk. Designed for efficiency in limited spaces, this wall-mounted desk offers a convenient work surface and integrated storage. Please read this manual thoroughly before beginning assembly or use to ensure proper installation and longevity of your product.



Figure 1: Sauder Harvey Park Wall Desk (Closed)

SAFETY INFORMATION

Important Safety Precautions:

- Always ensure cords are properly managed and kept away from edges to prevent tripping hazards or damage to the desk or devices.
- Securely mount the cabinet to the wall according to manufacturer instructions to prevent tipping or falling. Failure to do so can result in serious injury or property damage.
- Do not exceed the maximum weight recommendation of 25 pounds on the drop-down work surface. Distribute weight evenly.
- Keep small children and pets away from the assembly area.

SETUP AND ASSEMBLY

The Sauder Harvey Park Wall Desk comes pre-assembled and primarily requires secure wall mounting.

Follow these steps carefully for installation.

Required Tools and Components:

- Drill
- Screwdriver
- Level
- Stud finder (recommended)
- Included mounting hardware and assembly instructions

Assembly Steps:

1. **Identify Mounting Location:** Choose a wall location that can support the weight of the desk and its contents. Use a stud finder to locate two wall studs for secure mounting. The mounting board has pre-drilled holes to accommodate various stud spacings.
2. **Determine Mounting Height:** Consider your preferred working height. The desk's overall height is 26.69 inches. The drop-down work surface will be approximately 11.75 inches from the bottom of the unit when open.
3. **Install Mounting Board:** Secure the provided mounting board to the wall studs using appropriate screws. Ensure the board is perfectly level before tightening.
4. **Mount the Desk:** Carefully lift the assembled wall desk and align its rear cleat with the installed mounting board. Lower the desk onto the board, ensuring it is securely seated and stable. It is recommended that one person performs the assembly.
5. **Final Check:** Gently test the desk's stability on the wall. Open and close the doors to ensure smooth operation.



Figure 2: Wall Desk Mounted (Closed View)




Figure 3: Product Dimensions

OPERATING INSTRUCTIONS

The Harvey Park Wall Desk is designed for versatile use as a compact workspace and storage unit.

Using the Work Surface:

- To access the work surface, gently pull the lower door handle. The door will flip down to create a spacious desk area suitable for a laptop, notepads, and other small items.
- When finished, lift the door back into its closed position until it latches securely.

Utilizing Storage and Organization:

- The two top doors swing open to reveal an upper storage compartment. This area is ideal for storing folders, envelopes, and other office supplies.
- An integrated tack board is located on the inside of one of the top doors, providing a convenient spot to pin important notes and reminders.
- Cord management pass-thrus are included to help keep your wires neat and organized, preventing clutter on the work surface.



Figure 4: Wall Desk in Open Position with Laptop



Figure 5: Integrated Corkboard

MAINTENANCE

Proper care and maintenance will ensure the longevity and appearance of your Sauder Harvey Park Wall Desk.

Cleaning:

- Wipe surfaces with a soft, damp cloth.
- Avoid using harsh chemicals, abrasive cleaners, or polishes that may damage the Grand Walnut finish.
- Promptly wipe up spills to prevent staining or damage to the engineered wood.

General Care:

- Periodically check all mounting hardware and screws to ensure they remain tight and secure. Retighten as necessary.
- Avoid placing hot items directly on the surface; use coasters or protective pads.
- Protect the desk from direct sunlight and extreme temperature changes to prevent warping or fading.

TROUBLESHOOTING

If you encounter any issues with your Sauder Harvey Park Wall Desk, refer to the following common troubleshooting tips:

Problem	Possible Cause	Solution
Desk feels wobbly or loose on the wall.	Mounting hardware is not fully tightened or not secured into wall studs.	Ensure the mounting board is securely fastened to at least two wall studs. Tighten all screws. If necessary, relocate the desk to a wall with proper stud support.
Drop-down door does not open or close smoothly.	Hinges may be misaligned or require lubrication. Obstruction in the mechanism.	Check for any obstructions. Inspect hinges for damage or misalignment. Apply a small amount of silicone lubricant to the hinge points if needed.
Top doors do not close flush.	Hinges are misaligned or screws are loose.	Adjust the hinge screws to align the doors. Ensure all hinge screws are tightened.
Excessive dust or debris accumulation.	Lack of regular cleaning.	Wipe down surfaces regularly with a soft, dry or slightly damp cloth.

SPECIFICATIONS

Detailed specifications for the Sauder Harvey Park Wall Desk:

Feature	Detail
Brand	Sauder
Model Number	423704
Model Name	Harvey Park
UPC	042666045537
Product Dimensions (D x W x H)	16.75"D x 28.12"W x 26.75"H
Color	Grand Walnut Finish
Style	Soft Modern
Base Material	Engineered Wood
Top Material Type	Engineered Wood
Finish Type	Walnut Finish
Room Type	Bedroom, Home Office, Living Room, Kitchen
Recommended Uses For Product	Residential Use

Feature	Detail
Mounting Type	Wall Mount
Item Weight	32.5 Pounds
Maximum Weight Recommendation	25 Pounds (on work surface)
Number Of Shelves	1 (internal)
Number Of Enclosed Shelves	2 (behind top doors)
Storage Options	Two top doors with a tack board
Working Surface Diagonal Length	30.93 Inches

WARRANTY INFORMATION

Your Sauder Harvey Park Wall Desk is covered by a **5-Year Limited Warranty**. This warranty protects your investment and covers parts for a period of five years from the date of purchase. For specific details regarding warranty claims or coverage, please refer to the official warranty documentation included with your product or contact Sauder customer support.


SUPPORT

For additional assistance, replacement parts, or further inquiries regarding your Sauder Harvey Park Wall Desk, please utilize the following support resources:

- **Live Chat Support:** Access on-demand support through the official Sauder website.
- **Assembly Tip Videos:** Find helpful video insights for assembly and installation on the Sauder support portal.
- **Replacement Parts:** Easily order replacement parts directly from Sauder for quick shipping.
- **Domestic Call Center:** Contact our dedicated domestic call center for personalized assistance.
- **Official Sauder Store:** Visit the [Sauder Store on Amazon](#) for more product information and support resources.

Related Documents - 423704

 <p>Wall Desk Harvey Park Collection Model 423704</p> <p>Download Assembly Instructions</p>	<p>Sauder Wall Desk - Harvey Park Collection - Model 423704 Assembly Instructions</p> <p>Comprehensive assembly instructions and safety guide for the Sauder Wall Desk (Model 423704) from the Harvey Park Collection. This manual includes a parts list, required tools, step-by-step assembly procedures in English, French, and Spanish, important safety warnings, and details on the 5-year limited warranty. Contact information for Sauder Woodworking Company is provided.</p>
--	--

 <p>Sauder Narrow Bookcase Assembly Instructions - Model 420283</p> <p>Comprehensive assembly guide for the Sauder Narrow Bookcase, Harvey Park Collection, Model 420283. Includes detailed steps, part identification, hardware list, safety precautions, and warranty information.</p>	
 <p>Sauder 4-Drawer Chest Assembly Instructions - Model 420824</p> <p>Comprehensive assembly guide for the Sauder Harvey Park Collection 4-Drawer Chest (Model 420824). Includes detailed steps, part identification, hardware lists, safety warnings, and warranty information.</p>	
 <p>Sauder Writing Desk Assembly Instructions & Safety Guide Model 425347</p> <p>Detailed assembly instructions, part identification, safety warnings, and 1-year limited warranty for the Sauder Model 425347 Writing Desk. Support available via sauder.com/service and phone.</p>	
 <p>Sauder L-Shaped Desk (Model 425773) Assembly Instructions</p> <p>Comprehensive assembly guide for the Sauder L-Shaped Desk, Model 425773, from the Rock Glen Collection. Includes part identification, hardware list, step-by-step instructions, and safety information.</p>	
 <p>Sauder 402375 Computer Desk Assembly Instructions</p> <p>Assembly instructions, safety information, and warranty details for the Sauder 402375 Computer Desk. Available in English, French, and Spanish.</p>	

Documents - Sauder – 423704



[Sauder Wall Desk - Harvey Park Collection - Model 423704 Assembly Instructions](#)

Comprehensive assembly instructions and safety guide for the Sauder Wall Desk (Model 423704) from the Harvey Park Collection. This manual includes a parts list, required tools, step-by-step assembly procedures in English, French, and Spanish, important safety warnings, and details on the 5-year limited warranty. Contact information for Sauder Woodworking Company is provided.

lang:en score:29 filesize: 337.53 K page_count: 12 document date: 2018-11-08