



Manuals.plus /

› Brandless /

› Instruction Manual for Universal Silicone Earbud Replacement Tips (9 Pairs, S/M/L Sizes)

Brandless Universal Silicone Earbud Replacement Tips (9 Pairs, S/M/L Sizes)

Instruction Manual: Universal Silicone Earbud Replacement Tips

Model: Universal Silicone Earbud Replacement Tips (9 Pairs, S/M/L Sizes)

1. PRODUCT OVERVIEW

These Universal Silicone Earbud Replacement Tips are designed to provide a comfortable and secure fit for a wide range of in-ear earphones. Made from soft, durable silicone, they offer enhanced noise isolation and stability. This package includes 9 pairs of tips across three sizes (Small, Medium, Large) to ensure an optimal fit for various ear canal sizes.




Image 1.1: Assortment of 9 pairs of silicone earbud tips in various colors and sizes.

2. PACKAGE CONTENTS

- 9 pairs of Silicone Earbud Tips (3 pairs Small, 3 pairs Medium, 3 pairs Large)
- 1 Cleaning Cloth

Note: Earphones are not included.




Image 2.1: Visual representation of package contents and key features.

3. SETUP AND INSTALLATION

These replacement earbud tips are compatible with earphones featuring an inner nozzle diameter between 3.8mm and 5.1mm, including models from SENSO, TOZO, Sony, and others.

3.1 Selecting the Correct Size

Choosing the right size is crucial for comfort, sound quality, and secure fit. Experiment with the Small, Medium, and Large tips to find the size that creates a good seal in your ear canal without causing discomfort.

Small: 11mm (Outer diameter) * 10mm (Height), Inner hole diameter: 3.8mm

Medium: 12mm (Outer diameter) * 10mm (Height), Inner hole diameter: 3.8mm

Large: 13mm (Outer diameter) * 10mm (Height), Inner hole diameter: 3.8mm




Image 3.1: Dimensions of Small, Medium, and Large earbud tips.

3.2 Attaching the Earbud Tips

1. Gently remove the existing earbud tip from your earphone's nozzle.
2. Align the new silicone tip with the earphone nozzle.
3. Apply gentle, firm pressure while twisting slightly to slide the tip onto the nozzle until it is securely seated. Ensure the tip is fully attached and not loose.



Image 3.2: Earbud tips correctly installed on earphones.

4. OPERATING (USAGE)

Once installed, the earbud tips are ready for use. Insert your earphones into your ears, ensuring a snug and comfortable fit. The silicone material is designed to provide a stable in-ear experience and improve passive noise isolation.

5. MAINTENANCE

To ensure hygiene and prolong the lifespan of your earbud tips:

- Regularly clean the earbud tips with the provided cleaning cloth or a soft, damp cloth.
- For deeper cleaning, remove the tips from the earphones and wash them gently with mild soap and water. Rinse thoroughly and allow them to air dry completely before reattaching.
- Avoid using harsh chemicals or abrasive materials, as these can damage the silicone.

6. TROUBLESHOOTING

6.1 Tips Do Not Fit Earphones

Ensure your earphone nozzle diameter is within the compatible range of 3.8mm to 5.1mm. If the nozzle is oval or significantly larger/smaller, these tips may not provide a secure fit.

6.2 Poor Sound Quality or Lack of Bass

This often indicates an improper seal in the ear canal. Try a different size tip (usually a larger one) to achieve a better seal. A good seal is essential for optimal audio performance and noise isolation.

6.3 Earbuds Do Not Fit in Charging Case with New Tips

Some earbud charging cases have limited space. If the new tips prevent the case from closing completely, they may be too large for the case design. Consider using smaller tips or checking if the earbud still charges and disconnects properly despite the case not fully closing.

7. SPECIFICATIONS

Product Type	Earbud Replacement Tips
Material	Silicone
Quantity	9 Pairs (3 Small, 3 Medium, 3 Large)
Compatible Inner Hole Diameter	3.8mm - 5.1mm
Small Tip Dimensions	11mm (Outer Diameter) x 10mm (Height)
Medium Tip Dimensions	12mm (Outer Diameter) x 10mm (Height)
Large Tip Dimensions	13mm (Outer Diameter) x 10mm (Height)
Item Weight	0.634 ounces
UPC	798131236756

8. WARRANTY AND SUPPORT

Your satisfaction is important. This product comes with a **30-day money-back guarantee**. If you encounter any issues or have questions regarding the product, please refer to your purchase documentation for contact information or visit the Brandless store on Amazon.