

SOFTSEA 117

SOFTSEA Twin Over Full Bunk Bed Instruction Manual

Model: 117 | Brand: SOFTSEA

1. PRODUCT OVERVIEW

The SOFTSEA Twin Over Full Bunk Bed is designed for versatility and space-saving, featuring a twin-size upper bed and a convertible twin/full-size lower bed. This innovative design allows for adaptation to various room configurations and family needs. The integrated staircase provides safe access to the upper bunk and includes built-in storage drawers and shelves, maximizing utility.

Key features include:

- **Convertible Design:** The lower bed can be configured as a twin or full size using provided wooden slats.
- **Integrated Storage:** Staircase with multiple drawers and shelves, plus under-bed drawers for ample storage.
- **Sturdy Construction:** Full-length guardrails and a solid frame ensure safety and durability.



Image: Overview of the SOFTSEA Twin Over Full Bunk Bed in grey, showcasing its structure with the upper twin bed, lower convertible bed, and integrated staircase with storage.

2. SAFETY INFORMATION

For the safety of all users, please adhere to the following guidelines:

- Always assemble the bunk bed strictly according to the provided instructions.
- Do not exceed the maximum weight limit of **400 lbs** for both the upper and lower bunks.
- Ensure full-length guardrails are securely attached at all times.
- This product is intended for children aged **6 years and above**.
- Always supervise children when they are using the bunk bed.
- Periodically check all connections and hardware to ensure they remain tight and secure.

3. SETUP AND ASSEMBLY

Assembly of the SOFTSEA Twin Over Full Bunk Bed is required. A detailed instruction manual with step-by-step diagrams and a complete list of components and hardware is included in the product packaging. Please ensure all parts are present and undamaged before beginning assembly.

Important Assembly Notes:

- It is recommended to assemble the bed with at least two adults.
- Clear a spacious area for assembly to prevent damage to components or flooring.
- Use hand tools for tightening fasteners to avoid overtightening, which can damage wood. If using power tools, set them to a low torque.
- Follow the numerical sequence of steps provided in the included manual.



Image: The bunk bed structure, highlighting the integrated staircase with storage compartments and the under-bed drawers.

4. OPERATING AND USAGE

This bunk bed offers flexible sleeping arrangements and ample storage solutions:

- **Convertible Lower Bed:** The lower bed can be used as a twin size or expanded to a full size by utilizing the extra wooden slats provided. This allows for accommodating more guests or providing additional sleeping space as needed. To convert, simply adjust the slats and frame as per the assembly instructions.
- **Staircase Access:** The 4-step staircase provides secure and easy access to the upper bunk.
- **Storage Drawers:** The staircase features multiple drawers and open shelves for storing books, toys, and other

personal items. The under-bed drawers, equipped with wheels, offer convenient storage for bedding, clothes, or other belongings, helping to keep the room tidy.



Image: Close-up view of the spacious under-bed storage drawers, designed for easy access and organization.



Image: Detail of the staircase, showing the integrated shelves and drawers for convenient storage.

5. MAINTENANCE AND CARE

To ensure the longevity and appearance of your SOFTSEA Bunk Bed, follow these care instructions:

- **Cleaning:** For general cleaning, use a soft, dry cloth. For stubborn marks, a slightly damp cloth can be used, followed immediately by a dry cloth. Avoid abrasive cleaners or harsh chemicals, as these can damage the stained finish.
- **Product Care Instructions:** Dry Clean Only. This refers to the general care of the wood finish.
- **Hardware Check:** Periodically (e.g., every 3-6 months) inspect all bolts, screws, and connections to ensure they are tight. Re-tighten if necessary to maintain structural integrity and safety.
- **Avoid Excessive Moisture:** Do not expose the bed to excessive moisture or humidity, as this can cause warping or damage to the wood.

6. TROUBLESHOOTING

If you encounter any issues during assembly or use, please refer to the following common solutions:


Problem	Possible Cause	Solution
Missing or Damaged Parts	Shipping damage or packaging error.	Do not proceed with assembly. Contact customer support immediately with your purchase details and a description of the missing/damaged parts.
Difficulty aligning holes during assembly	Parts are not correctly oriented or minor manufacturing variance.	Double-check part orientation against the manual's diagrams. Loosen adjacent connections slightly to allow for minor adjustments, then re-tighten. Avoid forcing parts.
Bed feels wobbly after assembly	Hardware not fully tightened or uneven floor.	Ensure all bolts and screws are securely tightened. If the floor is uneven, consider using furniture pads or shims under the bed legs to stabilize it.
Drawers do not slide smoothly	Obstruction, misaligned runners, or debris.	Check for any objects obstructing the drawer path. Ensure drawer runners are correctly installed and free of debris.

If the issue persists after attempting these solutions, please contact SOFTSEA customer support for further assistance.

7. SPECIFICATIONS

Feature	Detail
Model Number	117
Product Dimensions (Overall)	94.4"L x 77.7"W x 63.6"H (with drawers out)
Upper Bed Dimensions	42.4"L x 75.9"W (Twin)
Lower Bed Dimensions (Twin)	42.4"L x 75.9"W
Lower Bed Dimensions (Full)	57.5"L x 78.7"W
Weight Capacity (Upper Bunk)	400 lbs
Weight Capacity (Bottom Bunk)	400 lbs
Recommended Mattress Thickness (Top Bunk)	6 inches
Material	Pine Wood (Stained Finish)
Color	Grey
Assembly Required	Yes
Item Weight	242 pounds

SIZE : INCH



Note: The blue part is the lengthened version

Image: Detailed diagram showing the dimensions of the bunk bed, including the convertible lower bed and storage components.

8. WARRANTY AND SUPPORT

Your SOFTSEA Twin Over Full Bunk Bed comes with a **365-day warranty** from the date of purchase. This warranty covers manufacturing defects and issues arising from normal use.

For Warranty Claims or Support:

- If any part is missing or damaged during shipping or assembly, please contact SOFTSEA customer service immediately.
- Provide your purchase details, including the order number and date of purchase, along with a clear description and photos (if applicable) of the issue.
- Our support team will assist you in resolving the problem as quickly as possible.

Please retain your proof of purchase for warranty purposes.

© 2025 SOFTSEA. All rights reserved.

ASK A QUESTION ABOUT THIS MANUAL

Ask about setup, troubleshooting, compatibility, parts, safety, or missing instructions. Manuals+ will review the question and use this page's manual context to help answer it.

Name

Anonymous

Email

you@example.com

After a successful submission, we securely hash the supplied account or form email before sending it to Microsoft Advertising for conversion attribution. [Privacy details](#).

Question

Example: How do I reset this device or fix this error?

Details

Model number, symptoms, what you tried, or the section of the manual you are using.

Submit question