

[Manuals.plus](#) /

> [Ivation](#) /

> Ivation Huge 24-inch Digital LED Clock User Manual

Ivation JID0124TRED

Ivation Huge 24" Digital LED Clock User Manual

Brand: **Ivation**

Model: **JID0124TRED**

1. INTRODUCTION

Thank you for choosing the Ivation Huge 24" Digital LED Clock. This oversized timekeeper is designed for maximum visibility and convenience, featuring a large LED display for time, AM/PM, and temperature. It also includes versatile functions such as a stopwatch, countdown timer, and multiple alarm options, all controllable via a handy remote. Ideal for homes, offices, gyms, and spaces where clear, large-format time display is essential.



Figure 1: Ivation 24" Digital LED Clock and Remote Control.

2. IMPORTANT SAFETY INFORMATION

- Read all instructions carefully before use.
- Keep the device away from water and moisture.

- Do not expose to extreme temperatures or direct sunlight for prolonged periods.
 - Use only the provided AC adapter.
 - Do not attempt to disassemble or repair the device. Contact qualified service personnel for assistance.
 - Ensure the clock is securely mounted if wall-mounted to prevent falling.
-

3. PACKAGE CONTENTS

- Ivation 24" Digital LED Clock
 - Multi-Function Remote Control
 - 10-Ft AC Power Adapter
 - Mounting Hardware (screws and anchors)
 - User Manual (this document)
-

4. PRODUCT OVERVIEW

4.1. Front Display

The front of the clock features a large LED display showing time (Hour, Minute, Second), AM/PM indicator, and temperature. The digits are 3.25 inches high for excellent visibility.

EASY-READ SCREEN

Displays Hour, Minute, and Second



Figure 2: Front Display and Dimensions.

4.2. Rear Panel

The rear panel includes the power input port and built-in mounting holes for easy wall installation.

SITS FLUSH ON ANY WALL



10ft Power
Cord



Mounting
Hardware




Figure 3: Rear Panel with Power Port and Mounting Holes.

4.3. Remote Control

The included multi-function remote control allows for convenient adjustment of all clock settings from a distance. Key buttons include:

- **Clock:** Switches display to current time.
- **Display:** Cycles through time, date, and temperature.
- **Mute:** Toggles alert sounds on/off.
- **Brightness:** Cycles through 6 brightness levels.
- **Alarm:** Accesses alarm settings.
- **Start/Stop:** Starts/stops stopwatch or countdown timer.
- **Countdown:** Activates countdown timer function.
- **Stopwatch:** Activates stopwatch function.
- **Set/Enter:** Confirms settings.
- **F/C:** Toggles temperature display between Fahrenheit and Celsius.
- **AM/PM 12/24:** Cycles through 12-hour and 24-hour time formats.
- **Number Pad (0-9):** Used for manually setting time and date.

INCLUDED MULTI-FUNCTION REMOTE CONTROL PUTS THE POWER IN THE PALM OF YOUR HAND



Figure 4: Remote Control Layout.

5. SETUP

5.1. Power Connection

Connect the provided 10-foot AC power adapter to the power input port on the rear of the clock. Plug the adapter into a standard wall outlet. The clock will power on and display the current time.

Your browser does not support the video tag.

Video 1: Demonstrates connecting the AC power adapter to the clock and plugging it into an outlet. This video also provides an overview of the clock's features and applications.

5.2. Mounting (Optional)

The clock can be placed on a shelf or mounted on a wall. For wall mounting:

1. Choose a suitable location on a wall.
2. Use the built-in mounting holes on the rear of the clock as a template to mark the drilling points on the wall.
3. Drill holes and insert the provided wall anchors if necessary.
4. Secure the clock to the wall using the provided screws. Ensure it is level and stable.

SITS FLUSH ON ANY WALL



10ft Power
Cord



Mounting
Hardware




Figure 5: Mounting Holes on Rear Panel.

6. OPERATING INSTRUCTIONS

6.1. Setting Time and Date

1. Press the **Clock** button on the remote to ensure the time is displayed.
2. Use the number pad on the remote to enter the desired time (e.g., 0930 for 9:30).
3. Press **Set/Enter** to confirm.

4. To set the date, press the **Display** button until the date is shown. Use the number pad and **Set/Enter** to adjust.
5. Toggle between 12-hour and 24-hour format using the **AM/PM 12/24** button.

6.2. Setting Alarms

The clock features 8 unique alarm settings.

1. Press the **Alarm** button on the remote.
2. Use the number pad to enter the desired alarm time.
3. Press **Set/Enter** to save the alarm.
4. Repeat for additional alarms.
5. To mute alarm sounds, press the **Mute** button.

6.3. Using the Stopwatch

The stopwatch function is ideal for timing workouts, games, or other activities.

1. Press the **Stopwatch** button on the remote. The display will show 00:00:00.
2. Press **Start/Stop** to begin timing.
3. Press **Start/Stop** again to pause.
4. To reset, press the **Stopwatch** button again while paused or stopped.

Your browser does not support the video tag.

Video 2: Demonstrates the stopwatch function, showing how to start, stop, and reset the timer. This is particularly useful for gym workouts.

6.4. Using the Countdown Timer

Set a countdown for various tasks, up to 99:59:59.


1. Press the **Countdown** button on the remote.
2. Use the number pad to enter the desired countdown time (e.g., 001000 for 10 minutes).
3. Press **Start/Stop** to begin the countdown.
4. The clock will beep when the countdown reaches zero.

6.5. Adjusting Brightness

The clock offers 6 levels of brightness to suit different lighting conditions.

1. Press the **Brightness** button on the remote repeatedly to cycle through the 6 available levels.
2. Select the desired brightness level for optimal visibility.

6 ADJUSTABLE
BRIGHTNESS LEVELS



SAVES CURRENT TIME
EVEN WHEN POWERED OFF



Figure 6: 6 Adjustable Brightness Levels.

6.6. Temperature Display

The clock displays the ambient temperature. To switch between Fahrenheit and Celsius:

- Press the **Display** button until the temperature is shown.
- Press the **F/C** button to toggle between Fahrenheit (°F) and Celsius (°C).

7. MAINTENANCE

- Clean the clock's display and casing with a soft, dry cloth.
- Do not use abrasive cleaners or solvents.
- Ensure the clock is unplugged before cleaning.

8. TROUBLESHOOTING

Problem	Possible Cause	Solution
Clock not displaying	No power or loose connection.	Ensure AC adapter is securely plugged into the clock and a working wall outlet.
Remote not working	Low/dead batteries or obstructed signal.	Replace remote batteries (2x AAA). Ensure no obstructions between remote and clock. Point remote directly at the clock.
Incorrect time displayed	Time not set correctly.	Follow instructions in Section 6.1 to set the correct time.
Display too bright/dim	Brightness level needs adjustment.	Use the Brightness button on the remote to cycle through levels.

9. SPECIFICATIONS

- **Brand:** Ivation
- **Model Number:** JID0124TRED
- **Color:** Red (LED display)
- **Product Dimensions:** 1.75"D x 24"W x 8"H
- **Item Weight:** 3.76 pounds
- **Screen Size:** 61 Centimeters (approx. 24 inches)
- **Number of Brightness Settings:** 6
- **Power Source:** AC Adapter (10-Ft cord included)
- **Batteries Required (Remote):** Yes (2x AAA, not included)
- **Functions:** Time, AM/PM, Temperature, Stopwatch, Countdown Timer, 8 Alarms

10. WARRANTY AND SUPPORT

For warranty information or technical support, please contact Ivation customer service. Keep your purchase receipt and model number handy for faster service.
Visit the Ivation Store: [Ivation Official Store](#)

ASK A QUESTION ABOUT THIS MANUAL

Ask about setup, troubleshooting, compatibility, parts, safety, or missing instructions. Manuals+ will review the question and use this page's manual context to help answer it.

Name

Anonymous

Email

you@example.com

After a successful submission, we securely hash the supplied account or form email before sending it to Microsoft Advertising for conversion attribution. [Privacy details](#).

Question

Example: How do I reset this device or fix this error?

Details

Model number, symptoms, what you tried, or the section of the manual you are using.

Submit question

Open the live page

<https://manuals.plus/asin/B08C8P5BXK>

More documents and user manuals: **<https://manuals.plus/>**