

[Manuals.plus](#) /

> [Moongiantgo](#) /

> Moongiantgo 1700W High Pressure Steam Cleaner User Manual

Moongiantgo Controllable Steam Spray Gun

Moongiantgo 1700W High Pressure Steam Cleaner User Manual

Model: Controllable Steam Spray Gun

Brand: Moongiantgo

1. INTRODUCTION

Thank you for choosing the Moongiantgo 1700W High Pressure Steam Cleaner. This portable, handheld steam cleaning machine is designed for effective and chemical-free cleaning across various surfaces in commercial and home environments, including kitchens, bathrooms, grout, tiles, and car detailing. With its powerful 1700W heating element, it delivers high-temperature and high-pressure steam for deep cleaning and stain removal. Please read this manual thoroughly before operation to ensure safe and optimal use of your device.



Figure 1: Moongiantgo 1700W High Pressure Steam Cleaner with accessories.

2. IMPORTANT SAFETY INSTRUCTIONS

To reduce the risk of fire, electric shock, or injury, always follow these basic safety precautions:

- Do not clean items with a temperature resistance below 150°C (302°F).
- When replacing brush accessories, ensure the air vent is completely stopped. Do not touch the jet switch to avoid burns.

- When cleaning glass products, be aware that they may crack due to uneven heating.
- If the steam nozzle is blocked by foreign matter (e.g., limescale) during use, twist the nozzle off and remove the foreign matter.
- Always ensure the steam hose is securely connected before use. If loose, turn clockwise to tighten.
- Before connecting the spray gun, confirm that a waterproof gasket is present at the connection of the extension rod.

3. PRODUCT COMPONENTS

Your Moongiantgo Steam Cleaner package includes the following items:

- 1 x Cleaning Machine (Main Unit)
- 1 x Plastic Carrying Case
- 1 x Extended Elbow Nozzle
- 2 x Copper Brush
- 2 x Plastic Brush
- 1 x Flashlight (Battery not included)
- 1 x Gloves
- 1 x Rag
- 1 x Plastic Scraper
- 1 x Silicone Water Inlet Pipe (1.2m)

PRODUCT ACCESSORIES



Figure 2: Included accessories for the steam cleaner.

4. SETUP

1. **Connect the Steam Hose:** Securely connect the steam hose to the main unit. Turn clockwise to tighten if loose.
2. **Prepare Water Supply:** Place the silicone water inlet pipe into a bucket or sink filled with water. The tankless design allows for continuous water supply.
3. **Attach Nozzle/Brush:** Choose the appropriate nozzle or brush for your cleaning task. For extended reach, first remove the metal nozzle from the spray gun, then install the extension rod, ensuring the waterproof gasket is in place. Attach the desired brush head (plastic or metal) to the end of the extension rod.

Video 1: Demonstrates how to install the extension tube and brush heads for the Moongiantgo steam cleaner.

HIGH PRESSURE CLEANING WITH CHEMICAL-FREE STEAM



Figure 3: Steam gun with adjustable steam humidity control.

5. OPERATING INSTRUCTIONS

1. **Power On:** Plug the machine into a 110V AC power outlet and press the ON/OFF switch.
2. **Adjust Steam Humidity:** Use the knob on the main unit to adjust the steam humidity. It is recommended to start with the 'wettest' setting first to allow the machine to absorb water and prevent dry burning.
3. **Initiate Steam:** Hold the trigger of the steam gun. Fast steam will emerge within approximately 15-20 seconds. When the machine is first started, only water may flow out; this is normal until steam builds up.
4. **Cleaning:** Direct the steam towards the surface to be cleaned. For higher temperatures, keep the nozzle as close as possible to the object (within 3cm/1.2 inches), as steam temperature drops rapidly with distance.
5. **Stop Steam:** Release the trigger to stop the steam flow. If the ON/OFF switch remains on but the trigger is not pressed, the nozzle may 'smoke' due to steam accumulation inside the machine. Only press the trigger to spray out steam.
6. **Completion:** After cleaning, release the trigger and turn off the ON/OFF switch. Be cautious as the nozzle may continue to spray residual steam.



Figure 4: Example of effective cleaning on a stove burner.



Figure 5: Multi-purpose applications of the steam cleaner.

6. MAINTENANCE

Regular maintenance ensures the longevity and optimal performance of your steam cleaner.

- **Nozzle Cleaning:** If steam comes out intermittently, first check if the nozzle is blocked. Use the provided wire to clear any obstructions.
- **Descaling:** If the steam flow decreases after a period of use, it's necessary to perform descaling. Mix vinegar or citric acid 1:1 with water. Remove the steam nozzle, turn on the power switch, and let the machine work for 5-10 minutes, drawing in the descaling solution. After that, suck clean water and turn on the power switch to wash out scale inside the machine interior and steam hose.

Video 3: General overview and usage tips for the Moongiantgo 1700W High Pressure Steam Cleaner, including maintenance.

7. TROUBLESHOOTING

Problem	Possible Cause	Solution
No steam or intermittent steam.	No water in the bucket, clogged nozzle, or insufficient heating time.	Ensure water inlet pipe is submerged. Clear nozzle with wire. Allow 15-20 seconds for heating.
Water leakage from connections.	Loose connections or missing/damaged waterproof gasket.	Tighten all connections. Check and replace waterproof gaskets if necessary.
Steam output decreases.	Limescale buildup inside the machine or hose.	Perform descaling procedure as described in the Maintenance section.
Machine does not turn on.	No power supply or faulty power switch.	Check power outlet and connections. Ensure ON/OFF switch is fully engaged.

8. SPECIFICATIONS

- **Model Name:** Controllable Steam Spray Gun
- **Wattage:** 1700 watts
- **Voltage:** 110 Volts
- **Maximum Temperature:** 100°C (212°F)
- **Item Weight:** 2.5 Kilograms
- **Item Dimensions (D x W x H):** 3.54" x 7.87" x 4.72"
- **Power Source:** AC
- **Special Features:** 360° Chemical Free Cleaning, Hand-held design, Easy to carry, High Temperature Steam, Steam Humidity Adjustment, Silicone Water Inlet Pipe.

9. WARRANTY AND SUPPORT

The Moongiantgo 1700W High Pressure Steam Cleaner comes with a **1-YEAR WARRANTY & FREE PARTS REPLACEMENT**. For any questions, concerns, or support needs, please contact Moongiantgo customer service. You can find contact information on the product packaging or through your retailer.

ASK A QUESTION ABOUT THIS MANUAL

Ask about setup, troubleshooting, compatibility, parts, safety, or missing instructions. Manuals+ will review the question and use this page's manual context to help answer it.

Name

Anonymous

Email

you@example.com

After a successful submission, we securely hash the supplied account or form email before sending it to Microsoft Advertising for conversion attribution. [Privacy details](#).

Question

Example: How do I reset this device or fix this error?

Details

Model number, symptoms, what you tried, or the section of the manual you are using.

Submit question