



Manuals.plus /

› Bluenin /

› Bluenin T30 True Wireless Earbuds User Manual

Bluenin T30

Bluenin T30 True Wireless Earbuds User Manual

Model: T30

INTRODUCTION

Thank you for choosing the Bluenin T30 True Wireless Earbuds. These earbuds are designed to provide a superior audio experience with advanced features such as Bluetooth 5.0 connectivity, CVC8.0 noise-canceling microphone, and IPX7 waterproofing, making them ideal for various activities including sports and travel. This manual will guide you through the setup, operation, and maintenance of your new earbuds.



Image: The Bluenin T30 True Wireless Earbuds, showcasing their design and the charging case with a digital battery display.

SETUP


Unboxing and Initial Charge

Upon receiving your Bluenin T30 earbuds, carefully open the packaging. Inside, you will find the earbuds, the charging case, and a USB charging cable. It is recommended to fully charge the earbuds and the charging case before first use.

Wearing the Earbuds

The Bluenin T30 earbuds feature an ergonomic anti-fall earhook design for a secure and comfortable fit, especially during active use. Gently insert the eartips into your ears and adjust the earhook to rest comfortably around your ear.

Secure & Comfy Fit



Ergonomic
Anti-fall Earhook



Delicate eartips insert
into your ears more
stably and comfortably

Image: A person demonstrating the secure and comfortable fit of the Bluenin T30 earbuds with their ergonomic anti-fall earhook design.

One-Step Pairing

The T30 earbuds utilize Bluetooth 5.0 technology for stable and fast connections. To pair them with your device:

1. Ensure your device's Bluetooth is turned on.
2. Take both earbuds out of the charging case. They will automatically power on and enter pairing mode.
3. On your device, search for Bluetooth devices and select "Bluenin T30" from the list.
4. Once connected, you will hear a confirmation prompt, and the earbuds will be ready for use.

ONE-STEP Pairing

Bluetooth 5.0 technology ensures an incredible stable and fast connection. Just take them out from the case, they will automatically paired and connected.



Image: A visual representation of the one-step pairing process, showing the earbuds connecting to a smartphone via Bluetooth.

OPERATING

Touch Controls

The Bluenin T30 earbuds feature sensitive touch controls for easy management of your audio and calls. The touch

sensitive area is located on the outer surface of each earbud.

Action	Control
Volume +/-	Specific touch gesture (refer to quick start guide for exact gesture)
Play / Pause	Single tap on either earbud
Next / Previous Track	Double tap (right for next, left for previous)
Answer / Reject Call	Single tap to answer, long press to reject
Power On / Off	Long press or place in/remove from case

Sensitive Touch Control



Volume +/-



Play / Pause



Next / Previous



Answer / Reject



On / Off



Image: An illustration detailing the various touch control functions available on the Bluenin T30 earbuds for media and call management.

Audio Quality and Noise Cancellation

The T30 earbuds deliver premium HiFi sound with deep bass and crystal clear treble. They are equipped with CVC 8.0 Noise Cancellation technology, which helps to reduce ambient noise for clearer calls and a more immersive listening experience.

Premium HiFi Sound

Deep Bass & Crystal Clear Treble & Negligible Latency



Bluetooth
5.0



CVC 8.0
Noise Cancellation



Image: Highlighting the premium HiFi sound, Bluetooth 5.0, and CVC 8.0 Noise Cancellation features of the Bluenin T30 earbuds.

MAINTENANCE

Charging the Earbuds and Case

The Bluenin T30 earbuds offer a long-lasting playtime of up to 6 hours on a single charge, with the charging case providing an additional 23 recharges, totaling up to 136 hours of playtime. The charging case also functions as a

backup power bank for your personal devices.

- To charge the earbuds, place them back into the charging case. The digital display on the case will show their charging status.
- To charge the case, connect it to a power source using the provided USB cable. The display will indicate the case's battery level.



Image: The Bluenin T30 charging case acting as a power bank, illustrating its long-lasting playtime capabilities and ability to charge other devices.

Water Resistance (IPX7)

The T30 earbuds are IPX7 waterproof, meaning they are resistant to sweat, water, and rain. This makes them suitable for workouts and outdoor activities. While they can withstand splashes and brief immersion, they are not designed for swimming or prolonged submersion.

- After exposure to sweat or water, ensure the earbuds are dry before placing them back into the charging case to prevent damage to the charging contacts.
- Clean the earbuds regularly with a soft, dry cloth to remove any earwax or debris.

IPX7 Waterproof

Resistant to sweat, water and rain



Image: The Bluenin T30 earbuds submerged in water, illustrating their IPX7 waterproof rating, making them resistant to sweat, water, and rain.

TROUBLESHOOTING

Common Issues and Solutions

- **Earbuds not pairing:** Ensure both earbuds are out of the case and fully charged. Turn off and on your device's Bluetooth. If issues persist, try forgetting the device in your Bluetooth settings and re-pairing.
- **Only one earbud working:** Place both earbuds back into the charging case, close the lid, wait a few seconds, then take them out again. This often re-syncs them.
- **No sound:** Check the volume level on both your device and the earbuds. Ensure the earbuds are properly connected to your device.
- **Charging issues:** Clean the charging contacts on both the earbuds and inside the case with a dry cotton swab. Ensure the charging cable is securely connected and the power source is active.
- **Poor sound quality:** Ensure the earbuds are securely fitted in your ears. Check for any debris blocking the speaker mesh. Move closer to your connected device to avoid interference.

SPECIFICATIONS

Feature	Detail
Model Name	T30
Brand	Bluenin
Connectivity Technology	Wireless (Bluetooth 5.0)
Form Factor	In Ear with Earhook
Noise Control	CVC 8.0 Noise Cancellation
Water Resistance Level	IPX7 Waterproof
Control Method	Touch
Battery Life (Earbuds)	Up to 6 Hours
Total Playtime (with Case)	Up to 136 Hours
Charging Case Function	Backup Power Bank
Material	Silicone
Product Dimensions	4.72 x 2.36 x 1.97 inches
Item Weight	8.8 ounces

WARRANTY AND SUPPORT

Bluenin products are designed for reliability and performance. For warranty information, technical support, or service inquiries, please refer to the contact details provided in your product packaging or visit the official Bluenin website. Please retain your proof of purchase for warranty claims.

For further assistance, you may also contact the seller directly through the platform where the product was purchased.