

ACEVIVI AMP005146

ACEVIVI AMP005146 Foot Spa Massager User Manual

Model: AMP005146 | Brand: ACEVIVI

1. IMPORTANT SAFETY INSTRUCTIONS

Please read all instructions carefully before using the ACEVIVI Foot Spa Massager. Failure to follow these instructions may result in electric shock, fire, or serious injury.

- Always unplug the device before use, cleaning, or maintenance.
- Do not submerge the electrical components in water.
- Avoid using the device if you have any medical conditions that could be affected by heat or massage. Consult a physician if you have concerns.
- Keep the device away from children and pets.
- Always follow the instructions provided with the device.
- Ensure the device is placed on a stable, level surface during use.
- Do not operate if the cord or plug is damaged.
- Do not stand in the foot spa. Use while seated.

2. PRODUCT OVERVIEW

The ACEVIVI AMP005146 Foot Spa Massager is designed to provide a comprehensive foot care experience, integrating heating, bubbles, motorized massage, red light therapy, and a pedicure stone. It features a user-friendly control panel and convenient design elements for ease of use and maintenance.



Figure 2.1: Key Components of the Foot Spa Massager

3. SETUP

1. **Placement:** Place the foot spa on a flat, stable surface. Ensure it is near an electrical outlet and a water source.
2. **Attach Wheels (Optional):** The unit comes with 4 detachable universal wheels. To attach, align the wheel stems with the designated holes on the bottom of the unit and push firmly until they click into place.
3. **Fill with Water:** Open the basin cover. Fill the foot spa with water, ensuring the water level is between the minimum and maximum fill lines indicated inside the basin. Do not overfill.
4. **Plug In:** Connect the power cord to a suitable electrical outlet.

Available for Size 13 Feet



Dust Cap for Full Cover



Hidden Handle



Drain



Detachable Wheels

Figure 3.1: User-Friendly Design Features

4. OPERATING INSTRUCTIONS

The control panel allows you to customize your foot spa experience. Refer to Figure 4.1 for button layout.



Figure 4.1: Control Panel Overview

1. **Power On/Off:** Press the **ON/OFF** button to turn the unit on or off. The LED screen will display the current temperature or 'OF' when off.
2. **Set Temperature:** Use the **Temp+** and **Temp-** buttons to adjust the desired water temperature. The intelligent constant temperature system maintains the set temperature between 95-118°F (35-48°C).
3. **Set Timer:** Press the **Timer** button to set the duration of your foot spa session. The timer can be adjusted in increments.
4. **Activate Bubbles & Red Light:** Press the **Red Light/Bubble** button to activate the bubble surging jets and the red light therapy. Press again to cycle through modes or turn off.
5. **Activate Massage:** Press the **Massage Frequency** button to activate the motorized Tai Chi wheel massage balls and corn rollers. Press again to cycle through different massage modes or turn off.
6. **Use Pedicure Stone:** The integrated pedicure stone rotates to help remove dead skin and calluses. Gently place your foot on the stone during your session.

5. FEATURES & FUNCTIONS

- **Fully Automatic Multi-Mode Foot Spa:** Equipped with 360° motorized rotate Tai Chi wheel massage balls and corn rollers with acu-notes for deep kneading massage. Offers 3 types of foot spa bath modes.
- **All-in-One Design:** Integrates heating, bubbles, massage, red light, and a pedicure stone. All functions can operate independently or simultaneously.
- **Rapid Heating & Intelligent Constant Temperature:**Heats water from 77°F (25°C) to 104°F (40°C) in under 10 minutes. Maintains a stable temperature between 95-118°F (35-48°C) with precise 1°C control.
- **Convenient Design:** Features a detachable basin cover, a carrying handle, a drainage pipe, and 4 detachable universal wheels for easy movement, cleaning, and storage.
- **Large Capacity:** Dimensions of 17.7 x 15.7 x 14.9 inches accommodate men's feet up to size 14.

6. MAINTENANCE & CLEANING

Regular cleaning ensures hygiene and extends the product's lifespan.

1. **Drain Water:** After each use, unplug the unit. Locate the drainage pipe on the side of the basin. Pull out the plug to drain the water.
2. **Clean Basin:** Rinse the basin with clean water. Use a soft cloth and mild soap to wipe down the interior and exterior surfaces. Avoid abrasive cleaners.
3. **Dry:** Ensure all components are thoroughly dry before storing.
4. **Storage:** Store the foot spa in a cool, dry place, away from direct sunlight. The detachable basin cover helps prevent dust accumulation.

7. TROUBLESHOOTING

- **Unit does not power on:** Ensure the power cord is securely plugged into a working electrical outlet. Check if the ON/OFF button has been pressed.
- **Water is not heating:** Verify that the desired temperature is set using the Temp+ button. Allow a few minutes for the water to reach the set temperature.
- **Massage/Bubbles/Red Light not working:** Ensure the respective function buttons are pressed. Check if the unit is powered on and has sufficient water.
- **Unusual noise:** Turn off the unit and unplug it. Check for any obstructions in the massage rollers or bubble jets. If the issue persists, contact customer support.

8. SPECIFICATIONS

Feature	Detail
---------	--------

Feature	Detail
Product Dimensions	17.7 x 15.7 x 14.9 inches
Item Weight	11.3 Pounds
Item Model Number	AMP005146
Manufacturer	ACEVIVI
Power Source	Corded Electric
Target Use Body Part	Feet
Special Features	Heat, Bubbles, Motorized Massage, Red Light, Pedicure Stone
Temperature Range	95-118°F (35-48°C)
Material Type	Stone (for pedicure stone)
Color	Gray

9. WARRANTY & SUPPORT

For warranty information or technical support, please contact ACEVIVI customer service through the retailer where the product was purchased or visit the official ACEVIVI website.

Keep your purchase receipt and product model number (AMP005146) handy for faster service.

ASK A QUESTION ABOUT THIS MANUAL

Ask about setup, troubleshooting, compatibility, parts, safety, or missing instructions. Manuals+ will review the question and use this page’s manual context to help answer it.

Name

Anonymous

Email

you@example.com

After a successful submission, we securely hash the supplied account or form email before sending it to Microsoft Advertising for conversion attribution. [Privacy details](#).

Question

Example: How do I reset this device or fix this error?

Details

Model number, symptoms, what you tried, or the section of the manual you are using.

Submit question

Open the live page

<https://manuals.plus/asin/B08C9TJ8Y4>

More documents and user manuals: <https://manuals.plus/>