

[Manuals.plus](#) /

› [Thopeb](#) /

› Thopeb Personal Safety Alarm Model 185 User Manual

Thopeb 185

Thopeb Personal Safety Alarm Model 185 User Manual

Your guide to personal safety and peace of mind.

For optimal use, please read this manual thoroughly.

1. INTRODUCTION

The Thopeb Personal Safety Alarm Model 185 is a compact and powerful device designed to enhance personal safety. Featuring a loud 130dB siren and a bright LED strobe light, it aims to deter potential threats and attract attention in emergency situations. Its versatile design allows for easy attachment to various personal items, making it suitable for individuals of all ages.

2. IMPORTANT SAFETY INFORMATION

- **Loud Noise Warning:** The alarm emits a very loud sound (130dB). Avoid prolonged exposure to prevent hearing damage. Do not activate near ears.
- **Strobe Light Warning:** The LED light is very bright. Avoid direct eye exposure.
- **Children:** Keep out of reach of small children to prevent accidental activation or misuse.
- **Water Resistance:** The device has an IP54 rating, offering protection against splashes. It is not designed for submersion in water.
- **Battery Safety:** Use only specified CR2032 batteries. Do not attempt to open or modify the battery compartment beyond replacement.

3. PACKAGE CONTENTS

Ensure all items are present:

- Thopeb Personal Safety Alarm (Model 185)
- Carabiner Hook
- Detachable Wrist Strap
- User Manual (this document)
- 2 x CR2032 Batteries (pre-installed)

4. SETUP AND ATTACHMENT

The Thopeb Personal Safety Alarm comes with pre-installed batteries and is ready for immediate use. Follow these steps to attach it:

1. **Choose Attachment Method:** The alarm can be attached to keys, backpacks, belts, or purses using the included carabiner hook or detachable wrist strap.
2. **Secure Attachment:** Use the carabiner hook to clip the alarm securely to a desired item. Ensure it is firmly attached to prevent accidental detachment.
3. **Accessibility:** Position the alarm in a location that allows for quick and easy access in an emergency.

How To Use? Pull And Alarm!

1. Unplugging the latch immediately sounds an alarm.
2. The LED light is on.



1. The latch plugs back into the alarm to stop.
2. The LED lights are also turned off.



Image: Thopeb Personal Safety Alarm attached to a keychain, demonstrating its portability and ease of attachment.

5. OPERATING INSTRUCTIONS

5.1 Activating the Alarm

To activate the personal safety alarm:

1. **Pull the Pin:** Firmly pull the top pin (latch) away from the main body of the alarm.
2. **Siren and Light:** The 130dB siren will immediately sound, and the LED strobe light will activate simultaneously.



Image: A visual guide illustrating the action of pulling the pin to activate the alarm and the resulting loud sound and bright light.

5.2 Deactivating the Alarm

To stop the alarm and turn off the light:

- **Reinsert the Pin:** Push the pulled pin back into the main body of the alarm until it clicks into place. The siren will cease, and the light will turn off.



Image: A visual guide demonstrating how to reinsert the pin to deactivate the alarm, stopping the siren and turning off the light.

5.3 Using the LED Light Independently

The LED light can also be used as a small flashlight:

- **Press Button:** Press the small button on the front of the alarm to turn the LED light on.
- **Press Again:** Press the button again to turn the LED light off.



Image: The Thopeb Personal Safety Alarm with its LED light illuminated, demonstrating its function as a standalone flashlight.

5.4 Applications

The Thopeb Personal Safety Alarm is suitable for various situations:

- **Personal Protection:** Ideal for women, children, and the elderly to deter attackers or signal for help.
- **Outdoor Activities:** Useful for runners, hikers, or anyone walking alone at night.
- **Emergency Signaling:** Can be used to alert others in case of falls, medical emergencies, or getting lost.



Image: A collage depicting various scenarios where the Thopeb Personal Safety Alarm can be used, including for personal protection, during outdoor activities, and for children.

5.5 Product Videos

Your browser does not support the video tag.

Video: Official Thopeb video demonstrating the Original Self Defense Siren. This video shows the product's features and how it functions.

6. MAINTENANCE

6.1 Battery Replacement

The Thopeb Personal Safety Alarm uses 2 CR2032 batteries. Batteries are pre-installed and have a lifespan of approximately 18 months with typical use (3 emergency activations per week over 1 year). Replace batteries when the alarm sound weakens or the LED light dims.

1. **Locate Battery Compartment:** The battery compartment is typically on the back or side of the device, secured by small screws.
2. **Open Compartment:** Use a small screwdriver to carefully open the battery compartment.
3. **Replace Batteries:** Remove old batteries and insert two new CR2032 batteries, ensuring correct polarity (+/-).
4. **Close Compartment:** Securely close the battery compartment.

6.2 Cleaning

- Wipe the device with a soft, dry cloth. Do not use abrasive cleaners or immerse in water.

7. TROUBLESHOOTING

Problem	Possible Cause	Solution
Alarm does not sound / Light does not activate.	Dead or low batteries. Pin not fully pulled.	Replace batteries. Ensure pin is fully removed from the device.
Alarm sounds weak / Light is dim.	Low batteries.	Replace batteries.
Alarm activates accidentally.	Pin not securely inserted. Device snagged.	Ensure pin is fully inserted. Avoid placing the device where the pin can be easily dislodged.

8. SPECIFICATIONS

- **Model:** 185
- **Brand:** Thopeb
- **Noise Level:** 130 Decibels
- **Control Method:** Touch (for LED light), Pull-pin (for alarm)
- **Dimensions:** 3.2 x 1.25 x 0.59 inches (81.3 x 31.8 x 15 mm)
- **Item Weight:** 1.44 ounces (40.8 grams)
- **Batteries:** 2 CR2032 batteries (included)
- **Battery Life:** Approximately 18 months (tested by Intertek)
- **Water Resistance:** IP54-rated (splash resistant)
- **Special Features:** Lightweight, LED Light

9. WARRANTY AND SUPPORT

Warranty: The Thopeb Personal Safety Alarm Model 185 is backed by an industry-leading 3-year full replacement warranty. This covers manufacturing defects and ensures a hassle-free replacement process.

Customer Support: For any questions, troubleshooting assistance, or warranty claims, please contact our 24/7 US-based technical support. Average response time is 2.3 minutes via email or chat.

For more information, visit the [Thopeb Store on Amazon](#).

ASK A QUESTION ABOUT THIS MANUAL

Ask about setup, troubleshooting, compatibility, parts, safety, or missing instructions. Manuals+ will review the question and use this page's manual context to help answer it.

Name

Anonymous

Email

you@example.com

After a successful submission, we securely hash the supplied account or form email before sending it to Microsoft Advertising for conversion attribution. [Privacy details](#).

Question

Example: How do I reset this device or fix this error?

Details

Model number, symptoms, what you tried, or the section of the manual you are using.

Submit question

Open the live page

<https://manuals.plus/asin/B08CCCB58N>

More documents and user manuals: <https://manuals.plus/>