

Manuals+

[Q & A](#) | [Deep Search](#) | [Upload](#)

[manuals.plus](#) /

› [Edifier](#) /

› [Edifier TWS NB2 True Wireless Active Noise Canceling Earbuds User Manual](#)

Edifier TWS NB2

Edifier TWS NB2 True Wireless Active Noise Canceling Earbuds

Model: TWS NB2 | Brand: Edifier

INTRODUCTION

The Edifier TWS NB2 True Wireless Active Noise Canceling Earbuds are designed to provide a superior audio experience with advanced noise cancellation technology. These earbuds offer hybrid ANC for effective noise reduction, ensuring clear audio in various environments. Key features include crystal-clear calls with dual microphones, infrared wearing detection for automatic playback control, and convenient one-touch pairing. The ambient sound pass-through mode allows users to stay aware of their surroundings without removing the earbuds. With an extended playback time, the TWS NB2 is ideal for daily use, commuting, and workouts.

WHAT'S IN THE Box

Upon opening the package, you will find the following components:

- Edifier TWS NB2 Earbuds
- Charging Case
- USB Type-C Charging Cable
- Spare Eartips (S/M/L sizes)
- User Manual

Your browser does not support the video tag.

Video: Unboxing the Edifier TWS NB2 Earbuds. This video demonstrates the contents of the product packaging, including the earbuds, charging case, charging cable, and various eartip sizes.

PRODUCT OVERVIEW

The Edifier TWS NB2 earbuds are designed for comfort and high-quality audio performance. Below are some key features and components:



Image: The Edifier TWS NB2 earbuds resting in their open charging case, showcasing their sleek design and compact form factor.

Hi-Res
AUDIO
WIRELESS

Immersive Sound Effect
HiFi Enjoyment



Image: Visual representation highlighting the Hi-Res Audio Wireless capability, promising an immersive sound effect and HiFi

enjoyment.

Tri-MIC Phone Call

Freely Talking Against the Wind





Image: An individual using the earbuds, illustrating the Tri-MIC phone call feature designed for clear communication even in windy conditions.



Image: A user wearing the earbuds in an outdoor setting, demonstrating the Environment Monitoring Mode which allows hearing surroundings for safety.




Image: The charging case with water droplets, indicating the IP54 dust and water resistance, making the earbuds suitable for outdoor activities.



Image: A person wearing the earbuds in a cafe, highlighting the Ultra Quietness achieved through Hybrid Noise-cancellation technology.



Extended Playback Time

The TWS NB2 features a 7-hour playback time with the active noise canceling feature on and an additional 18-hour playback time with the feature off to ensure all day use.

Image: The earbuds in their case with a speed gauge background, illustrating the extended playback time of up to 32 hours.

Your browser does not support the video tag.

Video: Edifier TWS NB2 Active Noise Cancelling Lifestyle Video. This video showcases the earbuds' active noise cancellation and ambient sound features in various daily scenarios.

SETUP

1. Charging the Earbuds and Case

Before first use, fully charge the earbuds and the charging case. Place the earbuds into the charging case. Connect the USB Type-C charging cable to the charging port on the case and a power source. The indicator lights on the case will show the charging status. A full charge typically takes approximately 1.5 hours for the earbuds and 2 hours for the case.

2. Bluetooth Pairing

To pair your Edifier TWS NB2 earbuds with a device:

1. Ensure the earbuds are in the charging case and the case lid is open.
2. On your device (smartphone, tablet, etc.), enable Bluetooth.
3. The earbuds will automatically enter pairing mode. Look for 'TWS NB2' in your device's Bluetooth settings.
4. Select 'TWS NB2' to connect. Once connected, a voice prompt will confirm successful pairing.

Your browser does not support the video tag.

Video: Bluetooth Connection Guide for Edifier TWS NB2. This video illustrates the steps to connect your earbuds to a mobile device via Bluetooth.

OPERATING INSTRUCTIONS

The Edifier TWS NB2 earbuds feature intuitive touch controls. Here's how to operate them:

Function	Action	Earbud
Play/Pause	Double-tap	Left or Right
Next Track	Triple-tap	Right
Previous Track	Triple-tap	Left
Volume Up	Press and hold (Right)	Right
Volume Down	Press and hold (Left)	Left
Answer/End Call	Double-tap	Left or Right
Reject Call	Press and hold for 2 seconds	Left or Right
Activate Voice Assistant	Quadruple-tap	Left or Right
Toggle ANC/Ambient Sound	Double-tap (Left)	Left

Infrared Wearing Detection: The music will automatically pause playback when the earbuds are removed from your ears and resume when you put them back on.

MAINTENANCE

To ensure the longevity and optimal performance of your Edifier TWS NB2 earbuds, follow these maintenance guidelines:

- **Cleaning:** Regularly clean the earbuds and charging case with a soft, dry cloth. Avoid using abrasive materials or harsh chemicals.
- **Storage:** When not in use, store the earbuds in their charging case to protect them from dust and damage.
- **Water Resistance:** The earbuds are IP54 rated for dust and water resistance. This means they are protected against limited dust ingress and water spray from any direction. Do not submerge them in water or expose them to heavy rain. Dry them thoroughly if they get wet.
- **Charging:** Use only the provided USB Type-C cable for charging. Avoid extreme temperatures during charging and storage.
- **Avoid Impact:** Do not drop or subject the earbuds to strong impacts, as this can damage internal components.

TROUBLESHOOTING

If you encounter issues with your Edifier TWS NB2 earbuds, refer to the following common solutions:

- **Earbuds not pairing:** Ensure both earbuds are charged and in the case with the lid open. Turn off and on your device's Bluetooth. If issues persist, try resetting the earbuds (refer to the full user manual for specific reset instructions).
- **No sound from one earbud:** Place both earbuds back into the charging case, close the lid, wait a few seconds, then open it again. This often re-syncs them.
- **Charging issues:** Check the charging cable and adapter. Ensure the charging contacts on the earbuds and inside the case are clean and free of debris.
- **Poor sound quality:** Ensure the eartips provide a good seal in your ear. Try different sized eartips. Check for any obstructions in the earbud nozzles.
- **Intermittent connection:** Keep your device within the Bluetooth range (up to 10 meters). Avoid strong electromagnetic interference.

For more detailed troubleshooting or persistent issues, please contact Edifier customer support.

SPECIFICATIONS

Specification	Detail
Model Name	TWS NB2
Noise Control	Active Noise Cancellation
Connectivity Technology	Wireless (Bluetooth 5.0)
Battery Life	32 Hours (Total with charging case)
Control Type	Touch Control
Water Resistance Level	IP54 Water Resistant
Item Weight	1.9 Ounces
Color	White
Material	Plastic
Bluetooth Range	10 Meters
Manufacturer	EDIFIER

WARRANTY AND SUPPORT

Edifier products typically come with a limited warranty covering manufacturing defects. For specific warranty terms and conditions, please refer to the warranty card included in your product packaging or visit the official Edifier website. If you require technical assistance, have questions about your product, or need to claim warranty service, please contact Edifier customer support through their official channels. You can usually find contact information on the Edifier website or in your product's user manual.