

Manuals+

[Q & A](#) | [Deep Search](#) | [Upload](#)

manuals.plus /

- › [Marley](#) /
- › [House of Marley Champion True Wireless Earbuds \(Model EM-JE131\) Instruction Manual](#)

Marley EM-JE131

House of Marley Champion True Wireless Earbuds (Model EM-JE131) Instruction Manual

Your guide to setting up, operating, and maintaining your Champion earbuds.

1. PRODUCT OVERVIEW

The House of Marley Champion True Wireless Earbuds deliver superior audio clarity and an exceptional seal for noise isolation. Designed for comfort and durability, these earbuds feature a water-resistant design and are crafted from sustainable materials like bamboo and REGRIND silicone. Enjoy extended listening with up to 28 hours of total battery life with the charging case and convenient quick-charge technology.



Image 1.1: House of Marley Champion True Wireless Earbuds in Signature Black.

2. WHAT'S IN THE BOX

Your House of Marley Champion Earbuds package includes the following items:

- Champion Earbuds (Left and Right)
- Charging Case
- USB-C Charging Cable
- Ear Tips (various sizes for optimal fit)
- Quick Start Guide
- Warranty Booklet
- Welcome Card
- Sticker



Image 2.1: The Champion Earbuds and their compact charging case, along with the USB-C charging cable.

3. SETUP AND FIRST USE

3.1. Charging the Earbuds and Case

Before first use, ensure both the earbuds and the charging case are fully charged. The charging case provides additional power for your earbuds on the go.

1. Place the earbuds into their respective slots in the charging case. Ensure they are seated correctly.
2. Connect the provided USB-C charging cable to the charging port on the case and the other end to a USB power source (e.g., wall adapter, computer USB port).
3. The LED indicators on the charging case will illuminate to show the charging status. A full charge provides up to 8 hours of playback for the earbuds, with the case extending total battery life to 28 hours.
4. Quick charge feature: A 15-minute charge can provide up to 2 hours of playback.



**8 HOUR BATTERY LIFE,
28 HOURS WITH CASE**

Image 3.1: Earbuds inside the charging case, indicating charging status and extended battery life.

3.2. Pairing with a Bluetooth Device

The Champion earbuds use Bluetooth 5.0 for a stable wireless connection up to 10 meters (33 feet).

1. Open the charging case. The earbuds will automatically enter pairing mode.
2. On your device (smartphone, tablet, computer), go to Bluetooth settings.
3. Select "Champion" from the list of available devices.
4. Once connected, you will hear an audio prompt, and the earbuds will be ready for use.
5. The earbuds are compatible with both iOS and Android devices.

4. OPERATING THE EARBUDS

The Champion earbuds feature intuitive touch controls for managing your audio and calls.

**SWEAT AND WATER
RESISTANT
IPX4 RATING**

MICROPHONE



**8 HOUR
BATTERY LIFE
28 HOUR TOTAL
BATTERY LIFE
WITH CASE**

**CRAFTED FROM
SUSTAINABLE
MATERIALS**



**REGRIND™ SILICONE
NATURAL FIBER COMPOSITE
BAMBOO**

Image 4.1: Earbud features including microphone and touch control area.

4.1. Touch Controls

- **Play/Pause:** Single tap on either earbud.
- **Next Track:** Double tap on the right earbud.
- **Previous Track:** Double tap on the left earbud.
- **Answer/End Call:** Single tap on either earbud during an incoming call or active call.
- **Reject Call:** Press and hold either earbud for 2 seconds during an incoming call.
- **Activate Voice Assistant (Siri/Google Assistant):** Triple tap on either earbud.

Volume control is managed directly from your connected device.

4.2. Making Calls

The earbuds feature a high-performance onboard microphone for clear hands-free calling and stereo voice communications.

- Ensure earbuds are connected to your device.
- Use the touch controls as described above to manage calls.

5. MAINTENANCE AND CARE

To ensure the longevity and optimal performance of your Champion earbuds, follow these care guidelines:

- **Cleaning:** Gently wipe the earbuds and charging case with a soft, dry cloth. Avoid using harsh chemicals or abrasive materials.
- **Ear Tips:** Regularly remove and clean the silicone ear tips with mild soap and water. Ensure they are completely dry before reattaching.
- **Water Resistance:** The earbuds are water-resistant (IPX4 rated), meaning they can withstand splashes and sweat. They are not designed for submersion in water. Do not expose them to heavy rain or immerse them.
- **Storage:** When not in use, store the earbuds in their charging case to protect them and keep them charged. Store in a cool, dry place away from extreme temperatures.
- **Charging Port:** Keep the USB-C charging port free of dust and debris.

6. TROUBLESHOOTING

If you encounter issues with your Champion earbuds, try the following solutions:

- **No Sound/Poor Sound Quality:**
 - Ensure earbuds are fully charged.
 - Check Bluetooth connection to your device. Try re-pairing.
 - Adjust volume on both your device and the earbuds (if applicable).
 - Clean ear tips and earbud grilles.
 - Ensure ear tips provide a good seal in your ear.
- **Earbuds Not Pairing:**
 - Ensure earbuds are in pairing mode (open case).
 - Turn off and on Bluetooth on your device.
 - Forget "Champion" from your device's Bluetooth list and try pairing again.
 - Ensure earbuds and case are charged.
- **Charging Issues:**
 - Verify the USB-C cable is securely connected to both the case and the power source.
 - Try a different USB-C cable or power adapter.
 - Ensure the charging contacts on the earbuds and inside the case are clean.
- **One Earbud Not Working:**
 - Place both earbuds back in the case, close it, wait a few seconds, then open it again.
 - Ensure both earbuds are charged.
 - Try re-pairing the earbuds with your device.

For further assistance, refer to the Warranty Booklet or contact customer support.

7. TECHNICAL SPECIFICATIONS

Model Name	Champion
Model Number	EM-JE131

Connectivity Technology	Wireless (Bluetooth 5.0)
Bluetooth Range	10 Meters (33 feet)
Battery Life (Earbuds)	Up to 8 Hours
Total Battery Life (with Case)	Up to 28 Hours
Quick Charge	15 minutes charge for 2 hours playback
Water Resistance Level	IPX4 (Water Resistant)
Noise Control	Sound Isolation
Control Type	Built-in Touch Control
Material	Bamboo, Natural Wood Fiber Composite, REGRIND Silicone
Item Weight	4.2 ounces (earbuds and case)
Dimensions	17.99 x 9.65 x 7.36 inches (packaging)

8. OFFICIAL PRODUCT VIDEOS

8.1. House of Marley True Wireless Champion Earbuds Overview

Your browser does not support the video tag.

Video 8.1: An official overview video showcasing the features and design of the House of Marley Champion True Wireless Earbuds.

9. WARRANTY AND SUPPORT

For detailed warranty information, please refer to the included Warranty Booklet. If you require technical support or have questions about your product, please visit the official House of Marley store or contact their customer service. Official Brand Store: [House of Marley Store](#)