

Manuals+

[Q & A](#) | [Deep Search](#) | [Upload](#)

manuals.plus /

- › [NAVIFORCE](#) /
- › [NAVIFORCE NF9182 Military Sports Watch Instruction Manual](#)

NAVIFORCE NF9182

NAVIFORCE NF9182 Military Sports Watch Instruction Manual

Model: NF9182

INTRODUCTION

Thank you for purchasing the NAVIFORCE NF9182 Military Sports Watch. This manual provides detailed instructions for setting up, operating, maintaining, and troubleshooting your watch. Please read this manual carefully to ensure proper use and to maximize the lifespan of your timepiece.



Image: The NAVIFORCE NF9182 Military Sports Watch, featuring a blue stainless steel band and case, with both analog and digital displays.

SETUP

Initial Inspection

Upon unboxing, inspect the watch for any visible damage. Ensure all protective films are removed from the watch face and strap.

Strap Adjustment

The stainless steel strap can be adjusted to fit your wrist. If the strap is too long, links can be removed by a professional watchmaker or using a watch link removal tool. Ensure the clasp closes securely after adjustment.



Image: A NAVIFORCE watch worn on a wrist, indicating a wrist size of 18cm, demonstrating how the watch fits.

OPERATING INSTRUCTIONS

The NAVIFORCE NF9182 features both analog and digital displays, offering multiple functions.

FUNCTION DESCRIPTION



Image: A diagram illustrating the various functions and buttons of the NAVIFORCE watch, including Light, Mode, Start, Reset, and Time Adjustment.

Setting the Date

1. Pull the crown out to the first click position.
2. Rotate the crown to set the desired date.
3. **Important:** Do not set the date between 9 PM and 1 AM to avoid damaging the movement.
4. Push the crown back to the normal position.
5. **Hint:** If the date changes during the day, it indicates the AM/PM was incorrectly set. Advance the hour hand by 12 hours to correct this.

Setting Analog Time

Pull the crown out to the second click position. Rotate the crown to set the hour and minute hands. Push the crown back to the normal position when finished.

Digital Display Functions

The digital display offers 12-digit timing, showing time (hour, minute, second), day, month, and week. It also includes an alarm, SIG (hourly chime) function, snooze, and a 1/100 second precision stopwatch.

- **Mode Button:** Press to cycle through different digital display modes (Time, Date, Alarm, Stopwatch).
- **Start Button:** Used to start/stop the stopwatch or adjust settings in various modes.
- **Reset Button:** Used to reset the stopwatch or confirm settings.

LED Backlight

Press the 'LIGHT' button to illuminate the digital display for visibility in low-light conditions. The watch also features a luminous function for the analog hands and markers.

LUMINOUS FUNCTION



Conventional mode



Luminescent mode

Image: A comparison showing the watch in conventional mode (left) and luminescent mode (right), highlighting the glow-in-the-dark features for improved visibility.

MAINTENANCE

Water Resistance (3ATM)

Your NAVIFORCE NF9182 watch is rated for 3ATM water resistance. This means it is suitable for daily use and can withstand splashes, rain, and hand washing. However, it is **not** suitable for showering, bathing, diving, snorkeling, or any water-related work where it would be submerged or exposed to high-pressure water.

3ATM WATERPROOF



Image: The NAVIFORCE watch with water splashing around it, visually representing its 3ATM water resistance for everyday splashes.

Cleaning

Wipe the watch case and strap regularly with a soft, dry cloth to remove dirt and sweat. For the stainless steel strap, a slightly damp cloth can be used, followed by immediate drying.

Battery Replacement

The watch uses an SR920SW battery. When the watch stops or the digital display fades, it's time to replace the battery. It is recommended to have battery replacement performed by a qualified watch technician to ensure proper sealing and maintain water resistance.

Storage

When not in use, store your watch in a cool, dry place away from direct sunlight and extreme temperatures. Avoid exposing the watch to strong magnetic fields.

TROUBLESHOOTING

- **Watch not running:** Check if the crown is pushed in completely. If the watch still does not run, the battery may need replacement.
- **Incorrect time/date:** Refer to the 'Operating Instructions' section for proper setting procedures. Ensure the

date is not set between 9 PM and 1 AM.

- **Digital display not working:** This could indicate a low battery. If the analog movement is still working, the digital display may require less power and fail first. Replace the battery.
- **Condensation inside the watch:** This indicates a loss of water resistance. Avoid further contact with water and have the watch inspected by a professional immediately.

SPECIFICATIONS

Model Number	NF9182
Movement	Japanese Quartz Movement
Display Type	Analog & Digital Dual Display
Water Resistance	3ATM (30 meters / 98 feet) - Splash resistant, not for swimming or diving.
Crystal Material	High Hardness Mineral Glass
Case Material	Stainless Steel
Band Material	Stainless Steel
Battery Type	SR920SW (1 Lithium-ion battery included)
Functions	Time (Analog & Digital), Date, Day, Month, Week, Chronograph, Alarm, Snooze, SIG (Hourly Chime), LED Backlight
Weight	Approx. 300g

WARRANTY AND SUPPORT

For warranty information or technical support, please refer to the documentation provided with your purchase or contact NAVIFORCE customer service through their official website or authorized retailers. Keep your purchase receipt as proof of purchase for any warranty claims.