

Vitamix E310

Vitamix E310 Explorian Blender with Personal Cup Adapter

Professional-Grade Blending for Every Need

PRODUCT OVERVIEW

The Vitamix E310 Explorian Blender is a professional-grade appliance designed for versatile blending. This model includes a 48 oz. container and a Personal Cup Adapter with two 20 oz. travel cups, offering convenience for both family meals and individual servings. Its robust design and intuitive controls make it an essential tool for any kitchen.



Figure 1: Vitamix E310 Explorian Blender with main container and Personal Cup Adapter components.

SETUP AND ASSEMBLY

Before first use, ensure all components are clean. Place the blender base on a stable, flat surface. The 48 oz. container or the Personal Cup Adapter can be securely placed on the motor base.

Assembling the Personal Cup Adapter

1. Fill one of the 20 oz. blending cups with your desired ingredients.
2. Screw the Personal Cup Adapter onto the filled 20 oz. cup. Ensure it is tightly secured to prevent leaks.
3. Place the assembled cup and adapter onto the Vitamix motor base.
4. Once blending is complete, unscrew the adapter from the cup and attach the travel lid for on-the-go convenience.



Figure 2: The Personal Cup Adapter securely attached to the Vitamix E310 motor base.

OPERATING INSTRUCTIONS

The Vitamix E310 offers precise control over your blending process with its intuitive interface.

Controls

- **Variable Speed Control:** Use the central dial to adjust blending speed from 1 to 10. This allows you to refine textures from smooth purées to chunky salsas.
- **Pulse Feature:** The left toggle switch activates the pulse function, providing quick bursts of power for chopping ingredients or creating desired textures.
- **On/Off Switch:** The right toggle switch powers the unit on or off.

Pulse Feature

Makes chunky salsas, thick vegetable soups, and more.

Variable Speed Control

Creates a variety of textures with complete control.



Figure 3: Detailed view of the Vitamix E310's control panel.

Recommended Uses

- **Smoothies & Juices:** Achieve perfectly smooth blends with fruits and vegetables.
- **Hot Soups:** The powerful blades can generate friction heat, bringing cold ingredients to steaming hot in about six minutes.
- **Frozen Desserts:** Create creamy frozen treats in seconds.
- **Batters & Dough:** Mix pancake batter, waffle batter, or even knead dough.
- **Nut Butters & Non-Dairy Milks:** Easily make homemade nut butters and plant-based milks.
- **Chopping & Grinding:** Use the pulse feature for coarse chopping or grind whole grains into flour.

MAINTENANCE AND CLEANING

Maintaining your Vitamix blender is simple, ensuring longevity and hygiene.

Self-Cleaning Function

For quick and easy cleaning, simply add warm water and a drop of dish soap to the container. Secure the lid and run the machine on its highest speed for 30 to 60 seconds. The powerful action will clean the container without disassembly.

Dishwasher Safe Parts

The 20 oz. blending containers and their lids are dishwasher-safe for convenient cleaning.

TROUBLESHOOTING

While Vitamix blenders are built for durability, occasional issues may arise. Here are some common observations:

- **Leaking from Personal Cup Adapter:** Ensure the thin rubber gasket around the base of the personal cup adapter is properly seated and not shifted. Tighten the adapter securely onto the cup.
- **Water Under Main Blender Base:** If water accumulates under the main blender base after washing, it may indicate an issue with the seal. Avoid submerging the base in water. Refer to the official user manual for detailed cleaning instructions and contact customer support if the issue persists.

SPECIFICATIONS

Feature	Detail
Brand	Vitamix
Model	E310 Explorian
Color	Black
Special Feature	Variable Speed Control
Capacity	48 oz. Container, Two 20 oz. Blending Cups
Included Components	Two 20 oz. Blending Cups
Power Source	Corded Electric
Number of Speeds	10
Voltage	120 Volts
Blade Material	Stainless Steel
Item Weight	2.2 pounds

WARRANTY AND SUPPORT

The Vitamix E310 Explorian Blender comes with a limited warranty. For detailed warranty information, product support, or to download the full user manual, please refer to the official documentation.

- **User Manual (PDF):** [Download User Manual](#)
- **User Guide (PDF):** [Download User Guide](#)
- **Vitamix Store:** [Visit Official Vitamix Store](#)

ASK A QUESTION ABOUT THIS MANUAL

Ask about setup, troubleshooting, compatibility, parts, safety, or missing instructions. Manuals+ will review the question and use this page's manual context to help answer it.

Name

Anonymous

Email

you@example.com

After a successful submission, we securely hash the supplied account or form email before sending it to Microsoft Advertising for conversion attribution. [Privacy details](#).

Question

Example: How do I reset this device or fix this error?

Details

Model number, symptoms, what you tried, or the section of the manual you are using.

Submit question