

Prestige GTMC 04 L

Prestige Magic GTMC 04 L 4 Burner Gas Stove Instruction Manual

Model: GTMC 04 L

1. INTRODUCTION

This manual provides essential information for the safe and efficient operation, installation, and maintenance of your Prestige Magic GTMC 04 L 4 Burner Gas Stove. Please read all instructions carefully before using the appliance and retain this manual for future reference.

2. SAFETY INSTRUCTIONS

WARNING: Failure to follow these instructions may result in fire, explosion, electric shock, or other hazards, causing property damage, personal injury, or death.

- Ensure proper ventilation in the kitchen area during use.
- Do not store flammable materials near the gas stove.
- Keep children and pets away from the appliance during operation.
- Always use appropriate cookware for the burner size.
- Do not leave cooking unattended.
- In case of a gas leak, immediately turn off the gas supply, open windows, and do not operate any electrical switches or appliances. Contact a qualified technician.
- Ensure the gas stove is installed by a qualified technician according to local regulations.
- Do not modify the appliance.

3. PRODUCT COMPONENTS

Your Prestige Magic GTMC 04 L Gas Stove includes the following main components:

- **Toughened Glass Top:** A durable 6mm black glass surface.
- **Brass Burners:** Four high-efficiency tri-pin brass burners.
- **Pan Supports:** Sturdy supports for cookware.
- **Ergonomic Knobs:** Control knobs for flame adjustment.

- **Gas Inlet Nozzle:** For connecting to the gas supply.



Figure 3.1: Overview of the Prestige Magic GTMC 04 L Gas Stove.



**GLASS TOP
GAS STOVE**

Magic

**MAGIC LP GAS STOVE
GTMC - 04**

**BRING HOME INDIA'S FAVOURITE
GAS STOVE**



Figure 3.2: Detail of spill-proof design and brass burners.



Magic



- Spill-proof Design
- Ergonomic Knob Design
- Toughened Black Glass-top
- Tri-pin brass burners
- ISI Certified



MODEL ► GTMC 04



A  Product.

Figure 3.3: Key features including ergonomic knobs and toughened glass top.

4. SETUP AND INSTALLATION

Proper installation is crucial for safety and performance. It is recommended that installation be performed by a certified gas technician.

4.1 Unpacking

- Carefully remove the gas stove from its packaging.
- Check for any damage during transit. Do not use if damaged.
- Ensure all components listed in Section 3 are present.
- Retain packaging for potential future transport or service.



Figure 4.1: Product packaging.

4.2 Placement

- Place the gas stove on a stable, level, and heat-resistant surface.
- Ensure adequate clearance from walls and overhead cabinets as per local safety standards.
- The area should be well-ventilated.

4.3 Gas Connection

- Connect the gas stove to a suitable LPG cylinder or piped natural gas supply using an ISI-certified rubber hose and regulator.
- Ensure all connections are tight and leak-free. Use soapy water to check for leaks (bubbles indicate a leak).
- Do not use an open flame to check for leaks.

5. OPERATING INSTRUCTIONS

5.1 Lighting a Burner

1. Ensure the gas supply is open.
2. Push and turn the desired burner knob counter-clockwise to the "Ignite" position.
3. Simultaneously, use a gas lighter to ignite the burner.
4. Once the flame is lit, release the knob.
5. Adjust the flame intensity by turning the knob between "Sim" (Simmer) and "Off" positions.

5.2 Turning Off a Burner

- Turn the burner knob clockwise to the "Off" position.
- Ensure the flame is extinguished.
- For prolonged periods of non-use, turn off the main gas supply.

6. CLEANING AND MAINTENANCE

Regular cleaning and maintenance will ensure the longevity and efficient performance of your gas stove.

6.1 Daily Cleaning

- Allow the stove to cool completely before cleaning.
- Wipe the toughened glass top with a soft cloth and mild detergent. Avoid abrasive cleaners.
- Clean up spills immediately to prevent staining.

6.2 Burner Maintenance

- Periodically remove the brass burners and pan supports.
- Clean them with warm soapy water and a soft brush to remove food residue.
- Ensure burners are completely dry before placing them back on the stove. Blocked burner holes can affect flame quality.

6.3 General Care

- Do not use harsh chemicals or sharp objects on the glass top.
- Regularly check the gas hose for cracks or damage. Replace if necessary.

7. TROUBLESHOOTING

Refer to the following table for common issues and their solutions.

Problem	Possible Cause	Solution
Burner does not light.	Gas supply off, clogged burner holes, faulty lighter.	Check gas supply. Clean burner holes. Use a working lighter.
Irregular or yellow flame.	Clogged burner holes, improper burner placement.	Clean burner holes. Ensure burners are correctly seated.
Gas smell.	Gas leak from hose or connections.	Immediately turn off gas supply, ventilate area, and contact a qualified technician.

If the problem persists after attempting these solutions, contact Prestige customer service.

8. SPECIFICATIONS

Feature	Detail
Model Number	GTMC 04 L
Brand	Prestige
Colour	Black
Material	Glass
Heating Elements	4 Burners
Burner Type	Manual, Tri-pin Brass Burners
Glass Top Thickness	6mm Toughened Glass
Controls Type	Knob
Product Dimensions (D x W x H)	83D x 53W x 17H Centimeters
Item Weight	11.51 Kilograms
Power Source	Gas Powered
Special Features	Easy to clean and maintain, Ergonomic knob design, ISI Certified, Spill-proof design.

9. WARRANTY AND SUPPORT

Your Prestige Magic GTMC 04 L Gas Stove comes with a standard brand warranty. Please refer to the warranty card included in the packaging for specific terms and conditions.

For service or support, please contact Prestige customer care. Contact details can typically be found on the warranty card or the official Prestige website.

Included in the box: 1 Gas Stove, User Manual, Warranty Card.

10. PRODUCT VIDEOS

10.1 Prestige Magic Glass Top Gas Stove Overview

Your browser does not support the video tag.

This video provides a general overview of the Prestige Magic Glass Top Gas Stove series, highlighting key features such as spill-proof design, jumbo burners, ergonomic knobs, tri-pin brass burners, and toughened glass. It showcases various burner configurations available in the series.

10.2 Prestige Magic 4 Burner Gas Stove Features

Your browser does not support the video tag.

This video focuses specifically on the Prestige Magic 4 Burner Gas Stove, detailing its features including the 6mm superior toughened glass top, brass burners, tri-pin burner for high efficiency, and ergonomic knob design. It also mentions product dimensions and warranty information.

