

## Manuals+

[Q & A](#) | [Deep Search](#) | [Upload](#)

[manuals.plus](#) /

› [Prestige](#) /

› [Prestige Iris Plus 750 Watt Mixer Grinder User Manual](#)

## Prestige IRIS PLUS MIXER GRINDER

# Prestige Iris Plus 750 Watt Mixer Grinder User Manual

Model: IRIS PLUS MIXER GRINDER

## 1. INTRODUCTION

---

The Prestige Iris Plus 750 Watt Mixer Grinder is designed for efficient and versatile kitchen tasks. This manual provides essential information for safe operation, maintenance, and troubleshooting to ensure optimal performance and longevity of your appliance. Please read this manual thoroughly before first use and keep it for future reference.

## 2. WHAT'S IN THE BOX

---

Upon unpacking, you should find the following components:

- 1 unit of Prestige Iris Plus 750 Watt Mixer Grinder motor unit.
- 1.5L Wet Grinding Jar with blade and lid.
- 1L Dry Grinding Jar with blade and lid.
- 300ml Chutney Jar with blade and lid.
- 1.5L Juicer Jar with sieve and lid.
- Spatula.
- User Manual.

# Sturdy Wide-mouth Steel Jars

3 Stainless Steel Jars & 1 Juicer Jar



Image: The Prestige Iris Plus Mixer Grinder motor unit with its three stainless steel jars and one juicer jar.

## 3. SETUP

- 1. Unpacking:** Carefully remove all components from the packaging. Retain packaging for future storage or transport.
- 2. Placement:** Place the mixer grinder on a stable, flat, and dry surface, away from heat sources and water. Ensure adequate ventilation around the motor unit.
- 3. Power Connection:** Verify that the voltage indicated on the appliance matches your local power supply (220 Volts). Plug the power cord into a grounded electrical outlet.
- 4. Jar Assembly:** Ensure the jar base is securely fitted with the appropriate blade and gasket. Place the desired jar onto the motor unit and twist gently until it locks into place. Secure the lid firmly before operation.

## 4. OPERATING INSTRUCTIONS

Follow these steps for safe and effective operation:

- 1. Ingredient Preparation:** Cut ingredients into small pieces to avoid overloading the motor. Do not fill jars beyond the

maximum fill line.

2. **Attaching Jars:** Place the jar onto the motor unit and turn clockwise until it locks securely. Ensure the lid is properly closed and locked.
3. **Speed Control:** The mixer grinder features a 3-speed rotary control knob and a pulse function.
  - **Speed 1-3:** Turn the knob clockwise to select desired grinding speed. Start with lower speeds and gradually increase as needed.
  - **Pulse Function:** For short bursts of power or to dislodge ingredients, turn the knob to the 'P' (Pulse) position and release.



Image: The mixer grinder with various ingredients, demonstrating its use for different preparations.

4. **Wet Grinding (1.5L Jar):** Ideal for batters, purees, and gravies. Add liquids as required for smooth consistency.
5. **Dry Grinding (1L Jar):** Suitable for spices, coffee beans, and grains. Ensure ingredients are completely dry for best results.
6. **Chutney Grinding (300ml Jar):** Designed for small quantities of chutneys and pastes.
7. **Juicing (1.5L Juicer Jar):** Use for extracting juice from fruits and vegetables. Ensure the sieve is properly inserted.
8. **Operation Time:** Do not operate the mixer grinder continuously for more than 5 minutes. Allow a 2-3 minute cooling period between cycles to prevent motor overheating.

## 5. MAINTENANCE

Proper maintenance ensures the longevity and hygiene of your appliance.

1. **Cleaning the Motor Unit:** Always unplug the appliance before cleaning. Wipe the motor unit with a damp cloth. Do not immerse the motor unit in water.
2. **Cleaning Jars and Blades:**
  - After each use, immediately rinse jars and blades with water to prevent food from drying.
  - Use mild dish soap and a soft brush to clean the jars and blades thoroughly.
  - For stubborn stains, soak the jars in warm soapy water for a few minutes.

- Rinse well and dry completely before storing.



Image: Close-up view of the super-efficient stainless steel blades.

3. **Blade Care:** Handle blades with extreme care as they are sharp. Avoid touching the sharp edges directly.
4. **Storage:** Store the mixer grinder and its accessories in a clean, dry place.

## 6. TROUBLESHOOTING

If you encounter any issues, refer to the following common problems and solutions:

- **Appliance Not Starting:**
  - Check if the power cord is securely plugged into the outlet.
  - Ensure the jar is correctly locked onto the motor unit.
  - Verify that the power supply is active.
- **Burning Smell During First Use:** A mild burning smell during the initial uses is normal due to the motor varnish heating up. This should dissipate after a few uses. If the smell persists or is strong, discontinue use and contact customer service.
- **Excessive Noise/Vibration:**
  - Ensure the mixer grinder is placed on a stable, flat surface.
  - Check if the jar is properly locked and the lid is secure.
  - Avoid overloading the jar with ingredients.
- **Motor Stops During Operation:** The built-in overload protector may have activated due to overheating or overloading. Unplug the appliance, remove some ingredients if overloaded, and allow the motor to cool down for 10-15 minutes before restarting.

## 7. SPECIFICATIONS

Feature	Detail
Brand	Prestige
Model	IRIS PLUS MIXER GRINDER
Power	750 Watts
Voltage	220 Volts
Number of Speeds	3

Controls Type	Knob
Blade Material	Stainless Steel
Container Material	Stainless Steel (Grinding Jars), Polycarbonate (Juicer Jar)
Wet Jar Capacity	1.5 litres
Dry Jar Capacity	1 litre
Chutney Jar Capacity	300 ml
Juicer Jar Capacity	1.5 litres
Product Dimensions	2D x 50W x 29H Centimeters
Item Weight	5 kg 500 g
Special Features	Ergonomic Handle, Multiple Attachments
Certifications	ISI Certified
Country of Origin	India

## 8. WARRANTY AND SUPPORT

---

Your Prestige Iris Plus Mixer Grinder is covered by a comprehensive warranty.

- **Warranty:** This product comes with a 2-year limited warranty on both the product and the motor from the date of purchase. Please retain your purchase receipt as proof of purchase for warranty claims.
- **Customer Support:** For any service, repair, or warranty claims, please contact the Prestige Brand Service Centre. Refer to the contact information provided in the user manual included in the product packaging or visit the official Prestige website for the nearest service center.