



Manuals.plus /

› eKids /

› eKids Super Mario Bluetooth Speaker (Model TI-B66MR.EXV24) Instruction Manual

eKids TI-B66MR.EXV24

eKids Super Mario Bluetooth Speaker Instruction Manual

Model: TI-B66MR.EXV24

INTRODUCTION

Thank you for purchasing the eKids Super Mario Bluetooth Speaker. This manual provides essential information for setting up, operating, and maintaining your speaker. Please read these instructions carefully before use and retain them for future reference.



Image: The eKids Super Mario Bluetooth Speaker in its retail packaging, featuring Mario in a green pipe design.

PRODUCT FEATURES

- **Bluetooth Connectivity:** Wirelessly stream audio from compatible devices up to 30 feet away.
- **Iconic Design:** Features a sculpted Super Mario design, with Mario emerging from a green pipe.
- **Portable:** Compact and lightweight for easy transport.
- **Rechargeable Battery:** Built-in lithium-ion battery for extended playback.
- **USB Charging:** Includes a USB charging cable for convenient power.



Image: A visual representation of the speaker's key features: Bluetooth wireless streaming, rechargeable lithium-ion battery, and included USB charging cable.



Image: An illustration highlighting the speaker's compatibility with various devices such as smartphones, tablets, laptops,

PACKAGE CONTENTS

- eKids Super Mario Bluetooth Speaker (Model: T1-B66MR.EXV24)
- USB Charging Cable
- Instruction Manual (this document)

CONTROLS AND INDICATORS




Image: A detailed view of the speaker's rear panel, indicating the On/Off switch, USB charging port, Bluetooth button, and the LED indicators for power, pairing, and charging status.

1. **On/Off Switch:** Located on the back of the speaker to power the unit on or off.
2. **USB Charging Port:** Connect the provided USB cable here for charging.
3. **Bluetooth Button:** Press and hold to initiate Bluetooth pairing mode.
4. **LED Indicators:** Display the speaker's power status, Bluetooth pairing status, and charging status.

CHARGING THE SPEAKER

Before initial use, fully charge the speaker for optimal battery performance.

1. Connect the small end of the included USB charging cable to the USB Charging Port on the back of the speaker.
2. Connect the large end of the USB charging cable to a powered USB port (e.g., computer, USB wall adapter).
3. The LED indicator will illuminate to show charging status. It will change color or turn off when charging is complete.

4. Disconnect the cable once fully charged.

Note: The speaker contains 1 Lithium Ion battery. Do not attempt to replace the battery yourself.

BLUETOOTH PAIRING

Follow these steps to connect your Super Mario Bluetooth Speaker to a Bluetooth-enabled device:

1. Ensure the speaker is fully charged.
2. Slide the On/Off switch to the "On" position. The LED indicator will begin to flash, indicating it's in pairing mode.
3. On your Bluetooth-enabled device (smartphone, tablet, etc.), go to the Bluetooth settings menu.
4. Search for available devices. The speaker will appear as "eKids Super Mario Speaker" or a similar name.
5. Select the speaker from the list to initiate pairing.
6. Once successfully paired, the LED indicator on the speaker will stop flashing and remain solid. A confirmation tone may also sound.
7. You can now stream audio wirelessly to your speaker.

Note: If pairing fails, turn off the speaker and your device's Bluetooth, then repeat the steps. The Bluetooth range is approximately 10 meters (30 feet).

OPERATING THE SPEAKER

After successful Bluetooth pairing, you can control audio playback from your connected device.

- **Volume Control:** Adjust the volume directly from your connected device.
- **Audio Playback:** Use your device's media player to play, pause, skip tracks, etc.
- **Power Off:** To conserve battery, slide the On/Off switch to the "Off" position when not in use.



Image: A child enjoying the speaker while playing games, demonstrating its use in a typical home environment.

MAINTENANCE

- **Cleaning:** Use a soft, dry cloth to clean the speaker. Do not use liquid cleaners or aerosols.
- **Storage:** Store the speaker in a cool, dry place away from direct sunlight and extreme temperatures.
- **Water Exposure:** This speaker is **not waterproof**. Avoid exposure to water or moisture.
- **Battery Care:** To prolong battery life, avoid fully discharging the battery frequently. Charge it regularly.

TROUBLESHOOTING

Problem	Possible Solution
No power	Ensure the speaker is charged. Connect the USB charging cable and allow it to charge for at least 30 minutes before attempting to power on.
Cannot pair via Bluetooth	<ul style="list-style-type: none">◦ Make sure the speaker is in pairing mode (flashing LED).◦ Ensure your device's Bluetooth is enabled and within 10 meters (30 feet) of the speaker.◦ Forget the speaker from your device's Bluetooth list and try pairing again.◦ Turn both the speaker and your device off and on, then retry pairing.
No sound or low volume	<ul style="list-style-type: none">◦ Increase the volume on your connected device.◦ Ensure the speaker is properly paired and connected.◦ Check if the audio source on your device is playing.
Poor audio quality	<ul style="list-style-type: none">◦ Move the speaker closer to your Bluetooth device to reduce interference.◦ Avoid placing the speaker near other wireless devices that may cause interference.◦ Ensure the audio source is of good quality.

SPECIFICATIONS

Feature	Detail
Brand	eKids
Model Number	TI-B66MR.EXV24
Connectivity Technology	Bluetooth
Wireless Technology	Bluetooth
Bluetooth Range	10 Meters (approx. 30 feet)
Speaker Maximum Output Power	3 Watts
Audio Output Mode	Stereo
Speaker Type	Portable
Power Source	Battery Powered (1 Lithium Ion battery included)
Control Method	Touch (via connected device)
Item Dimensions (D x W x H)	4.87"D x 3.27"W x 3.27"H
Item Weight	0.34 Kilograms
Enclosure Material	Plastic
Is Waterproof	No
Compatible Devices	Personal Computer, Smartphone, Tablet, Television
UPC	092298949840

WARRANTY AND SUPPORT

This eKids Super Mario Bluetooth Speaker comes with a **Limited Warranty**. For specific warranty terms and conditions, please refer to the documentation included with your purchase or visit the eKids official website.

For technical support, troubleshooting assistance, or to inquire about replacement parts, please contact eKids customer service. Contact information can typically be found on the product packaging or the official eKids website.

You can also visit the eKids Brand Store on Amazon for more product information and support resources.