

[Manuals.plus](#) /

› [Happy Plugs](#) /

› Happy Plugs Air 1 Go True Wireless Earbuds User Manual

Happy Plugs AIR 1 GO WHITE1670

Happy Plugs Air 1 Go True Wireless Earbuds

User Manual - Model: AIR 1 GO WHITE1670

INTRODUCTION

Thank you for choosing the Happy Plugs Air 1 Go True Wireless Earbuds. This manual provides detailed instructions on how to set up, operate, maintain, and troubleshoot your earbuds to ensure optimal performance and longevity. Please read this manual carefully before using the product.



Image: Happy Plugs Air 1 Go True Wireless Earbuds in their white charging case, ready for use.

WHAT'S IN THE BOX

Upon opening the package, please ensure all the following items are present:

- Happy Plugs Air 1 Go True Wireless Earbuds (Left and Right)
- Charging Case
- USB Charging Cable
- User Manual (this document)

SETUP

1. Charging the Earbuds and Case

Before first use, fully charge the earbuds and the charging case.

1. Place both earbuds into the charging case, ensuring they are correctly seated in their respective slots.
2. Connect the USB charging cable to the charging port on the case and the other end to a USB power source (e.g., computer, wall adapter).
3. The LED indicator on the case will show charging status. Allow approximately 1.5 hours for a full charge.



Image: The charging case open, revealing the earbuds and the charging contacts for proper placement.

2. Pairing with Your Device

The earbuds automatically enter pairing mode when removed from the case.

1. Ensure the earbuds are charged.
2. Open the charging case and remove both earbuds. They will automatically power on and attempt to pair with each other.
3. On your smartphone or Bluetooth-enabled device, go to the Bluetooth settings.
4. Search for new devices and select "Happy Plugs Air 1 Go" from the list.
5. Once connected, you will hear a confirmation tone, and the earbuds' LED indicators will stop flashing.

Note: If pairing fails, place the earbuds back in the case, close the lid, wait 10 seconds, and then repeat the steps.

OPERATING INSTRUCTIONS

Power On/Off

- **Power On:** Remove earbuds from the charging case. They will power on automatically.
- **Power Off:** Place earbuds back into the charging case and close the lid. They will power off automatically.
- **Manual Power Off:** Press and hold the touch surface on either earbud for 5 seconds.
- **Manual Power On:** Press and hold the touch surface on either earbud for 2 seconds.

Touch Controls

The Happy Plugs Air 1 Go features intuitive touch controls on each earbud.



Image: A close-up view of the Happy Plugs Air 1 Go earbuds, showing the sleek design and the general area for touch controls.

Earbud Touch Commands

Action	Command (Left or Right Earbud)
Play/Pause Music	Single tap
Next Track	Double tap (Right earbud)
Previous Track	Double tap (Left earbud)
Answer/End Call	Single tap
Reject Call	Press and hold for 2 seconds
Activate Voice Assistant	Triple tap

Single Earbud Use

You can use either the left or right earbud independently. Simply remove one earbud from the case, and it will automatically connect to your device. The touch controls for that earbud will function as listed above, with track navigation commands specific to the earbud being used.



Image: An overview of key features including premium audio, built-in microphone, sweat resistance, universal device compatibility, 11 hours of battery life, and 14 touch commands.

MAINTENANCE AND CARE

- **Cleaning:** Use a soft, dry, lint-free cloth to clean the earbuds and charging case. Do not use harsh chemicals or abrasive materials.
- **Water Resistance:** The earbuds are sweat resistant. Avoid submerging them in water or exposing them to excessive moisture. Dry them thoroughly if they get wet.
- **Storage:** When not in use, store the earbuds in their charging case to protect them and keep them charged.
- **Battery Care:** To preserve battery life, avoid fully discharging the earbuds and case frequently. Charge them regularly, even

if not in constant use.

- **Temperature:** Do not expose the earbuds or case to extreme temperatures (hot or cold), as this can damage the battery and internal components.

TROUBLESHOOTING

Common Issues and Solutions

Problem	Possible Solution
Earbuds not pairing with device	1. Ensure earbuds are charged. 2. Place earbuds back in case, close lid, wait 10 seconds, then remove to re-enter pairing mode. 3. Forget "Happy Plugs Air 1 Go" from your device's Bluetooth list and try pairing again. 4. Ensure your device's Bluetooth is enabled and within range.
Only one earbud has sound	1. Place both earbuds back in the case, close the lid, and then remove them together. 2. Ensure both earbuds are charged. 3. Reset the earbuds (refer to the full Happy Plugs support page for specific reset instructions if needed).
Earbuds not charging	1. Ensure the charging cable is securely connected to both the case and the power source. 2. Check if the power source is working. 3. Clean the charging contacts on the earbuds and inside the case with a dry cotton swab.
Poor sound quality	1. Ensure the earbuds are clean and free of debris. 2. Check your device's volume settings. 3. Move closer to your device to avoid Bluetooth interference.

SPECIFICATIONS

Happy Plugs Air 1 Go Technical Specifications

Feature	Detail
Model Name	Air 1 Go
Model Number	AIR 1 GO WHITE1670
Connectivity Technology	Wireless (Bluetooth 5.0)
Battery Life (Earbuds)	Up to 3 hours per charge
Total Playtime (with Case)	Up to 11 hours
Microphone	Built-In Omnidirectional
Control Type	Touch Control (14 commands)
Water Resistance Level	Sweat Resistant
Item Weight	3.5 Grams (per earbud)
Material	Plastic

Feature	Detail
Color	White

WARRANTY AND SUPPORT

Happy Plugs products are covered by a limited warranty. For detailed warranty information, product registration, and technical support, please visit the official Happy Plugs website or contact their customer service.

Official Website: www.happyplugs.com

Please retain your proof of purchase for warranty claims.