Saved from manuals.plus.
Open the live page for links to other documents and user manuals.

MERITLINE B08CKNK66N

MERITLINE Twin Over Full Bunk Bed with Stairs User Manual

Model: B08CKNK66N | Brand: MERITLINE

Introduction

This manual provides essential information for the safe assembly, use, and maintenance of your MERITLINE Twin Over Full Bunk Bed with Stairs. Please read all instructions carefully before assembly and retain this manual for future reference.

Important Safety Information

WARNING:

- This bunk bed is not suitable for children under 6 years old.
- Always supervise children when they are using the bunk bed.
- Exercise caution around sharp edges during assembly and use.
- Ensure the bunk bed is assembled correctly to prevent instability or collapse.
- Do not exceed the weight capacity of each bed:**200 lbs for the upper bed** and **250 lbs for the bottom bed**.

Product Specifications

Feature	Detail
Size	Twin Over Full
Product Dimensions	91.73"L x 54.33"W x 61.4"H
Color	White-drawers
Finish Type	Wood
Assembly Required	Yes

Feature	Detail
Compatible Mattress Size	Twin (upper), Full (lower)
Included Components	Bunk Bed*1, Installation Manual
Special Feature	Spindles

For detailed dimensions, refer to the diagram below:




Image: Detailed dimensions of the MERITLINE Twin Over Full Bunk Bed, showing length, width, height, and individual component measurements.

Setup and Assembly

The MERITLINE Twin Over Full Bunk Bed requires assembly. It comes with a step-by-step instruction manual and necessary tools. It is recommended to have at least two adults for assembly.

Assembly Steps Overview:

1. Unpack all components and verify against the parts list in the included manual.
2. Assemble the main bed frames (twin and full) according to the instructions.
3. Attach the staircase unit, ensuring all connections are secure.
4. Install the storage drawers beneath the full bed.
5. Place the bed slats evenly across both bed frames.
6. Ensure all bolts and fasteners are tightened securely before use.

For a complete guide, please refer to the physical installation manual included with your product. An online version may also be available under the product's technical specifications.



Image: The MERITLINE bunk bed components shown separated, illustrating its detachable design into a twin bed, a full bed, and storage drawers.

Usage and Features

Product Overview:



Image: A fully assembled MERITLINE Twin Over Full Bunk Bed in white, featuring a staircase with integrated shelving and three under-bed storage drawers.

Key Features:

- **Detachable Design:** This bunk bed can be separated into a standalone twin bed and a standalone full bed, offering flexibility as needs change.
- **Integrated Storage:** Features two under-bed drawers and storage shelves built into the staircase, providing convenient space for linens, toys, or other items.
- **Sturdy Construction:** Built with wood, designed for durability and stability. Each bed includes 10 slats for even mattress support, eliminating the need for box springs.

Mattress Recommendations:

- **Top Bunk:** Recommended mattress thickness is 6 inches.
- **Bottom Bunk:** Recommended mattress thickness is 6 to 8 inches.
- Mattresses are sold separately.



Image: A detailed view of the bunk bed's staircase, highlighting the built-in shelves for storage and easy access to the top bunk.



Image: The MERITLINE bunk bed showing the three under-bed storage drawers, with one partially open to display its capacity.

Maintenance

Proper care and maintenance will extend the life of your bunk bed.

- **Cleaning:** Wipe surfaces with a soft, damp cloth. Avoid harsh chemicals or abrasive cleaners that may damage the finish.
- **Tighten Fasteners:** Periodically check and tighten all bolts, screws, and fasteners to ensure the bed remains stable and secure. This should be done every 3-6 months.
- **Avoid Overloading:** Do not exceed the recommended weight limits for each bunk.
- **Ventilation:** Ensure adequate air circulation around mattresses to prevent moisture buildup.

Troubleshooting

If you encounter any issues with your bunk bed, refer to the following common solutions:

- **Squeaking Noises:** Check all connections and tighten any loose bolts. Ensure the bed is on a level surface.
- **Instability/Wobbling:** Verify that all components are correctly assembled and all fasteners are fully tightened. Ensure the bed is placed on a flat, stable floor.
- **Drawers Not Sliding Smoothly:** Check for any obstructions in the drawer glides. Ensure the drawers are properly aligned within their tracks.
- **Missing Parts:** If you find any parts missing during assembly, contact customer support immediately.

Warranty and Support

For specific warranty information, please refer to the documentation included with your purchase or contact MERITLINE customer service. If you have any questions about your product, assembly, or require assistance, please do not hesitate to contact our after-sales service department.
You may also visit the MERITLINE Store on Amazon for additional product information and support resources.

© 2023 MERITLINE. All rights reserved.

Ask a question about this manual

Ask about setup, troubleshooting, compatibility, parts, safety, or missing instructions. Manuals+ will review the question and use this page's manual context to help answer it.

Name

Anonymous

Email

you@example.com

After a successful submission, we securely hash the supplied account or form email before sending it to Microsoft Advertising for conversion attribution. Privacy details.

Question

Example: How do I reset this device or fix this error?

Details

Model number, symptoms, what you tried, or the section of the manual you are using.

Submit question

Open the live page

https://manuals.plus/asin/B08CKNK66N

More documents and user manuals: **https://manuals.plus/**