

Manuals.plus /

› oneisall /

› oneisall Low Noise Dog and Cat Clippers Replacement Blade Instruction Manual

oneisall 1162910

oneisall Low Noise Dog and Cat Clippers Replacement Blade Instruction Manual

Model: 1162910

1. PRODUCT OVERVIEW

This document provides instructions for the oneisall Low Noise Dog and Cat Clippers Replacement Blade. This blade is designed to offer excellent cutting performance for pet grooming, ensuring a smooth and efficient experience for both pets and owners.

- **High-Quality Materials:** Features an upgraded stainless steel fixed blade and a ceramic moving blade.
- **Cooler Operation:** Ceramic cutting technology helps the blade run cooler during use.
- **Long-Lasting Sharpness:** Designed to stay sharper for extended periods.
- **Durability:** The blade is engineered for long-term use.
- **Easy Maintenance:** Detachable design allows for simple changing and cleaning.



Image: Detailed view of the oneisall replacement blade, highlighting its ceramic and stainless steel construction for durability and performance.

2. COMPATIBILITY

This replacement blade is specifically designed for use with oneisall Low Noise Dog and Cat Clippers. It is compatible with the following oneisall clipper models:

- B01HRSZRXM
- B07H9WJYK2
- B01LW145RS

- B083QHGD16
- B098BFT3CF
- B0923Y231R

Ensure your clipper model matches one of the listed ASINs for proper fit and function.



Image: A visual guide displaying several onesall pet clipper models, indicating their compatibility with this replacement blade. Models shown include those with identifiers like 26225202-003DE, X2, X3, and A11.

3. INSTALLATION AND DISASSEMBLY

Follow these steps to correctly disassemble and install the replacement blade on your onesall pet clippers.

3.1. Disassembly

1. **Adjust Gear:** Set the clipper's blade adjustment gear to 0.8.
2. **Push Blade Down:** Firmly push the blade downwards to release it from its housing.
3. **Remove Blade:** The blade should now be easy to detach from the clipper body.

3.2. Installation

1. **Adjust Gear:** Set the clipper's blade adjustment gear to 2.0.
2. **Align Blade:** Carefully align the new blade with the slot on the clipper.
3. **Secure Blade:** Push the blade in the direction indicated by the arrow on the clipper until you hear a distinct click, ensuring it is securely fastened.



Image: A step-by-step visual guide illustrating how to disassemble the old blade and assemble the new replacement blade onto the onesall pet clippers. It shows adjusting the gear, pushing the blade, aligning, and securing it.



Image: A simplified visual representation of the quick and easy process to remove an existing blade and install a new one on the onesall clippers.

4. MAINTENANCE

Proper maintenance extends the life and performance of your replacement blade.

- **Regular Cleaning:** The detachable design allows for easy cleaning. After each use, remove the blade and brush away any trapped hair.
- **Lubrication:** Apply lubricating oil to the blade regularly, especially if grooming multiple animals. This reduces friction and heat, maintaining cutting efficiency.
- **Avoid Water:** Do not immerse the blade in water or attempt to wash it with water. Exposure to water can cause the blade to seize and become permanently damaged. Clean with a dry brush or specialized blade cleaner.
- **Storage:** Store the blade in a clean, dry place when not in use to prevent rust and damage.

5. TROUBLESHOOTING

If you encounter issues with your replacement blade, consider the following:

- **Poor Cutting Performance / Dullness:** If the blade is pulling hair or not cutting effectively, it may be dull. Replacement blades are consumable items and will eventually require replacement.
- **Blade Seizing:** If the blade mechanism feels stiff or has seized, it is likely due to moisture exposure. Ensure the blade is kept dry and lubricated. A seized blade typically requires replacement.
- **Improper Installation:** Double-check that the blade is correctly aligned and securely clicked into place as per the installation instructions. An improperly installed blade will not function correctly.

6. SPECIFICATIONS

Feature	Detail
Item Model Number	1162910
Brand Name	oneisall
Recommended Uses	Clipping
Hair Type Compatibility	All
Target Audience	Cat (also suitable for dogs with oneisall clippers)
Unit Count	1 Count
Item Weight	0.02 Kilograms (0.63 ounces)
Material Type	Stainless Steel, Ceramic
Blade Material	Stainless Steel, Ceramic
Color	Black
Special Features	Hypoallergenic, Easy to Clean
Package Dimensions	2.68 x 2.36 x 0.71 inches

7. WARRANTY AND SUPPORT

oneisall is committed to providing high-quality products and excellent customer service.

- **Warranty:** This product is covered by a 2-Year Warranty. Please retain your proof of purchase for warranty claims.
- **Customer Support:** For any questions, concerns, or assistance, oneisall offers 24/7 customer support.
- **Contact Information:** Refer to the official oneisall website or your product packaging for specific contact details.



oneisall, founded in 2012, is a leading brand in smart pet products, dedicated to **"Transform How You Pet"** with innovative, high-quality grooming and feeding solutions that simplify pet care for both pets and their owners.

Image: A graphic highlighting oneisall's commitment to customer satisfaction, featuring a smiling support person and icons for a 2-year warranty and 24/7 support.