

Manuals+

[Q & A](#) | [Deep Search](#) | [Upload](#)

manuals.plus /

- > [VGR](#) /
- > [VGR V-040 Professional Hair Clipper Instruction Manual](#)

VGR V-040

VGR V-040 Professional Hair Clipper Instruction Manual

1. PRODUCT OVERVIEW

1.1. Product Description

The VGR V-040 Professional Hair Clipper is a versatile grooming tool designed for precision hair clipping, beard trimming, and body grooming. It features high-precision detachable stainless steel blades and a powerful motor for efficient performance. The clipper is designed for both corded and cordless use, powered by a 700mAh Lithium-ion battery, offering a substantial runtime after a quick charge. Its full-body waterproof design allows for easy cleaning and maintenance.



Image: The VGR V-040 Professional Hair Clipper, showcasing its sleek black design.

1.2. Key Features

- **Precision Blade:** High precision detachable stainless steel blades for sharp and efficient cutting.
- **Adjustable Guide Comb:** An adjustable comb is included to achieve various cutting lengths.
- **Cord/Cordless Use:** Operates both with a power cord and wirelessly for flexibility.
- **Long Runtime:** 90 minutes of cordless operation on a single charge.
- **Quick Charging:** Fully charges in approximately 1.5 hours.
- **Waterproof Design:** Full body waterproof construction for easy cleaning under running water.
- **LED Display:** Indicates battery status and charging.

FEATURES



Guide Comb

Adjustable comb to reach different cutting length



Precision Blade

High precision detachable stainless steel blades



Release Button

Quick release blades for easy cleaning



On/Off Button

Easy to operate convenient and practical



LED Display

LED display shows working and charging status

Image: Visual representation of the VGR V-040's key features, including its precision blade and LED display.

1.3. Package Contents

The VGR V-040 Professional Hair Clipper package includes the following items:

- 1x Hair Clipper (VGR V-040)
- 1x Charging Adapter
- 1x Guide Comb
- 1x Oil Bottle
- 1x Hair Comb
- 1x Cleaning Brush
- 1x Travel Pouch
- 1x User Manual



Image: All components included in the VGR V-040 Professional Hair Clipper package.

2. IMPORTANT SAFETY INSTRUCTIONS

To reduce the risk of electric shock, injury, or damage, always follow these basic safety precautions:

- Read all instructions before using this appliance.
- Keep the appliance away from water. Do not place or store the appliance where it can fall or be pulled into a tub or sink. Do not place in or drop into water or other liquid.
- Do not reach for an appliance that has fallen into water. Unplug immediately.
- Always unplug this appliance from the electrical outlet immediately after using and before cleaning.
- Do not use the appliance with a damaged cord or plug, or if it is not working properly, or if it has been dropped or damaged.
- Keep the cord away from heated surfaces.
- Never drop or insert any object into any opening.
- Do not use outdoors or operate where aerosol (spray) products are being used or where oxygen is being administered.

- Do not use this appliance with a damaged or broken comb, as injury may occur.
- Always attach plug to appliance first, then to outlet. To disconnect, turn all controls to 'OFF' (if applicable), then remove plug from outlet.
- This appliance is intended for household use only.
- Ensure the voltage specified on the appliance matches your local power supply before connecting.

3. GETTING STARTED


3.1. Charging the Clipper

Before first use, fully charge the clipper for approximately 1.5 hours. The LED display will indicate the charging status. A full charge provides up to 90 minutes of cordless operation.

1. Connect the charging adapter to the clipper's charging port.
2. Plug the adapter into a suitable electrical outlet.
3. The LED display will show the charging progress. Once fully charged, disconnect the adapter.

Cord and Cordless Use

5-minute quick charge for one full trim



Up to
90 Minutes
Runtime

Image: The VGR V-040 clipper illustrating its 90-minute runtime and charging indicator.

3.2. Attaching Guide Combs

The adjustable guide comb allows you to select various cutting lengths for different styles.

1. Ensure the clipper is turned off before attaching or detaching any comb.
2. Align the guide comb with the clipper blade and push it firmly until it clicks into place.
3. To adjust the cutting length, slide the comb adjuster to the desired setting.
4. To remove, gently pull the comb away from the blade.

4. OPERATION

4.1. Turning On/Off

Press the power button located on the clipper to turn it on or off.

4.2. Adjusting Cutting Length

Use the adjustable guide comb to select your preferred cutting length. Start with a longer setting if you are unsure, and gradually reduce it until the desired length is achieved.

4.3. Hair Clipping

For best results, ensure hair is clean and dry. Move the clipper against the direction of hair growth, using smooth, even strokes. Overlap strokes to ensure all hair is cut evenly.




Image: The VGR V-040 clipper being used for hair clipping.

4.4. Beard and Body Grooming

The VGR V-040 is suitable for beard and body grooming. Select an appropriate guide comb for the desired length. For precise lines, remove the guide comb and use the bare blade carefully.

FAMILY PORTRAIT



Image: The VGR V-040 clipper being used for beard trimming.

5. CARE AND MAINTENANCE

Regular cleaning and maintenance will ensure optimal performance and extend the life of your clipper.

5.1. Cleaning the Blades

The VGR V-040 features a full-body waterproof design, allowing for easy cleaning.

1. Turn off the clipper and disconnect it from the power source.
2. Remove the guide comb.
3. Use the included cleaning brush to remove loose hairs from the blades.
4. Rinse the blades and the clipper body under running water. Ensure no water enters the charging port if not properly sealed.
5. Allow the clipper to air dry completely before storing or recharging.



Image: The VGR V-040 clipper demonstrating its waterproof feature for easy cleaning.

5.2. Oiling the Blades

To maintain blade sharpness and prevent rust, oil the blades regularly.

1. After cleaning and drying, apply a small drop of the included lubricating oil to the teeth of the blades.
2. Turn the clipper on for a few seconds to distribute the oil evenly.
3. Wipe off any excess oil with a soft cloth.

5.3. Storage

Store the clipper in a dry, cool place, away from direct sunlight and out of reach of children. Use the provided travel pouch for protection.

6. TROUBLESHOOTING

If you encounter any issues with your VGR V-040 Hair Clipper, refer to the following common problems and solutions:

| Problem | Possible Cause | Solution |
|------------------------------|---------------------------|---|
| Clipper does not turn on. | Battery is depleted. | Charge the clipper for 1.5 hours. |
| Clipper does not turn on. | Power button malfunction. | Contact customer support. |
| Poor cutting performance. | Blades are dull or dirty. | Clean and oil the blades. If still dull, consider professional sharpening or replacement. |
| Poor cutting performance. | Hair is wet or tangled. | Ensure hair is clean and dry before clipping. |
| Clipper gets hot during use. | Extended continuous use. | Allow the clipper to cool down. Ensure blades are clean and oiled. |

7. TECHNICAL SPECIFICATIONS

| Feature | Specification |
|---------------------|---|
| Model Name | VGR V-040 |
| Power Source | Battery Powered (Cord/Cordless) |
| Battery Type | 700mAh Lithium-ion Battery |
| Charging Time | 1.5 hours |
| Run Time | 90 minutes |
| Blade Material | Stainless Steel |
| Special Feature | Waterproof |
| Product Dimensions | 20 x 20 x 2 cm |
| Item Weight | 200 g |
| Target Audience | Men |
| Included Components | 1 Hair Trimmer, 1N Cleaning Brush, 1N Comb, 1N Guide Comb, 1N Lubricating Oil |

8. WARRANTY AND CUSTOMER SUPPORT

8.1. Warranty Information

The VGR V-040 Professional Hair Clipper comes with a **1 Year Brand Warranty**. This warranty is valid only on products sold by authorized sellers. For warranty claims or to verify authorized sellers, please visit www.vgrofficial.in.

8.2. Customer Support

For any product-related queries, assistance, or support, please contact VGR customer care:

- **Email:** customercare@vgrofficial.in
- **Phone:** +91-9667796740