

[Manuals.plus](#) /

› [DarkWalker](#) /

› DarkWalker FO217 Gaming Pack Keyboard and Mouse Combo User Manual

DarkWalker FO217

DarkWalker FO217 Gaming Pack User Manual

Keyboard and Mouse Combo for PS4, Xbox One, Switch, PS3, Xbox 360

INTRODUCTION

The DarkWalker FO217 Gaming Pack provides a keyboard and mouse solution for console gaming. This combo is designed to enhance precision and speed in FPS games across multiple platforms, including Xbox One, PS4, Nintendo Switch, PS3, and Xbox 360. No additional adapter is required for its core functionality.



Image: The DarkWalker FO217 Gaming Pack, illustrating its compatibility with Nintendo Switch, Xbox One/360, and PS4/PS3 gaming consoles.

PACKAGE CONTENTS

Verify that all items are present in the package:

- 1 x Wired Keyboard (Cable length: 1.8M)
- 1 x Wired Mouse (Cable length: 1.8M)
- 1 x Mouse Pad

SETUP INSTRUCTIONS

The DarkWalker FO217 Gaming Pack connects directly to your console without the need for an external adapter. Follow the specific connection instructions for your gaming platform.

Connecting to PS4 / PS3

To use the FO217 on PS4 or PS3 consoles, an official DualShock 4 wireless controller is required for activation. Connect the keyboard, mouse, and your official controller to the console as illustrated below.



Image: Connection method for PS4/PS3, detailing how to connect the mouse, keyboard, a DualShock 4 controller, and an earphone to the console.

Connecting to Xbox One / Xbox 360

For Xbox One or Xbox 360 consoles, an official Xbox One wireless controller is necessary for activation. Connect the keyboard, mouse, and your official controller to the console as shown in the diagram.

Connection Method for XBOX ONE/360



Image: Connection method for Xbox One/360, illustrating how to connect the mouse, keyboard, an Xbox One controller, and an earphone to the console.

Connecting to Nintendo Switch

The DarkWalker FO217 offers plug-and-play functionality with the Nintendo Switch console. Simply connect the keyboard and mouse directly to the Switch dock.

Connection Method for SWITCH



Image: Connection method for Nintendo Switch, showing how to connect the mouse, keyboard, and an earphone to the console.

OPERATING INSTRUCTIONS

Custom Key Mapping

The FO217 allows for custom key mapping through dedicated PC software. This software enables you to personalize the controller button layout to your preferences. Download the PC Windows keymap program from the official DarkWalker website.

CUSTOMIZABLE BUTTON LAYOUT PROGRAM

DOWNLOAD THE PC WINDOWS KEYMAP PROGRAM ON WWW.DARKWALKERPRO.COM/
DOWNLOAD TO CUSTOMIZE THE CONTROLLER BUTTON LAYOUT.




Image: Screenshot of the Delta Keyboard Mouse Adapter PC software, demonstrating the interface for customizing button layouts.

For software download and detailed instructions, visit: darkwalkerpro.com

Headset Functionality

The keyboard features a built-in headset jack. Connect your headphones to this jack to enable in-game chat with other players. This eliminates the need for a separate headset connection to the console or controller.

NO ADAPTER REQUIRED, BUILT IN HEADSET JACK

The headset jack is built in the keyboard. Party chat is available during gaming. No adapter required, plug in controller, mouse and headset to the keyboard and play.



Image: The DarkWalker FO217 keyboard, highlighting its built-in headset jack for direct audio connection.

MAINTENANCE

To ensure the longevity and optimal performance of your DarkWalker FO217 Gaming Pack, follow these maintenance guidelines:

- **Cleaning:** Use a soft, dry cloth to wipe down the keyboard and mouse. For stubborn dirt, a slightly damp cloth can be used, ensuring no moisture enters the device. Avoid harsh chemicals or abrasive cleaners.
- **Storage:** Store the devices in a cool, dry place away from direct sunlight and extreme temperatures.
- **Cable Care:** Avoid bending or twisting the cables excessively to prevent internal damage.

TROUBLESHOOTING

If you encounter issues with your DarkWalker FO217 Gaming Pack, refer to the following common troubleshooting steps:

- **Device Not Responding:**

- Ensure all cables are securely connected to the console and the devices.
- For PS4/PS3 and Xbox One/360, confirm that an official controller is connected and activated.
- Try connecting the devices to a different USB port on your console.

- **Key Mapping Issues:**

- Verify that the PC key mapping software is correctly installed and configured.
- Ensure the custom profile is saved and loaded onto the device.
- Check for any software updates for the key mapping utility.

- **Mouse Sensitivity Problems:**

- Adjust mouse DPI settings if available on the mouse itself or through the PC software.
- Ensure the mouse pad is clean and free of obstructions.

- **Headset Audio Not Working:**

- Confirm the headset is fully plugged into the keyboard's jack.
- Check console audio settings to ensure output is directed correctly.
- Test the headset with another device to rule out headset malfunction.

If problems persist after attempting these steps, please contact customer support.

SPECIFICATIONS

Feature	Detail
Brand	DarkWalker
Model Number	FO217
Connectivity Technology	USB (Corded Electric)
Compatible Devices	Gaming Console, Personal Computer
Movement Detection Technology	Optical
Keyboard Layout	QWERTY
Number of Keys	19
Batteries Required	No
Keyboard Cable Length	1.8M
Mouse Cable Length	1.8M

WARRANTY AND SUPPORT

For warranty information, technical support, or further assistance with your DarkWalker FO217 Gaming Pack, please refer to the documentation included with your purchase or visit the official DarkWalker website. Contact details for customer service are typically available on the manufacturer's website.

