

- Manuals.plus /
- › MohMus /
 - › MohMus Premium Microfiber Vacuum Cleaner Bags Instruction Manual for Clatronic and Compatible Models

MohMus Premium Microfiber Vacuum Bags (ASIN B08CT1SWGN)

MohMus Premium Microfiber Vacuum Cleaner Bags Instruction Manual

For Clatronic and Compatible Vacuum Cleaner Models

Introduction

Setup

Operating

Instructions

Maintenance


Troubleshooting

Specifications

Support

1. INTRODUCTION

Thank you for choosing MohMus Premium Microfiber Vacuum Cleaner Bags. This product provides a high-quality, multi-layered filtration solution for your vacuum cleaner, ensuring optimal dust retention and suction power. This manual will guide you through the proper installation, usage, and maintenance of your new vacuum bags and universal filter. These bags are compatible with a wide range of vacuum cleaner models, including various Clatronic series (e.g., 1220, BS 1243, BS 1214, BS 900 EST, BR 7941, BS 1266, BS 1225, Electronic 1400, 1267, BS 1257, BS 1219, BS1231, BS 1210, BS 1600, BS 1233, TWINO 1200), AEG, Electrolux GR 50, Nilfisk Coupe, Philips HR6325, HR6326, HR6327, and Melitta Swirl Handy-Bag Y05, Y45, Y50, Y61, Y64, Y93, Y95, Y99, Y101, Y191, Y201, Y105 DD9.



Unsere Staubsaugerbeutel bestehen aus mehrlagigem Mikrovließ

Our vacuum cleaner dust bags are made of multi layer microfibre

Image: Detail of the multi-layer microfiber material used in MohMus vacuum bags, illustrating the quality and filtration capability.

2. SETUP AND INSTALLATION

Follow these steps to correctly install your new MohMus vacuum cleaner bag and filter:

1. **Prepare your vacuum cleaner:** Ensure your vacuum cleaner is unplugged from the power outlet before opening the dust compartment.
2. **Remove the old bag:** Carefully remove the full vacuum bag from its holder. Most MohMus bags feature a dust closure flap to prevent spills during removal.
3. **Install the new bag:** Insert the new MohMus vacuum bag into the designated holder within your vacuum cleaner's dust compartment. Ensure the bag's opening is securely fitted over the inlet pipe.




Image: Illustration of the dust closure flap system, demonstrating how to secure it (steps 1, 2, 3) to prevent dirt spills when handling the bag.

4. **Install the universal filter:** The package includes a universal filter. This filter can be cut to size to fit your vacuum cleaner's filter compartment.

- Locate your vacuum cleaner's filter compartment, usually near the motor or exhaust.
- Measure the dimensions of your existing filter or the filter compartment.
- Using scissors, carefully cut the provided universal filter to match the required size.
- Insert the cut filter into the compartment.



UNIVERSAL FILTER
ZUM ZUSCHNEIDEN

UNIVERSAL FILTER
CUT TO SIZE

Image: A universal filter sheet, accompanied by an icon depicting scissors cutting a dashed line, indicating that the filter can be trimmed to fit various vacuum cleaner models.

5. **Close the compartment:** Close the dust compartment cover securely. Ensure it clicks into place to maintain proper suction.

3. OPERATING INSTRUCTIONS

Once the new vacuum bag and filter are installed, your vacuum cleaner is ready for use. Operate your vacuum cleaner according to its manufacturer's instructions. The MohMus premium microfiber bags are designed to provide:

- **Optimal Suction Power:** The multi-layered material ensures consistent airflow, maintaining strong suction throughout the bag's lifespan.
- **High Filtration:** Fine dust particles are effectively captured within the bag, contributing to cleaner exhaust air.
- **Durability:** The robust construction of the bags minimizes the risk of tearing, even when collecting sharp debris.

4. MAINTENANCE

4.1. When to Change the Vacuum Bag

It is recommended to change the vacuum bag when it is approximately two-thirds full, or when you notice a significant decrease in suction power. Overfilling the bag can strain your vacuum cleaner's motor and reduce its efficiency.

4.2. Disposing of Used Bags

To dispose of a used bag, unplug the vacuum cleaner, open the dust compartment, and carefully remove the bag. Utilize the integrated dust closure flap to seal the bag, preventing dust from escaping. Dispose of the sealed bag in your household waste according to local regulations.

4.3. Filter Replacement

The universal filter should be checked regularly and replaced every 3-6 months, or more frequently if you vacuum frequently or have pets. A clogged filter can severely reduce suction and impact air quality.

5. TROUBLESHOOTING

If you encounter issues while using your vacuum cleaner with MohMus bags, consider the following:

- **Reduced Suction Power:**
 - Check if the vacuum bag is full and needs replacement.
 - Ensure the universal filter is clean and not clogged. Replace if necessary.
 - Verify that the vacuum bag is correctly installed and the dust compartment is securely closed.
 - Inspect the vacuum cleaner hose and attachments for blockages.
- **Dust Escaping:**
 - Ensure the vacuum bag is properly seated over the inlet pipe.
 - Confirm the dust compartment lid is fully closed and sealed.
 - Check if the bag itself is damaged or torn. Replace immediately if damaged.

6. PRODUCT SPECIFICATIONS

Feature	Detail
Brand	MohMus
Material	Multi-layer Microfiber
Compatibility	Compatible with various Clatronic, AEG, Electrolux GR 50, Nilfisk Coupe, Philips HR6325, HR6326, HR6327, Melitta Swirl Handy-Bag Y05, Y45, Y50, Y61, Y64, Y93, Y95, Y99, Y101, Y191, Y201, Y105 DD9 vacuum cleaners.
Package Contents	10 Vacuum Cleaner Bags, 1 Universal Filter (cut-to-size)
Special Features	Dust closure flap, optimal fine dust filtration, high suction power retention.
ASIN	B08CT1SWGN

7. SUPPORT AND WARRANTY

For any questions, concerns, or issues regarding your MohMus Premium Microfiber Vacuum Cleaner Bags, please contact the seller or manufacturer through the platform where the purchase was made. While specific warranty

information is not provided, customer satisfaction is important.
Please refer to your original purchase documentation for any applicable return or warranty policies.

© 2024 MohMus. All rights reserved. Product names and references are used for compatibility purposes only.

ASK A QUESTION ABOUT THIS MANUAL

Ask about setup, troubleshooting, compatibility, parts, safety, or missing instructions. Manuals+ will review the question and use this page’s manual context to help answer it.

Name

Anonymous

Email

you@example.com

After a successful submission, we securely hash the supplied account or form email before sending it to Microsoft Advertising for conversion attribution. [Privacy details](#).

Question

Example: How do I reset this device or fix this error?

Details

Model number, symptoms, what you tried, or the section of the manual you are using.

Submit question