

Manuals.plus /
› MohMus /
› MohMus Premium Vacuum Cleaner Bags for Wilfa RC 105 Compact, RC 705 Quiet, WCH 4601E, BS 2191, Zafir BS 1500 - Instruction Manual

MohMus Wilfa RC 105 Compact, RC 705 Quiet, WCH 4601E, BS 2191, Zafir BS 1500, AEG, Electrolux GR 50, Nilfisk Coupe, Philips HR6

MohMus Premium Vacuum Cleaner Bags Instruction Manual

For Wilfa RC 105 Compact, RC 705 Quiet, WCH 4601E, BS 2191, Zafir BS 1500, AEG, Electrolux GR 50, and other compatible models

INTRODUCTION

This manual provides comprehensive instructions for the installation, operation, and maintenance of MohMus Premium Microfibre Vacuum Cleaner Bags. These bags are engineered for superior filtration and compatibility with a wide range of vacuum cleaner models. Please read these instructions carefully before use to ensure optimal performance and longevity of your vacuum cleaner and bags.

PRODUCT OVERVIEW

Each package contains 10 premium multi-layer microfibre vacuum cleaner bags and 1 universal filter. The universal filter is designed to be cut to the required size for your specific vacuum cleaner model.



Image: A stack of ten MohMus premium vacuum cleaner bags, featuring a blue mounting collar for secure fitment.



UNIVERSAL FILTER
ZUM ZUSCHNEIDEN

UNIVERSAL FILTER
CUT TO SIZE

Image: A white, rectangular universal vacuum cleaner filter, accompanied by an icon suggesting it can be trimmed to fit various vacuum cleaner models.

SETUP AND INSTALLATION

Follow these steps to correctly install a new vacuum cleaner bag and filter:

1. **Open Vacuum Cleaner Compartment:** Locate and open the dust bag compartment of your vacuum cleaner. Refer to your vacuum cleaner's manual if you are unsure.
2. **Remove Old Bag:** Carefully remove the full dust bag. Many MohMus bags feature a dust closure flap to prevent spills.
3. **Install New Bag:** Insert the new MohMus vacuum cleaner bag into the compartment, ensuring the mounting collar is securely seated in the designated holder. Make sure the bag is fully unfolded inside the compartment.
4. **Prepare Universal Filter:** If your vacuum cleaner uses a motor protection filter, measure the dimensions of your old filter. Cut the provided universal filter to match these dimensions using scissors.
5. **Install Filter:** Place the cut universal filter into its designated slot, typically located near the motor or exhaust.
6. **Close Compartment:** Close the vacuum cleaner compartment securely. Ensure it clicks into place to prevent dust

leakage.




Image: A visual guide demonstrating three steps for utilizing the dust closure flap on the vacuum bag, ensuring secure sealing and preventing dirt from escaping during removal.

OPERATING INSTRUCTIONS

Once the new bag and filter are installed, your vacuum cleaner is ready for use. For optimal performance:

- Ensure the vacuum cleaner is switched off before opening or closing any compartments.
- Regularly check the dust bag fill level.
- Avoid vacuuming sharp objects or excessive liquids, as this can damage the bag or vacuum cleaner.

MAINTENANCE

Proper maintenance ensures efficient cleaning and extends the life of your vacuum cleaner:

- **Bag Replacement:** Change the vacuum cleaner bag when it is approximately two-thirds full, or when you notice a significant decrease in suction power. Overfilling the bag can strain the motor and reduce cleaning effectiveness.
- **Filter Replacement:** The universal filter should be checked regularly and replaced every 3-6 months, or more frequently if you vacuum frequently or have pets. A clogged filter can severely reduce suction and motor efficiency.




Image: A detailed close-up showing the multi-layer construction of the microfibre material, highlighting its filtration capabilities.

TROUBLESHOOTING

If you encounter issues, consider the following common solutions:

- **Reduced Suction Power:**
 - Check if the dust bag is full and needs replacement.
 - Inspect the universal filter for clogging and replace if necessary.
 - Ensure the vacuum cleaner bag is correctly installed and seated.

- **Dust Leakage:**
 - Verify that the dust bag's closure flap is properly sealed.
 - Ensure the vacuum cleaner compartment is fully closed and latched.
- **Unusual Noises:**
 - Check for any obstructions in the hose or nozzle.
 - Ensure the bag is not overfilled, which can strain the motor.

SPECIFICATIONS

Feature	Detail
Brand	MohMus
Material	Multi-layer Microfibre
Contents	10 Vacuum Cleaner Bags, 1 Universal Filter
Filtration	High level of fine dust filtration
Compatibility	Wilfa RC 105 Compact, RC 705 Quiet, WCH 4601E, BS 2191, Zafir BS 1500, AEG, Electrolux GR 50, Nilfisk Coupe, Philips HR6325, HR6326, HR6327, Melitta Swirl Handy-Bag Y05, Y45, Y50, Y61, Y64, Y93, Y95, Y99, Y101, Y191, Y201, Y105, DD9
Country of Origin	Germany

WARRANTY AND SUPPORT

For product support or inquiries regarding MohMus Premium Vacuum Cleaner Bags, please contact your retailer or the manufacturer, MohMus. Specific warranty details may vary by region and retailer. Please retain your proof of purchase for any warranty claims.

ASK A QUESTION ABOUT THIS MANUAL

Ask about setup, troubleshooting, compatibility, parts, safety, or missing instructions. Manuals+ will review the question and use this page’s manual context to help answer it.

Name

Anonymous

Email

you@example.com

After a successful submission, we securely hash the supplied account or form email before sending it to Microsoft Advertising for conversion attribution. [Privacy details](#).

Question

Example: How do I reset this device or fix this error?

Details

Model number, symptoms, what you tried, or the section of the manual you are using.

Submit question

Open the live page

<https://manuals.plus/asin/B08CT1Y1KZ>

More documents and user manuals: <https://manuals.plus/>