

[Manuals.plus](#) /

› [Artist hand](#) /

› Artist hand Salon Chair User Manual - Model 720524711601

Artist hand 720524711601

Artist hand Salon Chair User Manual

MODEL: 720524711601

Introduction

This manual provides essential instructions for the safe and effective use of your Artist hand Salon Chair. Designed for professional use in barbershops, beauty salons, and tattoo shops, this chair features a heavy-duty hydraulic pump for height adjustment, a 360-degree swivel, and durable construction for long-lasting performance. Please read all instructions carefully before assembly and operation.



Figure 1: Artist hand Salon Chair, front view.

Setup and Assembly

The Artist hand Salon Chair is designed for straightforward assembly. Follow these steps to set up your chair:

1. Unpack all components and verify against the parts list provided in the packaging.
2. Attach the hydraulic pump to the base. Ensure all connections are secure.
3. Mount the seat onto the hydraulic pump assembly.
4. Secure the backrest and armrests to the seat frame using the provided hardware.
5. Attach the footrest to the chair.
6. Confirm all screws and bolts are tightened to ensure stability.



Figure 2: Exploded view of Artist hand Salon Chair components for assembly.



Figure 3: Fully assembled Artist hand Salon Chair.

Operating Instructions

The Artist hand Salon Chair offers adjustable features for optimal client comfort and stylist convenience.

Height Adjustment

To adjust the chair's height, use the hydraulic pump lever located at the base. Pressing the lever down will lower the chair, while repeatedly pumping the lever will raise it. The chair can be adjusted up to 6 inches in height.

PINPOINT ADJUSTABLE



Figure 4: Hydraulic pump lever for height adjustment.

360-Degree Swivel

The chair features a full 360-degree swivel for easy positioning. To rotate the chair, simply turn the seat in the desired direction. The swivel mechanism allows for flexible movement around the client.

360° SWIVEL WITH LOCK



Figure 5: Chair demonstrating 360-degree swivel capability.

Product Overview Video

Video 1: An overview of the Artist hand Salon Chair, highlighting its features and suitability for hair stylists.

Swivel and Footrest Demonstration

Video 2: Demonstration of the 360-degree swivel and the integrated footrest of the Artist hand Salon Chair.

Maintenance

Proper maintenance ensures the longevity and optimal performance of your salon chair.

Cleaning

- Wipe clean the PU leather upholstery with a damp cloth and mild soap. Avoid harsh chemicals or abrasive cleaners, as these can damage the material.

- For the metal base and hydraulic pump, use a soft, dry cloth to remove dust and fingerprints.
- Ensure the chair is dry after cleaning to prevent water spots or moisture damage.

General Care

- Regularly check all bolts and screws for tightness. Re-tighten as necessary to maintain stability.
- Avoid exceeding the maximum weight capacity of 330 lbs to prevent damage to the hydraulic system and frame.
- Keep the hydraulic pump mechanism free from hair and debris to ensure smooth operation.

Troubleshooting

If you encounter issues with your Artist hand Salon Chair, refer to the following common problems and solutions:

Problem	Possible Cause	Solution
Chair is wobbly or unstable.	Loose connections or uneven floor surface.	Check and tighten all assembly bolts. Ensure the chair is on a flat, even surface. Adjust leveling feet if available.
Hydraulic pump not adjusting height.	Debris in pump mechanism or hydraulic fluid issue.	Ensure the pump lever is fully engaged. Check for any obstructions around the pump. If the issue persists, contact customer support.
Chair does not swivel smoothly.	Accumulation of hair or debris in the swivel mechanism.	Clean around the swivel mechanism to remove any obstructions. Apply a silicone-based lubricant if necessary.

Safety Information: Do not exceed the maximum bearing capacity of 330 lbs. Improper use of the hydraulic pump may cause injury or damage to the product.

Specifications

- **Model Number:** 720524711601
- **Brand:** Artist hand
- **Product Dimensions:** 19.5"D x 24.8"W x 44"H
- **Item Weight:** 50.7 Pounds
- **Maximum Weight Recommendation:** 330 Pounds
- **Material Type:** Stainless Steel (Frame), PU Leather (Upholstery), Sponge (Fill Material)
- **Color:** Black
- **Features:** 360-degree Swivel, Adjustable Height (6 inches), Ergonomic Design, Durable, Waterproof, Easy to Clean
- **Assembly Required:** Yes

ARTIST HAND SALON CHAIR



Ergonomic Design
Ensures Comfort



Durable and Stable



330lbs
Weight Capacity



Figure 6: Detailed dimensions of the Artist hand Salon Chair.

Warranty Information

Artist hand provides a good return and exchange service for this product. For specific warranty details and terms, please refer to the documentation included with your purchase or contact customer support.

Customer Support

If you have any questions, concerns, or require assistance with your Artist hand Salon Chair, please contact our customer service team. We are committed to providing timely support and will respond to your inquiries within 24 hours.

Please refer to your purchase documentation for specific contact methods (e.g., email, phone number).

ASK A QUESTION ABOUT THIS MANUAL

Ask about setup, troubleshooting, compatibility, parts, safety, or missing instructions. Manuals+ will review the question and use this page's manual context to help answer it.

Name

Anonymous

Email

you@example.com

After a successful submission, we securely hash the supplied account or form email before sending it to Microsoft Advertising for conversion attribution. [Privacy details](#).

Question

Example: How do I reset this device or fix this error?

Details

Model number, symptoms, what you tried, or the section of the manual you are using.

Submit question