

[Manuals.plus](#) /

› [FITUEYES](#) /

› FITUEYES Mobile TV Stand (Model B08CV1QD7Z) Instruction Manual

FITUEYES B08CV1QD7Z

FITUEYES Mobile TV Stand (Model B08CV1QD7Z) Instruction Manual

1. INTRODUCTION

This manual provides detailed instructions for the assembly, operation, and maintenance of your FITUEYES Mobile TV Stand, Model B08CV1QD7Z. This stand is designed to accommodate televisions ranging from 32 to 70 inches, offering height adjustment, swivel functionality, and mobility with its integrated wheels. Please read this manual thoroughly before assembly and use to ensure safe and correct operation.

2. SAFETY INFORMATION

- **Weight Capacity:** Do not exceed the maximum weight capacity of 88 lbs (40 kg). Overloading can cause instability and potential injury.
- **Screen Size:** Ensure your TV's screen size is within the supported range of 32-70 inches.
- **VESA Compatibility:** Verify your TV's VESA mounting pattern matches the stand's supported patterns (200x200 mm to 600x400 mm).
- **Assembly:** Assemble the stand on a soft, clean surface to prevent scratches. It is recommended that two people assemble the stand for safety and ease.
- **Stability:** Always ensure all screws are securely tightened before placing a TV on the stand. Do not move the stand with a TV mounted if the wheels are not unlocked or if moving over uneven surfaces.
- **Children and Pets:** Keep children and pets away from the stand during assembly and ensure the TV is securely mounted to prevent tipping.

3. PACKAGE CONTENTS

Please check that all components are present and undamaged. Refer to the parts list included in your product packaging for a complete inventory. If any parts are missing or damaged, contact customer support.

4. SPECIFICATIONS

Supported Screen Sizes	32 - 70 inches
Maximum Weight Capacity	88 lbs (40 kg)
VESA Compatibility	200x200 mm to 600x400 mm
Material	Wood, Steel
Movement Type	Swivel, Height Adjustable, Mobile



Figure 4.1: VESA Compatibility and Dimensions. This diagram illustrates the various VESA mounting patterns supported by the stand and its overall dimensions.

5. SETUP AND ASSEMBLY

Follow these steps carefully to assemble your FITUEYES Mobile TV Stand:

1. **Unpack Components:** Carefully remove all parts from the packaging and lay them out on a soft, flat surface. Verify all parts are present against the included parts list.
2. **Assemble the Base:** Attach the main column to the wooden base using the provided screws and tools. Ensure the base is oriented correctly for wheel installation.
3. **Install Wheels:** Securely attach the four wheels to the bottom of the wooden base. Ensure two of the wheels are locking wheels and position them for easy access.
4. **Attach TV Brackets:** Secure the TV mounting brackets to the back of your television using the appropriate screws and spacers from the hardware kit. Refer to your TV's manual for correct screw length and VESA pattern.
5. **Mount TV to Stand:** With assistance, carefully lift the TV and hook the mounted brackets onto the main column's TV plate. Ensure the TV is centered and level.
6. **Secure TV:** Insert the safety screws or pins at the bottom of the TV brackets to prevent the TV from accidentally lifting off the stand.



Figure 5.1: Security Pin. Ensure the security pin is engaged after mounting the TV.

6. OPERATING INSTRUCTIONS

6.1 Height Adjustment

The TV stand allows for vertical height adjustment to achieve an optimal viewing experience. To adjust the height, loosen the locking mechanism on the main column, carefully raise or lower the TV to the desired height, and then securely tighten the locking mechanism. Always ensure the TV is stable after adjustment.



Figure 6.1: Height Adjustment Mechanism. This image shows the adjustable column for setting TV height.

6.2 Swivel Function

The TV bracket can swivel left and right by up to 30 degrees in each direction. Gently push the TV to the desired angle.

This feature allows for flexible viewing from different positions in a room.



Figure 6.2: Swivel Functionality. The TV can be rotated left or right for optimal viewing angles.

6.3 Mobility (Wheels)

The stand is equipped with four wheels for easy movement. Two of these wheels have locking mechanisms. To move the stand, unlock the wheels. To secure the stand in place, engage the locking mechanisms on the wheels.



Figure 6.3: Locking Wheel. Engage the lock to prevent unintended movement.

6.4 Cable Management

Utilize the integrated cable management system along the main column to organize and conceal TV and device cables. This helps maintain a tidy appearance and prevents tripping hazards.

Cable Management

keeps the wires neat.



Thickening Design



Cable Management



Wheels with Brakes



Figure 6.4: Cable Management. Cables can be routed through the stand's column for a clean look.

7. MAINTENANCE

- **Cleaning:** Wipe the stand with a soft, dry cloth. Avoid abrasive cleaners or solvents that may damage the finish.
- **Check Connections:** Periodically check all screws and bolts to ensure they remain tight and secure.
- **Inspect Wheels:** Ensure wheels are free of debris and roll smoothly. Lubricate if necessary.

8. TROUBLESHOOTING

- **Stand is unstable:** Ensure all assembly screws are fully tightened. Verify the TV weight does not exceed the maximum capacity. Ensure the stand is on a flat, level surface.
- **TV is not level:** Check that the TV mounting brackets are installed evenly on the back of the TV. Adjust the height of the brackets if necessary.
- **Difficulty moving the stand:** Ensure the locking mechanisms on the wheels are disengaged. Check for any obstructions or debris around the wheels.

9. WARRANTY AND SUPPORT

This FITUEYES product comes with an up to 10-year warranty. For warranty claims, technical support, or replacement parts, please contact FITUEYES customer service. Refer to your purchase documentation for specific contact details or visit the official FITUEYES website.

ASK A QUESTION ABOUT THIS MANUAL

Ask about setup, troubleshooting, compatibility, parts, safety, or missing instructions. Manuals+ will review the question and use this page's manual context to help answer it.

Name

Email

After a successful submission, we securely hash the supplied account or form email before sending it to Microsoft Advertising for conversion attribution. [Privacy details](#).

Question

Details

Submit question