MIATONE BOOMBOX

MIATONE Boombox Portable Bluetooth Speaker User Manual

Model: BOOMBOX

INTRODUCTION

The MIATONE Boombox Portable Bluetooth Speaker (Model: BOOMBOX) is designed to deliver high-quality audio in a durable, portable package. Featuring advanced Bluetooth 5.3 technology, it offers seamless connectivity and a wide range, making it ideal for both indoor and outdoor use. Its rugged, waterproof design ensures reliability in various environments, while the option for TWS stereo pairing allows for an enhanced audio experience.





Figure 1: MIATONE Boombox Portable Bluetooth Speaker (Green)

WHAT'S IN THE BOX

- MIATONE Boombox Portable Bluetooth Speaker
- Charging Cable
- Aux-in Cable

SETUP

1. Charging the Speaker

Before first use, fully charge the speaker. Connect the provided charging cable to the speaker's charging port and the other end to a compatible USB power adapter (not included). The charging indicator light will show charging status.



Figure 2: Speaker back view with charging and aux-in ports.

2. Powering On/Off

Press and hold the power button located on the side of the speaker to turn it on or off. An English voice prompt will confirm "Power On" or "Power Off".

OPERATING INSTRUCTIONS

1. Bluetooth Pairing

- 1. Ensure the speaker is powered on and in Bluetooth pairing mode (indicated by a flashing Bluetooth indicator light).
- 2. On your device (smartphone, tablet, laptop), enable Bluetooth and search for available devices.
- 3. Select "MIATONE BOOMBOX" from the list.
- 4. Once connected, an English voice prompt will confirm "Bluetooth Connected".

The speaker maintains a stable Bluetooth connection up to 100 feet (30 meters) from your device.

2. Volume Control

Use the '+' and '-' buttons on the speaker to adjust the volume. You can also control the volume from your connected device.

3. TWS (True Wireless Stereo) Pairing

To achieve a true stereo sound experience, you can pair two identical MIATONE Boombox speakers together:

- 1. Ensure both speakers are powered on and not connected to any Bluetooth device.
- 2. On one speaker, press and hold the TWS button (often indicated by an infinity symbol or two interlocking circles). The speaker will enter TWS pairing mode.
- 3. The two speakers will automatically connect to each other. A voice prompt will confirm successful TWS pairing.
- 4. Once paired, connect your device to one of the speakers via Bluetooth as described in the "Bluetooth Pairing" section. Both speakers will now play audio in stereo.



4. Audio Playback

Control playback (play/pause, skip tracks) directly from your connected Bluetooth device. The speaker's buttons may also offer basic playback controls (e.g., single press for play/pause, long press for next/previous track, refer to specific button icons on the device).



Figure 4: Speaker delivering high-resolution audio in an outdoor setting.

MAINTENANCE

1. Cleaning

Wipe the speaker with a soft, damp cloth. Do not use harsh chemicals or abrasive cleaners. Ensure the charging port cover is securely closed before cleaning or exposing to water.

2. Storage

Store the speaker in a cool, dry place away from direct sunlight and extreme temperatures when not in use for extended periods.

3. Waterproofing

The speaker is IPX6 waterproof, meaning it can withstand powerful water jets. Do not submerge the speaker for extended periods or expose it to high-pressure water streams. Always ensure the port cover is sealed tightly to maintain water resistance.



Figure 5: Speaker floating in water, highlighting its waterproof capability.

4. Durability

The speaker features a rugged, anti-slip design with soft silicone end caps to absorb shock from drops. While durable, avoid excessive force or dropping from significant heights to prevent damage.



Figure 6: Speaker on sand, showcasing its shockproof and dustproof design.

TROUBLESHOOTING

Problem	Possible Cause	Solution
Speaker does not power on.	Low battery or no charge.	Charge the speaker fully using the provided cable.
No sound from speaker.	Volume too low, not paired, or incorrect audio source.	Increase volume on speaker and device. Ensure proper Bluetooth pairing. Check if audio is playing on the source device.
Bluetooth connection unstable or disconnects.	Device too far, interference, or low speaker battery.	Move device closer to speaker (within 100 ft). Avoid obstacles. Charge speaker. Re-pair if necessary.

Problem	Possible Cause	Solution
Cannot TWS pair two speakers.	Speakers already connected to another device, or not in TWS pairing mode.	Ensure both speakers are disconnected from other devices. Follow TWS pairing instructions carefully.

SPECIFICATIONS

Feature	Detail
Model Name	BOOMBOX
Brand	MIATONE
Speaker Type	Surround Sound
Special Features	Portable, Stereo Pairing (TWS)
Connectivity Technology	Bluetooth 5.3
Bluetooth Range	Up to 100 feet (30 meters)
Speaker Output Power	16W (20W peak)
TWS Paired Output Power	32W (40W peak)
Water Resistance Level	IPX6 Waterproof
Battery Life	Up to 17 hours (at 50% volume)
Product Dimensions	2.87"D x 2.87"W x 7.3"H
Item Weight	14.88 ounces
Included Components	Charging Cable, Aux-in Cable

WARRANTY AND SUPPORT

The MIATONE Boombox Portable Bluetooth Speaker comes with a Limited Warranty. For detailed warranty information, product support, or to contact customer service, please visit the official MIATONE Store on Amazon:

Visit MIATONE Store

© 2024 MIATONE. All rights reserved.

Documents - MIATONE - BOOMBOX



[pdf]

Statement USER CHINA model difference letter Shenzhen Miya Technologies Limited BB12 Water Proof Bluetooth Speaker 2AWG3 2AWG3BB12 bb12

Shenzhen Miya Technologies Limited RM 2212, Building A, Huihai Plaza, Chuangye Rd, Longhua, Shenzhen, China Statement Product: Water Proof Bluetooth Speaker Model: **BOOMBOX** Additional Model: Q12 Trademark: MIATONE We hereby state that All models above are identical in interior structure, electrical c...

lang:tl score:18 filesize: 14.22 K page_count: 1 document date: 2020-05-25



[pdf] Test Report

CE EMC TEST REPORT Harris DSS REP Shenzhen Miya Technologies Limited BB12 Water Proof Bluetooth Speaker 2AWG3 2AWG3BB12 bb12

TEST REPORT FCC ID: 2AWG3-BB12 Product: Water Proof Bluetooth Speaker Model No.: **BOOMBOX** Additional Model No.: Q12 Trade Mark: MIATONE Report No.: TCT200515E011 Issued Date: May 21, 2020 Issued for: Shenzhen Miya Technologies Limited RM 2212, Building A, Huihai Plaza, Chuangye Rd, Longhua, Shenzhen,...

lang:en score:13 filesize: 5.09 M page_count: 67 document date: 2020-05-26