

Beko TSE1284N

Beko TSE1284N Table Refrigerator with 4-Star Freezer User Manual

Model: TSE1284N

1. INTRODUCTION

This manual provides essential information for the safe and efficient operation of your Beko TSE1284N Table Refrigerator with 4-Star Freezer. Please read these instructions carefully before installation and use, and keep them for future reference. Proper use and maintenance will ensure the longevity and optimal performance of your appliance.

2. SAFETY INFORMATION

Always observe the following safety precautions to reduce the risk of fire, electric shock, injury, or damage to the appliance.

- **Electrical Safety:** Ensure the appliance is connected to a grounded power outlet with the correct voltage (240 Volts). Do not use extension cords or multiple socket adapters. Unplug the appliance before cleaning or maintenance.
- **Ventilation:** Ensure adequate air circulation around the appliance. Do not block ventilation openings. Maintain a minimum distance from walls as specified in the setup section.
- **Flammable Materials:** Do not store explosive substances such as aerosol cans with flammable propellants in this appliance.
- **Child Safety:** This appliance is not intended for use by persons (including children) with reduced physical, sensory or mental capabilities, or lack of experience and knowledge, unless they have been given supervision or instruction concerning use of the appliance by a person responsible for their safety. Children should be supervised to ensure that they do not play with the appliance.
- **Disposal:** When disposing of the appliance, do so in an environmentally responsible manner. Remove the door to prevent children from becoming trapped.

3. SETUP AND INSTALLATION

3.1 Unpacking

Carefully remove all packaging materials, including protective films and tapes, from the appliance. Inspect the refrigerator for any damage that may have occurred during transit. Report any damage to your retailer immediately.

3.2 Placement

The Beko TSE1284N is a freestanding appliance. Place the refrigerator on a firm, level surface away from direct sunlight, heat sources (e.g., stoves, radiators), and extreme cold. Ensure there is sufficient space around the appliance for proper ventilation. A minimum clearance of 10 cm at the back and sides is recommended to allow heat dissipation.



Image 1: Dimensions of the Beko TSE1284N refrigerator. Height: 84 cm, Width: 54 cm, Depth: 59 cm.

3.3 Door Reversal

The door of your Beko TSE1284N refrigerator is reversible, allowing it to open from either the left or the right

side. This feature provides flexibility for placement in your kitchen. Door reversal should be performed by a qualified technician or by carefully following the detailed instructions provided in the full product manual (not included here). The appliance features removable door hinges to facilitate this process.

3.4 First Use

- Before plugging in, clean the interior of the refrigerator with a mild detergent and warm water. Wipe dry thoroughly.
- After cleaning, allow the appliance to stand for at least 4 hours before plugging it into the power outlet. This allows the refrigerant to settle.
- Once plugged in, set the thermostat to a medium setting and allow the refrigerator to cool for several hours before loading it with food.

4. OPERATING INSTRUCTIONS

4.1 Temperature Control

The temperature inside your refrigerator is controlled by a thermostat dial, typically located inside the fresh food compartment. Turn the dial to adjust the cooling level. Higher numbers usually indicate colder temperatures. Start with a medium setting and adjust as needed based on ambient temperature and food load.

4.2 Food Storage

The Beko TSE1284N offers a total capacity of 114 liters, with 101 liters for cooling and a 13-liter 4-star freezer compartment. Utilize the internal layout for efficient storage:




Image 2: Interior view of the refrigerator with food items.

- **Adjustable Shelves:** The refrigerator features two adjustable shelves, allowing you to customize storage space for various items.
- **Door Compartments:** Three door compartments are provided for bottles, jars, and smaller items.
- **Vegetable Drawer:** A dedicated drawer is located at the bottom for storing fruits and vegetables, helping to maintain their freshness.
- **4-Star Freezer Compartment:** The 13-liter freezer compartment is suitable for storing frozen foods and has a freezing capacity of 2kg/24h. Ensure items are properly sealed before placing them in the freezer.



Image 3: Empty interior of the refrigerator, showcasing shelves and storage options.

4.3 MinFrost Technology

Your Beko TSE1284N refrigerator is equipped with MinFrost technology. This feature significantly reduces ice build-up on the evaporator, meaning less frequent manual defrosting is required for the freezer compartment. While it minimizes frost, occasional light frost may still form, especially with frequent door openings or high humidity.

5. MAINTENANCE

5.1 Cleaning

- **Interior:** Unplug the appliance before cleaning. Clean the interior regularly with a solution of warm water and a mild, non-abrasive detergent. Rinse with clean water and dry thoroughly. Do not use harsh chemicals or abrasive cleaners.
- **Exterior:** Wipe the exterior surfaces with a soft cloth dampened with water and a mild detergent. Dry with a soft, clean cloth.
- **Door Seal:** Clean the door gasket regularly to ensure a tight seal. A dirty or damaged seal can lead to inefficient operation.

5.2 Defrosting

Thanks to MinFrost technology, manual defrosting of the freezer compartment is required less frequently. However, if a significant layer of ice builds up (more than 5mm), it is recommended to manually defrost the freezer. To do this:

- Unplug the refrigerator.
- Remove all food items and store them in a cool place.
- Leave the freezer door open to allow the ice to melt naturally. Place towels or a tray to collect melted water.
- Do not use sharp objects or heating devices to speed up the defrosting process, as this can damage the appliance.
- Once defrosted, clean and dry the interior before plugging the appliance back in and returning food.

5.3 Power Saving Tips

- Avoid placing hot food directly into the refrigerator. Allow it to cool to room temperature first.
- Do not open the door too frequently or leave it open for extended periods.
- Ensure the door seal is clean and intact for an airtight closure.
- Periodically clean the condenser coils at the back of the appliance (if accessible) to maintain efficiency.

6. TROUBLESHOOTING

Before contacting customer service, please check the following common issues and solutions:

Problem	Possible Cause	Solution
Refrigerator is not cooling.	No power, thermostat set too high, door left open.	Check power connection, adjust thermostat, ensure door is closed properly.
Unusual noises.	Appliance not level, items vibrating inside, normal operating sounds.	Adjust leveling feet, rearrange items, consult manual for normal sounds.
Water on the floor.	Blocked drain hole, door not sealing properly.	Clear the drain hole, check door seal for obstructions.
Excessive frost in freezer.	Frequent door opening, high humidity, door seal issue.	Reduce door openings, check door seal, perform manual defrost if necessary.

If the problem persists after checking these points, please contact Beko customer service.

7. SPECIFICATIONS

Key technical specifications for the Beko TSE1284N Table Refrigerator:

Feature	Specification
Brand	Beko
Model Number	TSE1284N

Feature	Specification
Product Dimensions (L x W x H)	57 x 60 x 88 cm
Weight	28.5 kg
Total Capacity	114 Liters
Cooling Capacity	101 Liters
Freezer Volume	13 Liters (4-star)
Freezing Capacity	2 kg/24h
Noise Level	38 Decibels
Installation Type	Freestanding
Color	White
Voltage	240 Volts
Power	50 Watts
Number of Shelves	3
Number of Drawers	1 (Vegetable)
Defrost System	Automatic (MinFrost)
Door	Reversible
Energy Efficiency Class	2017/1369/EU Certified

8. WARRANTY AND SUPPORT

Your Beko TSE1284N refrigerator comes with a 24-month manufacturer's warranty, effective from the date of purchase. Please retain your proof of purchase for warranty claims.

For technical assistance, spare parts, or warranty claims, please contact Beko customer service or visit the official Beko website. Information regarding spare parts availability may vary by region.

Beko Official Website: <http://support.beko.com>