

## Manuals+

[Q & A](#) | [Deep Search](#) | [Upload](#)

manuals.plus /

› [Daytona](#) /

› [Daytona 86610 Motorcycle Heated Grips Instruction Manual](#)

## Daytona 86610

# Daytona 86610 Motorcycle Heated Grips Instruction Manual

## INTRODUCTION

---

This manual provides essential instructions for the proper installation, operation, and maintenance of your Daytona 86610 Motorcycle Heated Grips. Please read this manual thoroughly before installation and use to ensure safe and optimal performance of the product. Keep this manual for future reference.

## PACKAGE CONTENTS

---

Carefully unpack all components and verify that all items listed below are present and undamaged. If any items are missing or damaged, please contact your retailer.



Image: All components of the Daytona 86610 Motorcycle Heated Grips kit, including two heated grips, a control unit, wiring harness, mounting bracket, cable ties, screws, and electrical connectors.

- Two (2) Daytona Heated Grips (140 mm length, closed end)
- One (1) Control Unit with integrated wiring
- One (1) Mounting Bracket for Control Unit
- One (1) Wiring Harness with connectors
- Two (2) Cable Ties
- Two (2) Screws/Bolts
- Two (2) Red Electrical Splice Connectors
- One (1) Black Adhesive Pad
- One (1) Small Silver Adhesive Pad

## SETUP AND INSTALLATION

Professional installation is recommended for this product. Incorrect installation can lead to damage to the product, your motorcycle, or personal injury. Ensure the motorcycle's ignition is off and the battery is disconnected before beginning installation.

### 1. Handlebar Compatibility

These heated grips are designed for handlebars with a diameter of 22.2 mm. Please verify your motorcycle's handlebar diameter before proceeding. (Note: Some product descriptions may mention 25.4 mm; always confirm your specific handlebar size.)

## 2. Removing Existing Grips

1. Carefully remove your motorcycle's existing handlebar grips. You may need to cut them off if they are glued.
2. Clean the handlebar surfaces thoroughly, removing any old adhesive or residue. Ensure the surface is dry before installing new grips.

## 3. Installing Heated Grips

1. Apply a small amount of grip adhesive (not included) evenly to the handlebar surface.
2. Slide the Daytona heated grips onto the handlebars. Ensure the wires exit cleanly and are not pinched. Allow the adhesive to cure according to its manufacturer's instructions.

## 4. Mounting the Control Unit

1. Select a suitable location on your handlebar for the control unit, ensuring it is easily accessible and does not obstruct controls.
2. Attach the mounting bracket to the handlebar using the provided screws/bolts.
3. Secure the control unit to the mounting bracket.

## 5. Wiring Connection

Connect the wiring harness from the heated grips and control unit to your motorcycle's electrical system. It is crucial to connect to a switched 12V power source (e.g., ignition switched power) to prevent battery drain when the motorcycle is off. Use the provided electrical splice connectors if necessary, ensuring secure and insulated connections. Route all wires carefully, securing them with the provided cable ties to prevent interference with moving parts or damage from heat/abrasion.

# OPERATING INSTRUCTIONS

---

The Daytona 86610 Heated Grips feature 4 temperature settings, allowing you to adjust the heat output to your preference.

### Powering On/Off and Adjusting Temperature

1. Turn on your motorcycle's ignition.
2. Press the orange button on the control unit to power on the heated grips. The indicator lights will illuminate, showing the current heat setting.
3. Each subsequent press of the orange button will cycle through the 4 temperature settings.
4. To turn off the heated grips, continue pressing the button until all indicator lights are off, or turn off the motorcycle's ignition.

**Caution:** Prolonged use at the highest setting may cause discomfort or damage to the grips. Always use a comfortable heat level. Do not operate the grips if they are damaged or if the wiring is exposed.

# MAINTENANCE

---

The Daytona 86610 Heated Grips require minimal maintenance to ensure long-lasting performance.

- **Cleaning:** Clean the grips and control unit with a soft, damp cloth. Do not use harsh chemicals or abrasive cleaners.
- **Wiring Inspection:** Periodically inspect all wiring and connections for signs of wear, fraying, or corrosion. Ensure all connections remain secure.

- **Grip Condition:** Check the grips for any cuts, tears, or damage. Damaged grips should be replaced to maintain safety and performance.

## TROUBLESHOOTING

Problem	Possible Cause	Solution
Grips do not heat up	No power supply; Loose wiring connection; Blown fuse	Check motorcycle ignition; Verify all wiring connections are secure; Check and replace fuse if necessary.
Grips heat unevenly	Internal wiring issue; Faulty grip element	Contact customer support or a qualified technician for inspection.
Control unit not responding	No power supply; Faulty control unit	Check power connection; If power is present, the control unit may be faulty and require replacement.

If you encounter issues not listed here or if the suggested solutions do not resolve the problem, please contact Daytona customer support or a certified motorcycle technician.

## SPECIFICATIONS

- **Model:** Daytona 86610
- **Brand:** Daytona
- **Grip Length:** 140 mm
- **Handlebar Diameter Compatibility:** 22.2 mm (7/8 inch)
- **Temperature Settings:** 4 levels
- **End Type:** Closed end
- **Material:** Rubber
- **Product Dimensions:** Approximately 14 x 7.4 x 5.7 cm (overall package)
- **Item Weight:** Approximately 460 g

## WARRANTY AND SUPPORT

For warranty information, please refer to the documentation included with your purchase or visit the official Daytona website. For technical support or assistance with installation, please contact your authorized Daytona dealer or customer service.

**Manufacturer:** Daytona