



Manuals.plus /

› PLKO /

› PLKO 10FT Artificial Spruce Hinged Christmas Tree Instruction Manual

## PLKO AX318-SDS

# PLKO 10FT Artificial Spruce Hinged Christmas Tree

Model: AX318-SDS

## INTRODUCTION

---

Thank you for choosing the PLKO 10FT Artificial Spruce Hinged Christmas Tree. This manual provides detailed instructions for the safe and proper assembly, operation, maintenance, and storage of your new Christmas tree. Please read all instructions carefully before beginning assembly to ensure a beautiful and stable display for your holiday season.

## SAFETY INFORMATION

---

- This artificial Christmas tree is designed for indoor and outdoor use. Ensure it is placed on a flat, stable surface to prevent tipping.
- The tree is made from flame-retardant PVC material. However, keep all open flames, heat sources, and electrical devices (such as lights) away from the tree to prevent fire hazards.
- Do not overload the tree with excessive or heavy ornaments, as this may compromise its stability and cause branches to sag or break.
- Keep small children and pets away from small parts during assembly to prevent choking hazards.
- Always unplug any lights or electrical decorations before leaving the tree unattended or going to bed.

## PACKAGE CONTENTS

---

Before assembly, please verify that all components are present and undamaged:

- Tree Sections (typically 3-4 sections, labeled A, B, C, etc., from bottom to top)
- Metal Folding Stand
- Stand Screw (for securing the tree to the stand)



Image: The PLKO 10FT Artificial Spruce Hinged Christmas Tree, showcasing its full form and indicating that decorations are not included but are shown for illustrative purposes.

## SETUP INSTRUCTIONS

---

### 1. Unpacking

Carefully remove all components from the packaging. Lay them out on a clean, flat surface. Keep the packaging for future storage.

### 2. Assembling the Stand

Open the metal folding stand and spread its legs evenly to form a stable base. Ensure the stand is fully extended and locked into position. The stand features a scratch-resistant soft leather case on its feet to protect your floor.



► **Ours**

*Sturdy metal stand  
with scratch-resistant  
soft leather case*

**VS**

**Others** ◀

*Weak plastic feet with  
loose structure*



Image: A comparison highlighting the sturdy metal stand provided with the PLKO tree, designed for stability and floor protection, versus a less stable plastic alternative.

### 3. Assembling Tree Sections

Insert the bottom section (usually labeled 'A') of the tree into the center hole of the assembled stand. Secure it firmly with the provided screw by tightening it into the stand's collar. Then, insert the middle section (labeled 'B') into the top of section 'A', and continue with the top section (labeled 'C') until all sections are connected. The hinged branches will fall into place automatically.

### 4. Shaping the Branches

Once all sections are assembled, begin to 'fluff' or shape the branches. Starting from the bottom and working your way up, gently spread out each individual branch tip, bending them slightly upwards and outwards to fill any gaps and create a full, natural appearance. The tree features 2150 branch tips designed to look full-bodied and genuine.



## **2150 Tips**

*Branch tips look  
more full-bodied  
and genuine*

Image: A detailed close-up view of the tree's branch tips, illustrating the dense and realistic appearance achieved by the 2150 tips.



Image: Individuals engaged in decorating a Christmas tree, demonstrating the final stage of setup where ornaments and lights are added.

## OPERATING INSTRUCTIONS

---

Once assembled and fluffed, your PLKO Christmas tree is ready for decoration. This tree is designed to be a centerpiece for your holiday decor, suitable for various settings.

- **Placement:** Choose a prominent location in your home or outdoor area that is flat and stable. Ensure there is enough space around the tree for easy movement and decoration.
- **Decorating:** Apply your preferred lights, ornaments, and garlands. Distribute decorations evenly to maintain balance and prevent stress on individual branches.
- **Lighting:** If adding string lights, ensure they are rated for indoor/outdoor use as appropriate for your tree's placement and follow all manufacturer instructions for the lights.



Image: A fully decorated PLKO 10FT Artificial Spruce Hinged Christmas Tree, adorned with various ornaments and lights, surrounded by wrapped gifts, illustrating its festive appearance.



Image: The PLKO 10FT Artificial Spruce Hinged Christmas Tree positioned on an outdoor patio, demonstrating its suitability for both indoor and outdoor holiday decor.

## MAINTENANCE

---

### Cleaning

To clean your artificial Christmas tree, gently wipe down the branches with a soft, damp cloth. Avoid using harsh chemicals or abrasive cleaners, as these can damage the PVC material. For dust, a feather duster or a vacuum cleaner with a brush attachment can be used on a low setting.

### Disassembly and Storage

After the holiday season, carefully remove all decorations and lights. Disassemble the tree by reversing the assembly steps: remove the top section, then the middle, and finally the bottom section from the stand. Gently compress the hinged branches. Store the tree sections and stand in their original packaging or a suitable storage bag in a cool, dry place away from direct sunlight to preserve the material and color for future use.

## TROUBLESHOOTING

---

Problem	Possible Cause	Solution
Tree is wobbly or unstable.	Stand not fully extended or screw not tightened. Uneven surface.	Ensure the metal stand legs are fully spread and locked. Tighten the stand screw securely. Place the tree on a flat, level surface.
Branches appear sparse or not full.	Branches not properly fluffed or shaped.	Spend time carefully spreading and shaping each individual branch tip, bending them upwards and outwards to fill gaps. This process significantly impacts the tree's fullness.
Tree height seems shorter than advertised.	Measurement taken incorrectly or tree not fully assembled/fluffed.	Ensure all sections are securely connected and the top section is fully inserted. The stated height includes the top-most tip of the tree. Proper fluffing can also add to perceived height.

## SPECIFICATIONS

Feature	Detail
Brand	PLKO
Model Number	AX318-SDS
Product Dimensions	55"D x 55"W x 120"H (10 feet tall)
Color	Green
Material	Polyvinyl Chloride (PVC)
Item Weight	32 Pounds
Tip Count	2150
Special Features	Flame Resistant, Non Allergenic
Tree Type	Spruce
Base Type	Metal Folding Stand
UPC	783914711285




Image: A visual representation of the tree's dimensions, indicating a height of 10 feet and a base width of 55 inches, alongside details about its life-like tips and safe, durable materials.

## WARRANTY AND SUPPORT

For any questions, concerns, or support regarding your PLKO 10FT Artificial Spruce Hinged Christmas Tree, please refer to the retailer's return policy or contact PLKO customer service through their official channels. Specific warranty details may vary by region and retailer. Please retain your proof of purchase for any warranty claims.

For more information about PLKO products, you may visit the PLKO Store on Amazon.