

AIKELA M100C

AIKELA Bluetooth Headset User Manual

Model: M100C

INTRODUCTION

Thank you for choosing the AIKELA Bluetooth Headset. This manual provides detailed instructions on how to set up, operate, and maintain your headset to ensure optimal performance and longevity. Designed for clear communication and comfort, this headset is ideal for various applications including business calls, online meetings, and general multimedia use.


PRODUCT OVERVIEW



The AIKELA Bluetooth Headset features a comfortable over-ear design with an adjustable headband and a 280° rotatable microphone. It is equipped with soft memory foam ear cushions for extended wear. The headset integrates Bluetooth 5.0 technology for stable connections and a noise-canceling microphone for clear audio transmission.



Key comfort features include an adjustable headband to fit various head sizes, a microphone that can rotate 280 degrees for left or right ear use, and soft memory foam ear cushions designed for breathability and comfort during long periods of use.



The headset features easily accessible controls including volume up (+), volume down (-), a multi-functional button for power and call management, a Type-C charging port, and a dedicated mute button with an LED indicator for the microphone.

SETUP

1. Charging the Headset




Before first use, fully charge the headset. Connect the provided Type-C charging cable to the headset's charging port and the other end to a USB power source. A full charge takes approximately 1.5 hours. The headset provides up to 30 hours of talk/music time on a single charge and has a standby time of 400 hours.

2. Bluetooth Pairing

1. Ensure the headset is fully charged.
2. Power on the headset by pressing and holding the Multi-Functional Button until the LED indicator flashes blue and red, indicating pairing mode.
3. On your device (smartphone, PC, tablet), enable Bluetooth and search for available devices.
4. Select "AIKELA M100C" from the list of devices.
5. Once connected, the LED indicator will show a solid blue light.

3. Dual Device Connection



The AIKELA headset supports simultaneous connection to two Bluetooth devices. After connecting to the first device, disable Bluetooth on the first device. Then, pair the headset with the second device following the Bluetooth Pairing steps. Once the second device is connected, re-enable Bluetooth on the first device. The headset should automatically connect to both devices, allowing you to seamlessly switch between calls from your work phone and personal phone, or other devices.

OPERATING INSTRUCTIONS

Basic Controls

Button/Action	Function
Multi-Functional Button (Press and Hold)	Power On/Off
Multi-Functional Button (Short Press)	Play/Pause Music, Answer/End Call
Multi-Functional Button (Double Press)	Redial Last Number
Multi-Functional Button (Press and Hold during incoming call)	Reject Call
Volume + Button (Short Press)	Increase Volume
Volume - Button (Short Press)	Decrease Volume
Mute Button (Short Press)	Mute/Unmute Microphone (LED indicator shows mute status)

The dedicated mute button allows for quick microphone muting during calls, providing privacy when needed. The LED indicator on the mute button will change to confirm the mute status.

MAINTENANCE

- **Cleaning:** Use a soft, dry cloth to clean the headset. Do not use abrasive cleaners or solvents. For ear cushions, gently wipe with a damp cloth and allow to air dry completely before use.
- **Storage:** Store the headset in a cool, dry place away from direct sunlight and extreme temperatures. Avoid placing heavy objects on the headset.
- **Battery Care:** To prolong battery life, avoid fully discharging the headset frequently. Charge it regularly, even if not in use for extended periods.

TROUBLESHOOTING

Problem	Possible Solution
Headset does not power on.	Ensure the headset is fully charged. Connect it to a power source and try again.
Cannot pair the headset with a device.	<ul style="list-style-type: none">• Ensure the headset is in pairing mode (flashing blue and red LED).• Make sure Bluetooth is enabled on your device.• Move the headset closer to your device.• "Forget" or remove the headset from your device's Bluetooth list and try pairing again.• Restart both the headset and your device.
No sound or low volume.	<ul style="list-style-type: none">• Increase the volume on both the headset and your connected device.• Ensure the headset is properly connected to your device.• Check if the microphone is muted if you are experiencing issues with outgoing audio.
Microphone not working.	<ul style="list-style-type: none">• Check if the microphone mute button is active (indicated by LED).• Ensure the microphone boom is positioned correctly towards your mouth.• Verify microphone settings on your connected device (e.g., in communication software).
Connection is unstable or drops frequently.	<ul style="list-style-type: none">• Ensure the headset is within the 10-meter Bluetooth range of your device.• Avoid obstacles between the headset and your device (e.g., walls, large metal objects).• Minimize interference from other wireless devices.

SPECIFICATIONS

Feature	Detail
Model Name	M100C
Connectivity Technology	Wireless (Bluetooth)
Wireless Communication Technology	Bluetooth 5.0
Bluetooth Range	Up to 10 meters (33 feet)
Battery Life (Talk/Music Time)	Up to 30 hours
Charging Time	Approximately 1.5 hours
Noise Control	Active Noise Cancellation (Microphone)
Earpiece Shape	On Ear
Material	Memory Foam (ear cushions)
Item Weight	141 Grams (approx. 5 ounces)
Compatible Devices	PCs, Smartphones, Tablets

WARRANTY AND SUPPORT

AIKELA products are designed and manufactured to the highest quality standards. For information regarding warranty coverage and customer support, please refer to the warranty card included with your product or visit the official AIKELA website. If you encounter any issues not covered in this manual, please contact AIKELA customer service for assistance. For further assistance, you may visit the AIKELA Store on Amazon:[AIKELA Store](#)