Onvian B08CXVG38M

Onvian Remote Control User Manual

For Smart Bike Tail Light Anti-Theft Motorcycle Bike Alarm

1. Introduction

This manual provides comprehensive instructions for the setup, operation, and maintenance of your Onvian Remote Control. This remote is designed to work specifically with Onvian Smart Bike Tail Light Anti-Theft Motorcycle Bike Alarms (models B07Y8BW8TF and B09Q86S7K2).

Please read this manual carefully before using the product to ensure proper function and longevity.

2. Safety Information

- Keep the remote control away from extreme temperatures, direct sunlight, and corrosive liquids.
- Do not attempt to disassemble or modify the remote control, as this will void the warranty and may cause damage.
- Ensure the battery is inserted with correct polarity.
- Dispose of used batteries responsibly according to local regulations.
- This remote control is IPX5 waterproof, meaning it is protected against low-pressure water jets from any direction. It is not designed for submersion.

3. Product Overview

The Onvian Remote Control is a compact and durable device designed for wireless operation of compatible Onvian bike alarms. It features four distinct buttons for various alarm functions.



Image: Front view of the Onvian Remote Control, showing its four buttons and sleek design.

3.1 Remote Control Buttons



Image: Diagram illustrating the functions of each button on the Onvian Remote Control.

- **Lock Button (Arm):** Activates the alarm system, putting it in armed mode.
- **Unlock Button (Disarm):** Deactivates the alarm system.
- **Lightning Bolt Button (Tone Selected):** Changes the alarm tone or sensitivity setting (functionality depends on the connected alarm model).
- **Bell Button (Vehicle Finder):** Triggers a sound from the alarm to help locate your bike.

3.2 Package Contents



Image: Contents of the Onvian Remote Control package, including the remote, mounting clip, zip ties, and adhesive pad.

- Onvian Remote Control (1)
- Mounting Clip (1)
- Zip Ties (2)
- Adhesive Pad (1)
- 12V/27A Alkaline Battery (pre-installed)

4. Setup

4.1 Battery Installation

The remote control comes with a 12V/27A alkaline battery pre-installed. If replacement is needed, carefully open the remote control casing and replace the battery, ensuring correct polarity. Close the casing securely after replacement.

5. Operating Instructions

5.1 Pairing the Remote Control

To pair the remote control with your Onvian Smart Bike Tail Light Anti-Theft Alarm, follow these steps:

1. **Step 1:** Ensure the alarm is disarmed. Click the disarm button on your existing remote or disarm the alarm manually if applicable.
2. **Step 2:** On the alarm unit, long press the function key for 7 seconds to cancel any existing pairing mode. You will hear a single "di" sound, indicating that the alarm has been disarmed and is ready for new pairing.
3. **Step 3:** Long press the function key on the alarm unit for 3 seconds to enter pairing mode. You will hear one "Di" sound.
4. **Step 4:** Within the pairing mode, press any button on the new remote controller. You will hear two "didi" sounds, indicating successful pairing.

The remote control is now paired and ready for use.

5.2 Basic Operations

- **Arming the Alarm:** Press the **Lock** button once. The alarm will typically emit a confirmation sound.
- **Disarming the Alarm:** Press the **Unlock** button once. The alarm will typically emit a confirmation sound.
- **Changing Tone/Sensitivity:** Press the **Lightning Bolt** button to cycle through available alarm tones or sensitivity levels (refer to your alarm's manual for specific functionality).
- **Vehicle Finder:** Press the **Bell** button to activate a short burst of sound from the alarm, helping you locate your bike.

6. Maintenance

- **Cleaning:** Wipe the remote control with a soft, dry cloth. Do not use abrasive cleaners or solvents.
- **Storage:** Store the remote control in a cool, dry place when not in use.
- **Battery Replacement:** Replace the 12V/27A alkaline battery when the remote's range decreases or it stops responding. Battery life is approximately 1 year with typical usage (5 times/day).

7. Troubleshooting

Problem	Possible Cause	Solution
Remote not responding to alarm.	Not paired; Low battery; Out of range.	Re-pair the remote (see Section 5.1); Replace battery; Move closer to the alarm.
Remote range is short.	Low battery; Environmental interference.	Replace battery; Avoid strong electromagnetic interference.
Alarm does not respond to pairing.	Incorrect pairing steps; Alarm not in pairing mode.	Ensure correct pairing sequence (see Section 5.1); Verify alarm is compatible.

8. Specifications



Image: Dimensions of the Onvian Remote Control, showing its length, width, and thickness.

Feature	Specification
Brand	Onvian
Model	B08CXVG38M
Power Source	Battery Powered
Battery Type	12V/27A Alkaline Battery (included)
Wireless Range	Up to 80 meters (empty distance)

Feature	Specification
Waterproof Rating	IPX5
Dimensions (L x W x H)	5.5 cm x 4 cm x 1.5 cm (2.17 x 1.57 x 0.59 inches)
Weight	32 grams
First Available Date	August 9, 2020

9. Warranty and Support

Onvian products are manufactured to high-quality standards. For warranty information or technical support, please refer to the specific warranty terms provided at the time of purchase or contact Onvian customer service through the retailer where the product was acquired.

Keep your purchase receipt as proof of purchase for any warranty claims.

Ask a question about this manual

Ask about setup, troubleshooting, compatibility, parts, safety, or missing instructions. Manuals+ will review the question and use this page's manual context to help answer it.

Name

Anonymous

Email

you@example.com

After a successful submission, we securely hash the supplied account or form email before sending it to Microsoft Advertising for conversion attribution. Privacy details.

Question

Example: How do I reset this device or fix this error?

Details

Model number, symptoms, what you tried, or the section of the manual you are using.

Submit question