

Manuals+

[Q & A](#) | [Deep Search](#) | [Upload](#)

manuals.plus /

- › [Brookstone](#) /
- › [Brookstone Wireless Ergonomic Mouse Instruction Manual \(Model B08CY64YCZ\)](#)

Brookstone Wireless Ergonomic Mouse (B08CY64YCZ)

Brookstone Wireless Ergonomic Mouse Instruction Manual

Model: Wireless Ergonomic Mouse (B08CY64YCZ)

1. INTRODUCTION

This manual provides detailed instructions for the setup, operation, and maintenance of your Brookstone Wireless Ergonomic Mouse. Designed for comfort and efficiency, this mouse features a selectable DPI, dedicated navigation buttons, and broad compatibility with Mac and PC systems.

Brookstone®



RIGHT HAND USER

Optimized for right hand user



DPI BUTTON

dpi sensitivity button-press to switch between 800, 1200 or 1600dpi



ERGONOMIC DESIGN

Sleek form-fitting ergonomic design with a high palm grip



Figure 1: Side view of the Brookstone Wireless Ergonomic Mouse. This image highlights the mouse's dimensions (approximately 4.75 inches in length and 1.7 inches in height) and its ergonomic design, optimized for right-hand users with a high palm grip.

2. PACKAGE CONTENTS

Please ensure all items are present in the package:

- Brookstone Wireless Ergonomic Mouse
- USB Nano Receiver (2.4 GHz)
- 2 x AAA Batteries

3. SETUP INSTRUCTIONS

3.1. Battery Installation

1. Locate the battery compartment on the underside of the mouse.
2. Open the battery compartment cover.
3. Insert the two AAA batteries, ensuring correct polarity (+/-).

4. Close the battery compartment cover securely.

3.2. Connecting the USB Nano Receiver

1. Remove the USB nano receiver from its storage slot on the underside of the mouse.
2. Plug the USB nano receiver into an available USB-A port on your laptop or desktop computer.
3. The mouse should automatically connect to your computer. No additional software installation is required.

4. OPERATING INSTRUCTIONS

The Brookstone Wireless Ergonomic Mouse is designed for intuitive use with several key features to enhance your productivity.



Figure 2: Overview of the Brookstone Wireless Ergonomic Mouse with labeled features. This image points out the Next/Last Page Buttons, the DPI Sensitivity Button, and the Thumb Rest. It also highlights the wireless connection, soft touch finish, and ergonomic design.

4.1. DPI Sensitivity Button

The dedicated DPI sensitivity button, located on the top of the mouse, allows you to adjust the pointer speed

and precision. Press this button to cycle through the following DPI settings:

- **800 DPI:** For slower, more precise movements.
- **1200 DPI:** A balanced setting for general use.
- **1600 DPI:** For faster pointer movement.

4.2. Next and Previous Buttons

Located on the side of the mouse, these buttons allow for quick navigation. Press the **Next** button to advance to the next page or item, and the **Previous** button to go back to the previous page or item, particularly useful when browsing web pages or documents.

4.3. Ergonomic Design

The mouse is contoured for right-handed use, providing a comfortable grip and reducing strain during extended periods of use. The soft touch finish enhances tactile comfort.

5. MAINTENANCE

5.1. Cleaning

To clean your mouse, gently wipe the surface with a soft, damp cloth. Avoid using harsh chemicals or abrasive cleaners, as these can damage the finish.

5.2. Battery Replacement

When the mouse performance degrades or it stops responding, it may be time to replace the batteries. Follow the battery installation steps in Section 3.1 to replace the two AAA batteries.

6. TROUBLESHOOTING

- **Mouse not responding:**
 - Ensure the USB nano receiver is securely plugged into a USB-A port.
 - Check the batteries. Replace them if necessary.
 - Try plugging the receiver into a different USB-A port.
 - Restart your computer.
- **Erratic pointer movement:**
 - Ensure the mouse is on a clean, flat, non-reflective surface.
 - Change the DPI setting using the DPI sensitivity button.
- **Short wireless range:**
 - Move the mouse closer to the USB nano receiver.
 - Avoid placing the receiver near large metal objects or other wireless devices that may cause interference.

7. SPECIFICATIONS

Feature	Specification
Brand	Brookstone

Feature	Specification
Model	Wireless Ergonomic Mouse (B08CY64YCZ)
Color	Black
Connectivity Technology	USB, Wireless (2.4 GHz)
Movement Detection Technology	Optical
DPI Settings	800, 1200, 1600 DPI (selectable)
Number of Buttons	2 (plus scroll wheel, DPI button, Next/Previous buttons)
Hand Orientation	Right
Compatible Devices	Laptop, Personal Computer
Operating System Compatibility	OS X/macOS 10.4 or later; Windows XP, Vista, 7-10
Power Source	2 x AAA Batteries (included)
Manufacturer	Lifeworks Technology, Inc.

8. WARRANTY AND SUPPORT

For warranty information or technical support, please refer to the documentation provided with your purchase or contact Brookstone customer service. Keep your proof of purchase for warranty claims.