

## Manuals+

[Q & A](#) | [Deep Search](#) | [Upload](#)

manuals.plus /

- › [Koblenz](#) /
- › [Koblenz WD-6K2 Wet-Dry Vacuum Cleaner Instruction Manual](#)

## Koblenz WD-6K2

# Koblenz WD-6K2 Wet-Dry Vacuum Cleaner Instruction Manual

Model: WD-6K2

## INTRODUCTION

This manual provides essential instructions for the safe and efficient operation, maintenance, and troubleshooting of your Koblenz WD-6K2 Wet-Dry Vacuum Cleaner. Please read this manual thoroughly before using the appliance and retain it for future reference.



Figure 1: Koblenz WD-6K2 Wet-Dry Vacuum Cleaner. This image shows the main unit with its distinctive black and lime green color scheme, featuring the handle, hose connection, and accessory storage. The unit is equipped with wheels for mobility.

## IMPORTANT SAFETY INSTRUCTIONS

When using an electrical appliance, basic precautions should always be followed, including the following:

- Read all instructions before using this vacuum cleaner.
- Do not leave appliance when plugged in. Unplug from outlet when not in use and before servicing.
- Do not use outdoors or on wet surfaces.
- Do not allow to be used as a toy. Close attention is necessary when used by or near children.
- Use only as described in this manual. Use only manufacturer's recommended attachments.

- Do not use with damaged cord or plug. If appliance is not working as it should, has been dropped, damaged, left outdoors, or dropped into water, return it to a service center.
  - Do not pull or carry by cord, use cord as a handle, close a door on cord, or pull cord around sharp edges or corners. Do not run appliance over cord. Keep cord away from heated surfaces.
  - Do not unplug by pulling on cord. To unplug, grasp the plug, not the cord.
  - Do not handle plug or appliance with wet hands.
  - Do not put any object into openings. Do not use with any opening blocked; keep free of dust, lint, hair, and anything that may reduce air flow.
  - Keep hair, loose clothing, fingers, and all parts of body away from openings and moving parts.
  - Do not pick up anything that is burning or smoking, such as cigarettes, matches, or hot ashes.
  - Do not use to pick up flammable or combustible liquids, such as gasoline, or use in areas where they may be present.
  - Do not use without filter in place.
  - Turn off all controls before unplugging.
  - Use extra care when cleaning on stairs.
- 

## SETUP AND ASSEMBLY

Before operating your Koblenz WD-6K2, ensure all components are correctly assembled.

1. **Unpack Components:** Carefully remove all parts from the packaging. Verify that all accessories listed in the specifications are present.
2. **Attach Wheels:** Securely attach the reinforced wheels to the base of the vacuum cleaner. Ensure they click into place or are fastened according to the diagram.
3. **Connect Hose:** Insert the flexible hose into the intake port on the front of the vacuum unit. Twist to lock it securely.
4. **Assemble Extension Wands and Nozzle:** Connect the two telescopic tubes (extension wands) together, then attach the desired floor accessory (with squeegee for wet use, or brush for dry use) to the end.
5. **Install Filter:** For dry vacuuming, ensure the high-efficiency pleated filter is correctly installed inside the tank. For wet vacuuming, remove the pleated filter and ensure the foam filter (if included) is in place, or follow instructions for filter-less wet operation if applicable.



Figure 2: The Koblenz WD-6K2 unit with its hose and various attachments laid out, illustrating the components for assembly.

## OPERATING INSTRUCTIONS

### Dry Vacuuming

For dry debris such as dust, dirt, and small particles:

1. Ensure the high-efficiency pleated filter is securely installed.
2. Attach the appropriate dry cleaning accessory (e.g., floor brush, crevice tool) to the extension wands.
3. Plug the power cord into a suitable electrical outlet.
4. Turn the vacuum cleaner ON using the power switch.
5. Move the nozzle over the area to be cleaned, allowing the powerful suction to collect debris.
6. When finished, turn the vacuum OFF and unplug it.



Figure 3: A close-up view of the vacuum's crevice tool effectively cleaning dry debris, such as dust and small particles, from a surface.

## Wet Vacuuming

For liquid spills and wet messes:

1. **Important:** Remove the pleated filter before wet vacuuming. Install the foam filter if your model includes one for wet use, or ensure the float mechanism is clear.
2. Attach the floor accessory with squeegee or other suitable wet pick-up tool.



3. Plug the power cord into a suitable electrical outlet.
4. Turn the vacuum cleaner ON.
5. Move the nozzle slowly over the liquid spill to suction it into the tank.
6. The vacuum will automatically stop suctioning when the tank is full due to the float mechanism. Turn OFF the vacuum immediately and empty the tank.
7. When finished, turn the vacuum OFF and unplug it.



Figure 4: The vacuum's floor nozzle with squeegee attachment is shown effectively cleaning a liquid spill, demonstrating its wet pick-up capability.

---

## MAINTENANCE

Regular maintenance ensures optimal performance and extends the life of your vacuum cleaner.

- **Emptying the Tank:** After each use, especially wet vacuuming, unlatch the motor head and carefully lift it off. Pour out the collected debris or liquid. Clean the inside of the tank with water and mild detergent if necessary,

then dry thoroughly.

- **Cleaning Filters:**

- **Pleated Filter (Dry Use):** Tap the filter gently to dislodge dust. For deeper cleaning, rinse with water and allow to air dry completely before reinstallation. Do not use the vacuum with a wet pleated filter.
- **Foam Filter (Wet Use):** Rinse the foam filter with water and mild soap. Squeeze out excess water and allow to air dry completely before storage or next use.

- **Hose and Accessories:** Check the hose and accessories for blockages. Clear any obstructions to maintain suction power. Rinse wet accessories after use.

- **Cord Storage:** Wrap the power cord neatly around the designated storage hooks on the unit to prevent damage.



Figure 5: Rear view of the Koblenz WD-6K2, highlighting the integrated cord storage feature and the exhaust port.



Problem	Possible Cause	Solution
Vacuum does not turn on.	No power to the unit.	Check if the power cord is securely plugged into a working outlet. Test the outlet with another appliance.
Loss of suction.	Hose or attachment is blocked. Filter is clogged. Tank is full (wet vacuuming). Lid is not sealed properly.	Inspect and clear any blockages in the hose, wands, or nozzle. Clean or replace the filter according to maintenance instructions. Empty the tank. Ensure the motor head is securely latched onto the tank.
Water leaking from exhaust.	Tank is overfilled during wet vacuuming.	Turn off the vacuum immediately and empty the tank. Ensure the float mechanism is clean and operating correctly.
Motor runs but no suction.	Hose not connected properly. Lid not sealed. Large blockage.	Re-attach the hose securely. Check and re-latch the motor head. Check for and remove any large blockages.

## SPECIFICATIONS







- **Model:** WD-6K2
- **Brand:** Koblenz
- **Engine:** 3.0 HP
- **Tank Capacity:** 6 Gallons
- **Filter Type:** High Efficiency (pleated), Foam (for wet use, if applicable)
- **Special Features:** Wet/Dry capability, Air Ejection System, On-board accessory storage, Reinforced wheels
- **Included Components:** 2 telescopic tubes, floor accessory with squeegee, corner accessory, upholstery brush
- **Hose Diameter:** 1 ¼ inches
- **Product Dimensions:** 13.98 x 13.98 x 19.88 inches
- **Item Weight:** 14.97 pounds
- **Noise Level:** 82 Decibels

## WARRANTY AND CUSTOMER SUPPORT

For warranty information, service, or technical support, please refer to the warranty card included with your product or contact Koblenz customer service directly. Keep your purchase receipt as proof of purchase.

**Contact Information:** Please visit the official Koblenz website for the most up-to-date contact details for your region.

Related Documents - WD-6K2

	<p><a href="#">Koblenz WD-2.5 L/MA Wet/Dry Vacuum Cleaner Owner's Manual and Safety Guide</a></p> <p>This owner's manual provides essential safety instructions, operating procedures, maintenance tips, and warranty information for the Koblenz WD-2.5 L and WD-2.5 MA Wet/Dry Vacuum Cleaner.</p>
	<p><a href="#">Koblenz Coffee Maker User Manual - CKM Series</a></p> <p>Comprehensive user manual for Koblenz coffee makers, including models CKM-215 IN, CKM-212 IN, CKM-212 R, CKM-212 PIN, CKM-204 N, and CKM-204 B. Features setup, operation, maintenance, troubleshooting, and warranty information.</p>
	<p><a href="#">Koblenz Mix&amp;Go BKM-1000/BKM-800 User Manual</a></p> <p>User manual for the Koblenz Mix&amp;Go blender, including safety instructions, operation, maintenance, troubleshooting, and warranty information for models BKM-1000 and BKM-800.</p>
	<p><a href="#">Koblenz Product Warranty Information</a></p> <p>Details the warranty terms for Koblenz products, covering defects in materials and workmanship for one year, and exclusions for misuse or unauthorized repairs. Includes contact information for service centers.</p>
	<p><a href="#">Koblenz HL-450 V Pressure Washer Operating Instructions and Manual</a></p> <p>Comprehensive operating instructions, safety guidelines, maintenance, and troubleshooting for the Koblenz HL-450 V pressure washer. Learn how to use and care for your Koblenz pressure washer.</p>
	<p><a href="#">Koblenz B-1500 P/DC Burnisher Service Manual and Parts List</a></p> <p>Comprehensive service manual and parts list for the Koblenz B-1500 P and B-1500 DC burnisher models, including safety tests, replacement procedures, troubleshooting, electrical information, wiring diagrams, and a detailed parts list with assembly diagrams.</p>