

Manuals+

[Q & A](#) | [Deep Search](#) | [Upload](#)

[manuals.plus](#) /

› [GOBOULT](#) /

› [Boult Audio Powerbuds True Wireless Earbuds User Manual](#)

GOBOULT Omega

Boult Audio Powerbuds True Wireless Earbuds User Manual

Model: Omega

INTRODUCTION

Welcome to the user manual for your Boult Audio Powerbuds True Wireless Earbuds. These earbuds are designed to provide a high-quality audio experience with extended battery life, robust features, and a comfortable fit. This manual will guide you through the setup, operation, maintenance, and troubleshooting of your device.

WHAT'S IN THE Box

Upon opening your Boult Audio Powerbuds package, you should find the following items:

- Powerbuds Earphones (Left and Right)
- Charging Case
- Extra Pair of Earbuds (various sizes for optimal fit)
- Charging Micro USB Cable
- User Manual

Combat™ Gaming

Ultra Low Latency

Lights up to speak up your game



Image: Contents of the Boult Audio Powerbuds package.

The image above displays the complete contents of the Boult Audio Powerbuds box, including the earbuds, charging case, a micro USB charging cable, additional ear tips for a customized fit, and the user manual.

SETUP

Initial Pairing (First Time Use)

1. Remove both earbuds from the charging case. They will automatically power on and pair with each other.
2. On your mobile device, navigate to the Bluetooth settings.
3. Ensure Bluetooth is enabled.
4. Search for available devices and select "Boult Audio Powerbuds" to connect.
5. Once connected, you will hear an audio prompt confirming the connection.

Automatic Re-pairing

After initial pairing, the earbuds will automatically connect to the last paired device when removed

from the charging case, provided Bluetooth is enabled on your device.

Power On/Off

- **Power On:** Remove the earbuds from the charging case. They will automatically power on.
- **Power Off:** Place the earbuds back into the charging case. They will automatically power off and begin charging.

Your browser does not support the video tag.

Video: This video demonstrates the initial pairing process, automatic re-pairing, and how to power the earbuds on and off by placing them in or removing them from the charging case.

OPERATING INSTRUCTIONS

Music Control

- **Play/Pause:** Tap once on either earbud.
- **Next Track:** Double-tap the right earbud.
- **Previous Track:** Double-tap the left earbud.

Volume Control

- **Increase Volume:** Press and hold the right earbud for 3 seconds.
- **Decrease Volume:** Press and hold the left earbud for 3 seconds.

Call Control

- **Answer/End Call:** Tap once on either earbud.
- **Reject Call:** Press and hold either earbud for 2 seconds.

Voice Assistant

- **Activate Voice Assistant (Siri/Google Assistant):** Triple-tap either earbud.

Crafted in India, For India



Image: The touch-sensitive area on the earbuds allows for easy control of music playback, calls, and voice assistant activation.

Your browser does not support the video tag.

Video: This video illustrates how to control music playback, adjust volume, manage calls, and activate the voice assistant using the touch controls on the earbuds.

CHARGING

Charging the Earbuds

Place the earbuds into the charging case. They will automatically enter charging mode. The LED indicators on the earbuds will show their charging status.

Charging the Case

Connect the provided Micro USB cable to the charging port on the case and plug the other end into a 5V/1A power adapter. The LED indicators on the case will show the charging progress. For optimal charging performance, use the original Type-C cable and a compatible power supply.




Image: The charging case provides extended playtime and supports Type-C fast charging.

Power Bank Feature

The charging case features a 2200mAh battery and can be used as a power bank to charge other smart devices via its USB-A output port.



Image: The 2200mAh charging case can also function as a power bank for other devices.

FEATURES

- **Extended Playtime:** Enjoy up to 120 hours of total playtime with the charging case. Each earbud charge provides up to 6 hours of playback.

- **Bluetooth 5.0:** Ensures stable and fast wireless connectivity with your devices.
- **IPX7 Waterproof:** The earbuds are protected against sweat and splashes, making them suitable for workouts and outdoor activities.
- **Dual Mics:** Equipped with dual microphones for clear call quality.
- **Ergonomic Design:** Designed for a secure and comfortable fit during extended use.
- **Touch Controls:** Intuitive touch controls for managing music, calls, and voice assistant.
- **Low Latency Mode:** Provides an enhanced gaming experience with minimal audio delay.



Image: The IPX7 waterproof rating ensures durability against water and sweat.



Image: Experience enhanced gaming with ultra-low latency for synchronized audio and visuals.

TROUBLESHOOTING

Resetting the Earbuds

If you experience pairing issues or other connectivity problems, you may need to reset the earbuds:

1. Clear the pairing record of "Boult Audio Powerbuds" from your mobile device's Bluetooth settings.
2. Place both earbuds back into the charging case.
3. Press and hold both earbuds for approximately 6 seconds while they are in the charging state. This will reset their pairing.
4. Remove the earbuds from the case and attempt to re-pair them with your device following the "Initial Pairing" steps.

Your browser does not support the video tag.

Video: This video provides a visual guide on how to reset the Boult Audio Powerbuds to resolve pairing or connectivity issues.

SPECIFICATIONS

Feature	Specification
Model Name	AirBass Omega
Connectivity Technology	Bluetooth 5.0
Headphones Jack	Type-C (for charging case)
Battery Capacity (Case)	2200mAh
Total Playtime	Up to 120 hours (with charging case)
Water Resistance Level	IPX7 Waterproof
Control Method	Touch
Item Weight	50 Grams
Material	Plastic
Included Components	PowerBuds Earphones, Charging case, Extra Pair of ear buds, Charging Micro USB cable, User Manual

WARRANTY AND SUPPORT

Warranty Information

Your Boult Audio Powerbuds come with a 1-year manufacturer's warranty. Please refer to the warranty registration card included in your package for details on how to register your product and claim warranty services.

Customer Support

For any questions, concerns, or technical assistance, please contact Boult Audio customer support:

- **Email:** complaints@boultaudio.com
- **Phone:** +91-9555602502