

DoHonest B08D3G5WD4

DoHonest Automatic Pet Feeder User Manual

Model: B08D3G5WD4

1. INTRODUCTION

Thank you for choosing the DoHonest Automatic Pet Feeder. This device is designed to provide scheduled and portion-controlled meals for your pet, ensuring a consistent feeding routine. With Wi-Fi connectivity, voice recording, and dual power options, this feeder offers convenience and peace of mind for pet owners.

Please read this manual thoroughly before operating the feeder to ensure proper use and maintenance.

2. PRODUCT FEATURES

- **Programmable Feeding:** Customize up to 4 meals per day, with 1 to 20 portions per meal (approximately 5g per portion).
- **Voice Recorder:** Record a 10-second message to call your pet at meal times.
- **Dual Power Mode:** Operates via AC adapter or 3 x D-Type batteries (not included) for backup power.
- **Clog-Free Design:** Engineered to prevent food blockages during dispensing.
- **Detachable Stainless Steel Bowl:** Easy to clean and hygienic for your pet.
- **Wi-Fi Enabled App:** Control and schedule feeding via a dedicated app for iOS and Android devices.
- **4-Liter Food Capacity:** Suitable for small to medium-sized pets.

Never Miss A Meal




Image: The DoHonest Automatic Pet Feeder displaying its programmable feeding schedule, 4L food tank capacity, and recommended kibble size (5-10mm). A cat is shown next to the feeder, illustrating its use.

Reset Assured

Your Pet Will Always be Fed on Time



Image: The DoHonest Automatic Pet Feeder with illustrations of owners sleeping, exercising, and working, emphasizing that pets will be fed on time regardless of owner's schedule. Three dogs are shown in the foreground.

3. SETUP GUIDE

3.1 Unpacking and Component Check

Carefully remove all components from the packaging. Ensure you have the main feeder unit, food bowl, power adapter, and this user manual.

3.2 Power Connection

Connect the AC power adapter to the feeder's power input port and then to a wall outlet. For backup power, install 3 x D-Type batteries into the battery compartment at the bottom of the feeder. Batteries are not included.

Dual Power Mode

Powered battery(3D-Type) or C cable.
Stay online forever,Reduce your worries



Image: The DoHonest Automatic Pet Feeder illustrating its dual power mode, showing the Android connector for AC power and the compartment for D-Type batteries (not included).

3.3 Food Tank Assembly and Filling

1. Place the stainless steel food bowl onto the feeder base.
2. Open the lid of the food tank.
3. Fill the food tank with dry pet kibble. Ensure the kibble size is between 5-10mm to prevent blockages.
4. Close the lid securely.

3.4 App Download and Wi-Fi Connection

1. Download the DoHonest pet feeder app from the App Store (iOS) or Google Play Store (Android).
2. Register an account and log in.
3. Follow the in-app instructions to connect the feeder to your home Wi-Fi network. Ensure your Wi-Fi is 2.4GHz.

4. OPERATING INSTRUCTIONS

4.1 Control Panel Overview

All Function Control Panel

Provides clear,detailed instructions on all the programming




Image: Detailed view of the DoHonest Automatic Pet Feeder's control panel, labeling buttons for Record, Play, On/Off, Hour, Minute, Manual, Time, Mealsize, 4 Meal, Dinner, Low Battery, Lunch, and Breakfast.

- **Record:** Press to record a voice message.
- **Play:** Press to play the recorded voice message.
- **On/Off:** Power button.
- **Hour/Minute:** Adjust time settings.
- **Manual:** Dispense one portion manually.
- **Time:** Set current time.
- **Mealsize:** Adjust portion size.
- **Meal Buttons (Breakfast, Lunch, Dinner, 4 Meal):** Program specific meal times.
- **Low Battery Indicator:** Lights up when batteries are low.

4.2 Setting Meal Times and Portions

You can program feeding schedules either through the feeder's control panel or the mobile app. The app offers more detailed control and flexibility.

1. **Using the App:** Open the DoHonest app, navigate to the feeder settings, and set desired meal times (up to 4 per day) and portion sizes (1-20 portions per meal). Save your settings.
2. **Using the Control Panel:** Use the 'Time', 'Hour', 'Minute', 'Mealsize', and specific 'Meal' buttons to set your desired feeding schedule. Refer to the detailed instructions in the app or a more

comprehensive manual for specific button sequences.

4.3 Recording a Voice Message

Press and hold the 'Record' button on the control panel. Speak your 10-second message clearly into the microphone. Release the button to save. Press 'Play' to listen to your message.



Image: The DoHonest Automatic Pet Feeder with a speech bubble indicating a 10-second meal time message, such as "Hey Baby, It's time to eat!" and a cat responding with "Meow... Meow...".

4.4 Manual Feeding

To dispense a single portion of food immediately, long-press the 'Manual' button on the control panel. The feeder will rotate once to dispense food.

5. MAINTENANCE

5.1 Cleaning the Feeder

Regular cleaning ensures hygiene and proper functioning. The detachable stainless steel bowl and food tank are easy to clean.

1. Disconnect the power adapter and remove any batteries.
2. Remove the food tank and empty any remaining kibble.
3. Detach the stainless steel bowl.

4. Wash the food tank and bowl with mild soap and water. Rinse thoroughly and dry completely before reassembling.
5. Wipe the main feeder unit with a damp cloth. Do not immerse the main unit in water.

Detachable Stainless Steel Bowl

Easy to clean food-grade stainless steel tray avoid irritation



Image: The DoHonest Automatic Pet Feeder highlighting its detachable stainless steel bowl, emphasizing ease of cleaning and food-grade material for pet safety.

Clog Free Design

Long press the "Manual" button, the feeder would rotate by one grid.



Image: The DoHonest Automatic Pet Feeder demonstrating its clog-free design, showing the internal mechanism that rotates to dispense food smoothly when the 'Manual' button is long-pressed.

5.2 Kibble Management

Regularly check the food level in the tank and refill as needed. Ensure kibble is dry and within the recommended size range (5-10mm) to prevent dispensing issues.

6. TROUBLESHOOTING

Problem	Possible Cause	Solution
Feeder not dispensing food	Food tank empty; Kibble too large/small; Dispenser clogged; Low battery; Power disconnected.	Refill food tank; Use recommended kibble size; Clear any blockages; Replace batteries; Check power connection.
Wi-Fi connection failure	Incorrect Wi-Fi password; Feeder too far from router; Router is 5GHz only; App issues.	Verify password; Move feeder closer to router; Ensure 2.4GHz Wi-Fi is available; Restart app/feeder.

Problem	Possible Cause	Solution
Voice message not playing	Message not recorded; Volume too low; Speaker malfunction.	Record message again; Check app settings for volume; Contact support if issue persists.
Feeder not turning on	No power; Batteries depleted; Faulty power adapter.	Check AC adapter connection; Replace batteries; Try a different power outlet.

7. SPECIFICATIONS

- **Model:** B08D3G5WD4
- **Dimensions (L x W x H):** 17.9 x 16.3 x 32.3 cm
- **Weight:** 1.11 kg
- **Food Capacity:** 4 Liters
- **Material:** ABS, Stainless Steel
- **Power Input:** 5 Volts (AC adapter)
- **Battery Type:** 3 x D-Type batteries (not included)
- **Target Species:** Small to medium-sized dogs and cats
- **UPC:** 783103855226

8. WARRANTY AND SUPPORT

DoHonest offers a 2-year warranty for this product, along with a 30-day money-back guarantee. For any questions, technical assistance, or warranty claims, please contact our 24-hour online customer service.

Please refer to the contact information provided with your purchase or visit the official DoHonest website for support details.