

Manuals+

[Q & A](#) | [Deep Search](#) | [Upload](#)

[manuals.plus](#) /

› [HXSJ](#) /

› [HXSJ Wired Gaming Keyboard and Mouse Combo User Manual](#)

HXSJ MIS-C8634-EN

HSXJ Wired Gaming Keyboard and Mouse Combo User Manual

Model: MIS-C8634-EN

INTRODUCTION

Thank you for purchasing the HXSJ Wired Gaming Keyboard and Mouse Combo. This high-performance combo is designed to enhance your gaming and computing experience with its ergonomic design, adjustable backlighting, and precise optical tracking. This manual provides detailed instructions for setup, operation, maintenance, and troubleshooting to ensure optimal performance and longevity of your product.

PRODUCT OVERVIEW

The HXSJ Gaming Combo includes a wired gaming keyboard with 114 keys and a wired optical gaming mouse. Both devices feature LED backlighting for an immersive experience.



Figure 1: HXSJ Wired Gaming Keyboard and Mouse Combo. This image displays the full keyboard and the accompanying mouse, both featuring LED backlighting.

Keyboard Features:

- 114-key layout with dedicated multimedia keys.
- Adjustable 3-color LED backlighting (Blue, Purple, Red).
- Four levels of brightness adjustment.
- Ergonomic design for comfortable long-term use.

- Durable plastic construction.
- Wired USB 2.0 connection.

Mouse Features:

- 7 buttons: Left, Right, Scroll Wheel, DPI +, DPI -, Advance, Retreat.
- Adjustable DPI settings: 1200/1600/2400/3200dpi.
- High-end optical tracking system for precise positioning.
- Colorful LED light effect.
- Ergonomic design for comfortable grip.
- Wired USB 2.0 connection.

SETUP INSTRUCTIONS

Follow these steps to set up your HXSJ Gaming Keyboard and Mouse Combo:

1. Unpack the keyboard and mouse from their packaging.
2. Locate an available USB 2.0 port on your computer.
3. Plug the USB connector of the keyboard into the USB port.
4. Plug the USB connector of the mouse into another available USB port.
5. Your operating system (Windows 7/8/10/2000/XP/Vista, Mac OS or latest) should automatically detect and install the necessary drivers. No additional software installation is typically required.
6. Once drivers are installed, the keyboard and mouse are ready for use.

OPERATING INSTRUCTIONS

Keyboard Operation

Backlight Control:

- **Switching Backlight Colors:** Press **FN + SL** keys simultaneously to cycle through the three available backlight colors (Blue, Purple, Red).



Figure 2: Keyboard displaying blue backlight. The image highlights the FN and SL keys, indicating their use for switching backlight colors.

3 Color Backlit Gaming Keyboard



Cool Changeable Blue/Purple/Red Backlight



3 Colors Backlit



Figure 3: Examples of the three changeable backlight colors: Cool Blue, Magic Purple, and Flame Red.

- **Adjusting Backlight Brightness:**

- Press **FN + ↑ (Up Arrow)** to increase backlight brightness.
- Press **FN + ↓ (Down Arrow)** to decrease backlight brightness.
- There are four brightness levels: High, Medium, Weak, and Off.



Figure 4: Illustration of backlight brightness adjustment using FN + Up/Down arrow keys. Shows visual examples of highest, middle, low, and no light settings.




Figure 5: Visual representation of the four brightness adjustment levels: High Light, Medium Light, Weak Light, and Switch OFF.

Multimedia Keys:

The keyboard features 10 dedicated multimedia keys for quick access to various functions. These keys are located at the top of the keyboard.

- **Music Player:** Open default music player.
- **Volume Down:** Decrease audio volume.
- **Volume Up:** Increase audio volume.
- **Mute:** Mute/unmute audio.
- **Previous Track:** Go to the previous song.
- **Next Track:** Go to the next song.
- **Play/Pause:** Play or pause current media.
- **Stop:** Stop current media playback.
- **Web Browser:** Open default web browser.
- **Email:** Open default email client.



Figure 6: Keyboard displaying the layout of the multimedia function keys at the top, providing quick access to various controls.



Figure 7: Another view of the keyboard, emphasizing the 10 multimedia keys and their functionality for quick and easy access to media controls.

Key Design:

Wide keys from the design, not the card key.

Wide space design, control the every key precisely

Game Equipment

THE ULTIMATE
WIRELESS



Figure 8: Close-up view of a key, illustrating the wide space design for precise key control.



Figure 9: Image highlighting the ergonomic design and the textured wrist rest area, designed for utmost comfort during extended use.

Mouse Operation

DPI Adjustment:

The mouse features adjustable DPI (Dots Per Inch) settings, allowing you to change cursor sensitivity on the fly. This is useful for different tasks, such as precise aiming in games or faster navigation on the desktop.

- Press the **DPI+** button to increase the DPI setting.
- Press the **DPI-** button to decrease the DPI setting.
- Available DPI settings are 1200, 1600, 2400, and 3200. The mouse's LED lighting may change to indicate the current DPI level.

MAINTENANCE

Proper maintenance ensures the longevity and optimal performance of your gaming combo.

- **Cleaning:**

- Use a soft, dry cloth to wipe down the surfaces of the keyboard and mouse.
- For stubborn dirt, slightly dampen the cloth with water or a mild, non-abrasive cleaner. Ensure no liquid enters the device.
- Use compressed air to remove dust and debris from between keyboard keys.

- **Storage:** Store the devices in a cool, dry place away from direct sunlight and extreme temperatures when not in use.

- **Avoid Liquids:** Do not expose the keyboard or mouse to liquids. Spills can cause permanent damage.

- **Cable Care:** Avoid bending or twisting the cables excessively to prevent internal wire damage.

TROUBLESHOOTING

If you encounter issues with your HXSJ Gaming Combo, refer to the following common problems and solutions:

Problem	Possible Cause	Solution
Keyboard/Mouse not responding	Loose USB connection, faulty USB port, driver issue.	<p>Ensure USB cables are securely plugged into the computer.</p> <p>Try plugging into a different USB port.</p> <p>Restart your computer.</p> <p>Check Device Manager (Windows) to see if the devices are recognized or have driver errors.</p>
Backlight not working or stuck on one color	Incorrect key combination, software glitch.	<p>Ensure you are using the correct key combinations (FN + SL for color, FN + ↑/↓ for brightness).</p> <p>Unplug and replug the keyboard USB cable.</p> <p>Restart your computer.</p>
Mouse cursor erratic or not moving smoothly	Dirty optical sensor, unsuitable mouse pad surface, incorrect DPI setting.	<p>Clean the optical sensor on the bottom of the mouse with a soft cloth.</p> <p>Use the mouse on a clean, uniform surface or a proper mouse pad.</p> <p>Adjust the DPI setting using the DPI+ / DPI- buttons.</p>

SPECIFICATIONS

Keyboard Specifications:

Material	Plastic
Color	Black
Language	English / Russian
System Support	Windows XP, Windows 7, Windows Vista, Mac OS, Windows 8, Windows 2000, Windows 10
Interface	Wired USB2.0
Working Voltage	DC 5V

Operation Current	≤ 400mA
Cable Length	1.5 m
Item Size (L*W*H)	48 * 18.5 * 2.5 cm / 18.86 * 7.27 * 0.98 in
Item Weight	Approx. 620 g / 21.87 oz
Number of Keys	114

Mouse Specifications:

Color	Black
Material	ABS
Tracking System	Optical
Voltage Rating / Current	DC 5V / 100mA
Connection	Wired
Cable Length	Approx. 150 cm
Port	USB 2.0
DPI	1200/1600/2400/3200dpi
Switch Life	10 million cycles
Buttons	Left, Right, Scroll Wheel, DPI +, DPI -, Advance, Retreat
Light Effect	Colorful LED
Support System	Windows 7/8/10/2000/XP/Vista Mac OS or latest
Item Size (L*W*H)	12.7 * 7 * 4 cm / 5 * 2.76 * 1.57 in
Item Weight	Approx. 131 g / 4.62 oz

WARRANTY AND SUPPORT

For warranty information or technical support, please refer to the product packaging or contact the retailer/manufacturer directly. Keep your purchase receipt for warranty claims.

Manufacturer: MIS-C8634-EN

	<p>HXSJ X400 RGB Macro Programming Gaming Mouse Instructions</p> <p>Detailed instructions for the HXSJ X400 RGB Macro Programming Gaming Mouse, covering setup, software usage, DPI settings, lighting modes, and macro customization.</p>
	<p>HXSJ S500 RGB Marquee Gaming Mouse: Specifications and Features</p> <p>Detailed information on the HXSJ S500 RGB Marquee Gaming Mouse, including specifications, programmable macro keys, RGB lighting effects, and driver installation for enhanced gaming performance.</p>
	<p>HXSJ S500 RGB Macro Definition Programmable Gaming Mouse</p> <p>Detailed specifications and usage instructions for the HXSJ S500 RGB gaming mouse, featuring macro definition, programmable keys, adjustable DPI up to 4800, and customizable RGB lighting effects. Includes information on driver installation and custom settings for enhanced gaming performance.</p>
	<p>HXSJ J300 RGB Gaming Mouse: Programmable Buttons, 6400 DPI, and Lighting Modes</p> <p>Discover the HXSJ J300, a programmable RGB gaming mouse featuring 7 customizable buttons, adjustable DPI up to 6400, and multiple lighting modes. Includes detailed specifications and usage instructions for PC gaming.</p>
	<p>HXSJ T66 Wireless Charging Mouse: User Manual and Specifications</p> <p>Detailed information and instructions for the HXSJ T66 Wireless Charging Mouse, featuring 2.4G wireless connectivity, RGB lighting, and a rechargeable battery. Includes technical parameters, product specifications, and usage guide.</p>
	<p>HXSJ J900 RGB Gaming Mouse - Specifications and Usage Guide</p> <p>Detailed specifications and usage instructions for the HXSJ J900 RGB Lighting Programmable Gaming Mouse, including button customization, DPI settings, and lighting modes.</p>