

WAMPAT B-LA

WAMPAT Modern Farmhouse TV Stand

MODEL: B-LA

For 32-65 inch TVs, Washed Grey

Important Safety Information

Please read and understand all instructions before beginning assembly and use. Failure to follow these instructions may result in serious injury or property damage. Keep this manual for future reference.

- **Weight Capacity:** Do not exceed the maximum weight capacity of 220 lbs for the tabletop and 30 lbs for adjustable shelves. Overloading can cause instability and collapse.
- **Assembly:** Assemble the unit on a soft, clean surface to prevent scratches. Ensure all parts are securely fastened before use. Two people are recommended for assembly.
- **Stability:** To prevent tipping, especially with children, always place the TV stand on a flat, level surface. Consider using anti-tip hardware (if included or purchased separately) to secure the unit to a wall.
- **Electrical Safety:** Route all cables through the designated cable management holes to prevent pinching or damage. Do not overload electrical outlets.
- **Maintenance:** Regularly check all fasteners to ensure they remain tight. Loose fasteners can lead to instability.

Package Contents

Verify that all components listed below are present before starting assembly. If any parts are missing or damaged, please contact customer support.

Part	Description	Quantity
Top Panel	Main tabletop surface	1
Side Panels	Left and Right side supports	2
Middle Dividers	Internal vertical supports for shelves	2

Part	Description	Quantity
Adjustable Shelves	Shelves for media storage	2
Sliding Barn Doors	Decorative and functional doors	2
Door Rails & Hardware	Components for sliding door mechanism	1 set
Assembly Hardware	Screws, dowels, cam locks, pins, etc.	1 set
Back Panels	Rear panels with cable management cut-outs	2

Assembly Instructions

Follow these steps carefully for proper assembly. An installation video is provided for visual guidance.

Your browser does not support the video tag.

Video: WAMPAT Farmhouse TV Stand for 65 inch TV Installation Guide. This video provides a step-by-step visual guide for assembling your TV stand.

1. Step 1: Prepare the Base

Attach the bottom rail (Part H) to panels (1, 2) using screws (L, M). Ensure the rail is securely fastened and aligned.

2. Step 2: Assemble Side and Middle Panels

Screw parts (A) into panels (3, 4). Insert dowels (C) into panel (2) and attach panels (3, 4). Then insert and secure cam lock (B) to lock it.

3. Step 3: Attach Top Panel

Insert dowels (C) into panels (3, 4, 5, 6). Attach panel (10) to panels (3, 4, 5, 6) using screws (F). Then secure cam bolts (A) into top panel (10).

4. Step 4: Install Back Panels

Secure parts (G) to panels (3, 4, 7, 10). Ensure the back panels are flush and the cable management holes are accessible.

5. Step 5: Attach Door Hardware

Attach part (E, N) to panels (15, 16). Then screw part (K) to panels (15, 16) using part (J). Do not fix the screws too tight at this stage.

6. Step 6: Install Sliding Doors

After installing the doors (15, 16) in position, adjust door height and leveling. Then fix screws tight and slide doors (15, 16) into the designated area. To prevent the TV cabinet from toppling, install the anti-tip parts (O).


Setup and Placement

Proper setup ensures stability and optimal use of your WAMPAT TV Stand.

- **Location:** Place the TV stand on a flat, stable, and level surface. Avoid placing it in direct sunlight or near heat sources to prevent material damage.

- **TV Placement:** This stand is designed for TVs up to 65 inches. Ensure your TV's base fits within the tabletop dimensions (59" L x 15.4" W). The tabletop can support up to 220 lbs.
- **Cable Management:** Utilize the multiple round cut-outs in the back panels to route all power cords, HDMI cables, and other media device wires. This keeps cables organized and prevents clutter.
- **Adjustable Shelves:** The middle section features 3-level adjustable and removable shelves. Customize their height to accommodate your media devices, game consoles, or decorative items.

*Moisture-proof
& Prevent Floor From Scratches*



Adjustable Shelves



Image: Close-up showing the cable management holes, adjustable shelf positions, and moisture-proof base design.

Operating the Sliding Barn Doors

The WAMPAT TV Stand features smooth-gliding barn doors for flexible storage and display.

- **Opening/Closing:** Gently grasp the handle of either barn door and slide it along the top rail. The doors can be positioned to cover the side cabinets or the central open shelves, allowing you to conceal or display items as desired.

- **Smooth Operation:** The doors are designed to slide easily. If you experience any resistance, check the top rail for obstructions or ensure the door rollers are clean.



SLIDING BARN DOORS DESIGN

Sliding doors conceal a storage space to keep small items organized and out of sight.



Image: A view of the TV stand highlighting the sliding barn doors, showing how they can conceal storage spaces.

Maintenance and Care

To keep your WAMPAT TV Stand in excellent condition, follow these simple maintenance guidelines:

- **Cleaning:** Wipe the surface with a damp cloth. Avoid harsh chemicals or abrasive cleaners, as these can damage the engineered wood finish.
- **Spills:** Clean up spills immediately to prevent staining or water damage.
- **Fasteners:** Periodically check all screws, cam locks, and dowels to ensure they are tight. Re-tighten if necessary to maintain structural integrity.
- **Avoid Overloading:** Do not place excessively heavy items on the shelves or tabletop beyond the specified weight limits.

Troubleshooting

If you encounter any issues with your TV stand, refer to the following common solutions:

- **Wobbly Stand:**

Ensure all cam locks and screws are fully tightened. Check that the stand is on a level surface. If the floor is uneven, use furniture levelers (not included) under the base.

- **Sliding Doors Stick:**

Inspect the top rail and bottom groove for any debris or obstructions. Ensure the door rollers are clean and moving freely. Verify that the doors are correctly seated on the rails.

- **Missing Parts:**

Refer to the "Package Contents" section and the assembly video. If parts are genuinely missing, contact WAMPAT customer support with your product model and part number.

- **Damaged During Shipping:**

If any components arrived damaged, do not proceed with assembly. Contact WAMPAT customer support immediately for replacement parts or further assistance.

Specifications

Feature	Detail
Brand	WAMPAT
Model Number	B-LA
Color	Washed Grey
Size (TV Compatibility)	For 32-65 inch TV
Item Dimensions (L x W x H)	59.05 x 15.55 x 23.62 inches
Item Weight	80 Pounds
Material Type	Engineered Wood
Style	Modern Farmhouse
Number of Shelves	1 (adjustable)
Additional Features	Adjustable Shelf, Cable Management
Required Assembly	Yes
Product Care Instructions	Wipe with Damp Cloth

Warranty and Customer Support

WAMPAT is committed to providing high-quality products and excellent customer service.

- **Warranty Information:** For specific warranty details, please refer to the documentation included with your product or visit the official WAMPAT website.

- **Customer Support:** If you have any questions, require assistance with assembly, or need to report missing/damaged parts, please contact WAMPAT customer support.
- **Online Resources:** Visit the [WAMPAT Store on Amazon](#) for additional product information and support.

© 2024 WAMPAT. All rights reserved.

This manual is for informational purposes only. Product specifications are subject to change without notice.