

Manuals+

[Q & A](#) | [Deep Search](#) | [Upload](#)

[manuals.plus](#) /

› [Arzum](#) /

› [Arzum Pronto Lux 2-in-1 Handstick Vacuum Cleaner AR4075 User Manual](#)

Arzum AR4075

Arzum Pronto Lux 2-in-1 Handstick Vacuum Cleaner User Manual

Model: AR4075

INTRODUCTION

The Arzum Pronto Lux 2-in-1 Handstick Vacuum Cleaner (Model AR4075) is designed for efficient and versatile cleaning. This manual provides essential information for safe operation, assembly, maintenance, and troubleshooting to ensure optimal performance and longevity of your appliance.

SAFETY INSTRUCTIONS

- Read all instructions carefully before use.
- Ensure the power supply voltage matches the rating label on the appliance.
- Do not use the vacuum cleaner to pick up water or wet materials.
- Do not pick up flammable or combustible materials, hot ashes, or sharp objects.
- Keep hair, loose clothing, fingers, and all parts of the body away from openings and moving parts.
- Unplug from the outlet when not in use and before cleaning or servicing.
- Do not operate with a damaged cord or plug.
- This appliance is for household use only.

PRODUCT COMPONENTS

Familiarize yourself with the parts of your Arzum Pronto Lux vacuum cleaner.



Figure 1: Fully assembled Arzum Pronto Lux 2-in-1 Handstick Vacuum Cleaner in Deep Plum color. It features a long handle, a main body with a dust container, and a triangular floor head.

1. **Handle:** Ergonomically designed for comfortable grip.
2. **Extension Tube:** Connects the handle to the main unit for stick vacuum mode.
3. **Main Unit:** Contains the motor, dust container, and filter.
4. **On/Off Switch:** Controls power to the unit.
5. **Dust Container:** 1.5 L capacity for collecting dust and debris.

6. **Washable Filter:** Ensures consistent performance.
7. **Triangular Floor Head:** Designed to reach corners and edges effectively.

SETUP AND ASSEMBLY

1. **Unpacking:** Carefully remove all components from the packaging. Retain packaging for future storage or transport.

2. **Assembling the Stick Vacuum:**

Insert the extension tube into the main unit until it clicks securely into place.

Attach the triangular floor head to the bottom of the main unit, ensuring it is firmly connected.



Figure 2: Illustration of the vacuum cleaner in its assembled stick configuration, ready for use.

3. Assembling the Handheld Vacuum:

To use as a handheld unit, detach the extension tube and triangular floor head from the main unit. The main unit itself functions as the handheld vacuum.



Figure 3: The main unit of the Arzum Pronto Lux, detached for handheld operation.

OPERATING INSTRUCTIONS

Using as a Stick Vacuum

1. Ensure the vacuum is fully assembled in stick mode.
2. Plug the power cord into a suitable electrical outlet (220V).

3. Press the On/Off switch located on the main unit to start the vacuum cleaner.
4. Guide the triangular floor head over the surface to be cleaned. The triangular design allows for effective cleaning in corners and along edges.
5. When finished, press the On/Off switch again to turn off the appliance and unplug it from the outlet.

Using as a Handheld Vacuum

1. Ensure the main unit is detached from the extension tube and floor head.
2. Plug the power cord into a suitable electrical outlet (220V).
3. Press the On/Off switch to activate the handheld vacuum.
4. Use the handheld unit for cleaning smaller areas, upholstery, or car interiors.
5. When finished, press the On/Off switch to turn off the appliance and unplug it.

MAINTENANCE

Regular maintenance ensures the longevity and optimal performance of your vacuum cleaner.

Emptying the Dust Container

1. Ensure the vacuum cleaner is unplugged from the power outlet.
2. Locate the dust container release button or latch on the main unit.
3. Press the release and carefully remove the dust container.
4. Empty the contents of the dust container into a waste bin.
5. Reattach the dust container to the main unit, ensuring it clicks securely into place.

Cleaning the Washable Filter

1. After emptying the dust container, remove the washable filter.
2. Rinse the filter under cold running water until the water runs clear.
3. Allow the filter to air dry completely for at least 24 hours before reinserting it into the vacuum cleaner.
Do not use a dryer or heat to dry the filter.
4. Ensure the filter is completely dry before reassembly to prevent damage to the motor.
5. Reinsert the dry filter into the dust container and then reattach the container to the main unit.

TROUBLESHOOTING

Problem	Possible Cause	Solution
Vacuum cleaner does not turn on.	No power supply; power cord not plugged in; On/Off switch not pressed.	Check power outlet; ensure cord is securely plugged in; press the On/Off switch.
Reduced suction power.	Dust container full; filter clogged; blockage in nozzle or hose.	Empty dust container; clean or replace filter; check for and remove blockages.

Problem	Possible Cause	Solution
Unusual noise during operation.	Foreign object in the brush roll or hose; motor issue.	Turn off and unplug the vacuum. Inspect for and remove any foreign objects. If noise persists, contact customer support.

SPECIFICATIONS

Model: AR4075

Power: 800W

Dust Capacity: 1.5 Liters

Voltage: 220 Volts

Noise Level: 75 Decibels

Material: Plastic

Color: Deep Plum

Dimensions: 41 x 34 x 61 cm (Product)

Weight: 2.68 Kilograms

Filter Type: Washable (Cloth, Foam)

Special Features: 2-in-1 (Handstick & Handheld), Triangular Head Design, Vertical Storage

WARRANTY AND SUPPORT

The Arzum Pronto Lux 2-in-1 Handstick Vacuum Cleaner comes with a warranty for home use provided by "New Star," the official agent in Egypt. The product has a lifespan of 3 years from the purchase date, which includes the warranty period. For service or support, please contact the Certified Integrated Maintenance Centre.

For further assistance, please refer to the contact information provided with your purchase documentation.

Arzum Pronto Lux 2-in-1 Handstick Vacuum Cleaner User Manual | Model AR4075

Related Documents - AR4075

	<p><u>Arzum GIRGIR AR 4087 2-in-1 Stick Vertical Vacuum Cleaner User Manual</u></p> <p>Comprehensive user manual for the Arzum GIRGIR AR 4087 2-in-1 Stick Vertical Vacuum Cleaner, covering setup, operation, maintenance, safety, and warranty information.</p>
------------------------------------------------------------------------------------	-----------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------

 <p>Arzum LUNGO AR4096-G/AR4096-M 2-in-1 Stick Vertical Vacuum Cleaner User Manual</p> <p>Comprehensive user manual for the Arzum LUNGO AR4096-G/AR4096-M 2-in-1 stick vertical vacuum cleaner, covering setup, operation, maintenance, safety precautions, technical specifications, and warranty information.</p>	
 <p>Arzum FOCUS PRO AR 4077 Cyclone System Vacuum Cleaner User Manual & Guide</p> <p>Comprehensive user manual for the Arzum FOCUS PRO AR 4077 Cyclone System Vacuum Cleaner, covering setup, operation, safety precautions, accessory usage, cleaning, maintenance, technical specifications, and warranty information.</p>	
 <p>Arzum GASTROART AR1190 Stand Mikser Kullanım Kılavuzu</p> <p>Bu kullanım kılavuzu, Arzum GASTROART AR1190 stand mikser (model AR1190-33, AR1190-54) için kapsamlı bilgiler sunar. Güvenlik talimatları, çalışma yönergeleri, bakım ipuçları ve teknik özellikler hakkında detaylı bilgi içerir.</p>	
 <p>Arzum Hestia Pro AR1198 Multi Blender Set - User Manual & Instructions</p> <p>Comprehensive user manual for the Arzum Hestia Pro AR1198 Multi Blender Set. Learn about its features, operation, safety precautions, cleaning, and warranty.</p>	
 <p>Arzum Magiclean Ultimate AR4206-M Rechargeable Stick Vacuum Cleaner User Manual</p> <p>Comprehensive user manual for the Arzum Magiclean Ultimate AR4206-M rechargeable stick vacuum cleaner, detailing setup, operation, maintenance, safety guidelines, and technical specifications for optimal use.</p>	