Zorara NK003_EU

Zorara 550ml 3D Glass Essential Oil Diffuser User Manual

Model: NK003_EU

Introduction

Thank you for choosing the Zorara 550ml 3D Glass Essential Oil Diffuser. This device combines the benefits of an essential oil diffuser, cool mist humidifier, and ambient light. It is designed to enhance your home or office environment by purifying the air, increasing humidity, and providing a soothing aromatherapy experience.



Image: The Zorara 550ml 3D Glass Essential Oil Diffuser, showcasing its unique glass design and included remote control.

Safety Information

Please read and understand all safety instructions before using the diffuser.

- Avoid direct skin contact with undiluted essential oils.
- Keep out of reach of children and pets.
- Ensure proper ventilation during use.
- Always follow the recommended usage guidelines for essential oils to prevent adverse reactions.
- The diffuser features an automatic shut-off function when the water tank is empty. Do not operate the device without water.
- Use only the provided power adapter.
- Do not immerse the base unit in water or any other liquid.

Product Components

The package includes the following items:

- Zorara 550ml 3D Glass Essential Oil Diffuser (Base Unit with Glass Cover)
- Power Adapter
- Measuring Cup
- Remote Control
- User Manual (this document)




Image: All components included in the product packaging: aromatherapy machine, plug cable, measure cup, remote control, and user manual.

Specifications

Feature	Detail
Brand	Zorara
Model Name	Essential Oil Diffuser 550ml Cool Mist Humidifier 3D Glass Ultrasonic Aromatherapy
Model Number	NK003_EU
Capacity	550 Milliliters
Run Time	18-36 hours (depending on mist mode)
Coverage Area	25 - 60 m²
Mist Modes	Strong, Low, Intermittent (30s on/30s off)
Timer Settings	1H, 3H, 6H, ON (Continuous)
LED Lights	7 Color Changing (automatic gradient or fixed color, dim/bright options)
Auto Shut-off	Yes (Waterless)
Material	Handmade Glass Cover, BPA-free base
Power Source	Corded Electric (12 watts)
Product Dimensions	6.5"L x 6.5"W x 6.57"H
Item Weight	1.53 pounds



Image: Key features of the diffuser, highlighting its 3D glass design, capacity, and safety functions.

Setup Instructions

1. **Unpack:** Carefully remove the diffuser and all accessories from the packaging.
2. **Place:** Position the diffuser on a flat, stable surface away from direct sunlight or heat sources.
3. **Remove Cover:** Gently lift the glass cover and the inner cap from the base unit.
4. **Add Water:** Using the provided measuring cup, fill the water tank with clean tap water up to the maximum fill line. Do not overfill.
5. **Add Essential Oil:** Add 5-10 drops of your preferred essential oil directly into the water tank. Adjust the quantity based on desired aroma intensity.
6. **Replace Covers:** Place the inner cap back on, followed by the glass cover, ensuring they are securely seated.
7. **Connect Power:** Plug the power adapter into the diffuser's power port and then into a wall outlet.



Image: Visual guide for the initial setup process, including lifting the cover, plugging in, adding water and oil, and pressing the control buttons.

Operating Instructions

The diffuser can be operated using the buttons on the base unit or the included remote control.

Mist Control

- Press the **"MIST"** button (on base or remote) to turn on the mist.
- Each press cycles through mist modes: 1H (1 hour), 3H (3 hours), 6H (6 hours), ON (Continuous), Intermittent (30s on/30s off), OFF.
- To adjust mist intensity (Strong/Low), use the corresponding button on the remote control.

Light Control

- Press the **"LIGHT"** button (on base or remote) to turn on the LED lights.
- The lights will cycle through 7 gradient colors automatically.

- Press the "LIGHT" button again to fix it on a specific color. Continue pressing to cycle through colors.
- To adjust light brightness (Dim/Bright), use the corresponding button on the remote control.
- Long press the "LIGHT" button to turn off the lights.



Image: The remote control and control buttons on the diffuser base, illustrating options for mist, light, and timer settings.



Image: The diffuser showcasing its various LED light colors, which can be set to a gradient or a single fixed color.

Official Product Videos

Video: A demonstration of the Zorara 3D Glass Aroma Diffuser, highlighting its visual effects and mist output.

Video: A closer look at the 3D Firework Glass Aroma Diffuser, showcasing its unique aesthetic and functionality.

Video: An overview of the Zorara Essential Oil Diffuser 550ml, demonstrating its features and ease of use.

Maintenance

Regular cleaning ensures optimal performance and extends the lifespan of your diffuser.

Daily Maintenance

- After each use, empty any remaining water from the tank.
- Wipe the inside of the water tank with a clean, soft cloth.

Weekly Maintenance

- Unplug the diffuser from the power outlet.
- Remove the covers and empty the water tank.
- Add a small amount of warm water and a few drops of neutral detergent to the tank.
- Gently wipe the inside of the tank and the ultrasonic plate with a soft brush or cotton swab.
- Rinse the tank thoroughly with clean water, avoiding contact with the air outlet.
- Wipe the exterior of the diffuser with a soft, dry cloth.
- Allow all parts to air dry completely before reassembling or storing.

Caution: Do not use corrosive detergents or harsh chemicals, as this may damage the diffuser.

Troubleshooting

Problem	Possible Cause & Solution
No mist or low mist output	• Insufficient water: Add water to the tank (up to max line). • Water level too high: Ensure water is below the max line. • Ultrasonic plate dirty: Clean the ultrasonic plate as per maintenance instructions. • Air outlet blocked: Ensure the air outlet is clear. • Diffuser not level: Place on a flat, stable surface.
Diffuser turns off unexpectedly	• Water tank empty: The auto shut-off feature has activated. Refill water. • Timer setting expired: Reset the timer or select continuous mode. • Power connection loose: Check power adapter connection.
No light or light not changing	• Light function off: Press the "LIGHT" button to turn on. • Fixed color selected: Press "LIGHT" button repeatedly to cycle or select gradient mode. • Remote control battery low: Replace remote control battery.

Warranty and Support

Zorara products are manufactured with quality and care. For any issues or questions regarding your diffuser, please contact Zorara customer support.

- Please refer to your purchase documentation for specific warranty details.
- Keep your proof of purchase for warranty claims.

For assistance, please visit the official Zorara website or contact their customer service team directly.

© 2023 Zorara. All rights reserved.

Ask a question about this manual

Ask about setup, troubleshooting, compatibility, parts, safety, or missing instructions. Manuals+ will review the question and use this page's manual context to help answer it.

Name

Anonymous

Email

you@example.com

After a successful submission, we securely hash the supplied account or form email before sending it to Microsoft Advertising for conversion attribution. Privacy details.

Question

Example: How do I reset this device or fix this error?

Details

Model number, symptoms, what you tried, or the section of the manual you are using.

Submit question