

[manuals.plus](#) /› [SEGA](#) /› [SEGA Demon Slayer: Kimetsu No Yaiba PM Perching Figure Tanjiro Kamado - Instruction Manual](#)**SEGA SG94482**

# SEGA Demon Slayer: Kimetsu No Yaiba PM Perching Figure Tanjiro Kamado Instruction Manual

Model: SG94482

## 1. PRODUCT OVERVIEW

This manual provides instructions for the SEGA Demon Slayer: Kimetsu No Yaiba PM Perching Figure featuring Tanjiro Kamado. This collectible figure depicts the main protagonist of the popular anime series, Demon Slayer: Kimetsu No Yaiba, in a unique perching pose. The figure is designed for display and is an officially licensed product.



This image displays the SEGA Demon Slayer: Kimetsu No Yaiba PM Perching Figure of Tanjiro Kamado within its retail box. The box features character art and product branding.

## 2. SAFETY INFORMATION

- **Choking Hazard:** This product contains small parts and is not suitable for children under 15 years of age. Keep away from small children.
- **Fragile:** Handle the figure with care to prevent damage. Avoid dropping or applying excessive force.

## 3. PACKAGE CONTENTS

Verify that all components are present in the package:

- Tanjiro Kamado Figure
- Base Stand

## 4. SETUP AND PLACEMENT

1. **Unboxing:** Carefully remove the figure and its base stand from the packaging.
2. **Assembly:** Place the Tanjiro Kamado figure onto its designated base stand. Ensure the figure is securely seated to prevent accidental falls.
3. **Placement:** Select a stable, flat surface for display. Avoid areas prone to vibrations, direct sunlight, or extreme temperature fluctuations, which can cause damage or discoloration over time.



This image shows the Tanjiro Kamado figure assembled with its base stand, ready for display. The figure depicts Tanjiro in a perching pose.

## 5. CARE AND MAINTENANCE

- Cleaning:** Gently dust the figure regularly with a soft, dry cloth or a soft brush. For stubborn dirt, lightly dampen a cloth with water and wipe carefully, then dry immediately. Avoid abrasive cleaners or solvents.
- Environment:** Keep the figure away from direct sunlight, high humidity, and extreme temperatures to prevent material degradation and color fading.
- Handling:** Always handle the figure by its base or main body. Avoid touching delicate parts excessively.

## 6. PRODUCT SPECIFICATIONS

Feature	Detail
Model Number	SG94482
Product Dimensions	5 x 4 x 7 inches (approximate)
Item Weight	7.4 ounces
Manufacturer Recommended Age	15 years and up
Manufacturer	SEGA
Release Date	December 31, 2020

## 7. TROUBLESHOOTING

- **Figure not stable on base:** Ensure the figure's feet or designated perching points are correctly aligned with the grooves or pegs on the base stand. Apply gentle, even pressure to secure it.
- **Minor dust accumulation:** Use a soft, dry brush or a can of compressed air to carefully remove dust from intricate areas.

## 8. WARRANTY AND SUPPORT

---

This product is covered by the manufacturer's standard warranty against defects in materials and workmanship. For specific warranty details, claims, or technical support, please refer to the official SEGA website or contact their customer service department. Please retain your proof of purchase for warranty purposes.

For further assistance, please visit the [SEGA Store on Amazon](#).