

Manuals+

[Q & A](#) | [Deep Search](#) | [Upload](#)

manuals.plus /

> [T'nB](#) /

> [T'nB Shiny TWS Bluetooth 5.0 Earbuds User Manual - Model EBSHINYWH](#)

T'nB EBSHINYWH

T'nB Shiny TWS Bluetooth 5.0 Earbuds User Manual

Model: EBSHINYWH

1. INTRODUCTION

This manual provides instructions for the safe and efficient use of your T'nB Shiny TWS Bluetooth 5.0 Earbuds. Please read this manual thoroughly before use and retain it for future reference. These earbuds are designed for comfort and performance, featuring a lightweight, compact, and semi in-ear design.


2. PACKAGE CONTENTS

The package includes the following components:

- 1 x Charging Case
- 2 x Shiny TWS Earbuds
- 1 x Micro USB Cable
- 1 x User Manual

3. PRODUCT OVERVIEW

The T'nB Shiny TWS earbuds are designed with a semi in-ear form factor for an ergonomic and comfortable fit, suitable for various activities including sports and travel. Their lightweight and compact design ensures ease of wear.



Format semi-intra auriculaire : design ergonomique

The semi in-ear design of the T'nB Shiny TWS earbuds ensures an ergonomic and comfortable fit for extended wear and active lifestyles.



A detailed view of the T'nB Shiny TWS earbuds, highlighting their semi in-ear form factor.

Design tendance et coloré



The earbuds and charging case feature a compact and modern design.

4. CHARGING THE EARBUDS AND CASE

Before first use, fully charge the earbuds and the charging case. The charging case provides additional power for extended use.

4.1 Charging the Earbuds

Place the earbuds into the charging case. They will begin charging automatically. Ensure the charging contacts on both the earbuds and the case are clean and dry.

4.2 Charging the Case

Connect the micro USB cable to the charging port on the case and to a compatible USB power source (e.g., computer, wall adapter). The charging indicator on the case will show its charging status. A full charge of the case and earbuds provides up to 19 hours of total listening time.

Autonomie 19 heures



Autonomie max
Max playing time

The earbuds, combined with their charging case, offer up to 19 hours of total listening time.

5. SETUP: PAIRING WITH YOUR DEVICE

The T'nB Shiny TWS earbuds utilize Bluetooth 5.0 technology for stable and efficient wireless connection. They feature automatic pairing for convenience.

1. Ensure the earbuds are charged.
2. Open the charging case. The earbuds will automatically power on and enter pairing mode.
3. On your device (smartphone, tablet, computer), enable Bluetooth and search for 'T'nB Shiny' in the list of available devices.
4. Select 'T'nB Shiny' to connect. Once successfully paired, the earbuds will automatically connect to your device for future use when removed from the case.

Appairage automatique



The earbuds feature automatic pairing for quick and easy connection to your device.

6. OPERATING INSTRUCTIONS

The earbuds are equipped with intuitive touch controls for managing music and calls.

6.1 Music Control

- **Play/Pause:** Tap once on either earbud.
- **Next Track:** Tap twice on the **right** earbud.
- **Previous Track:** Tap twice on the **left** earbud.
- **Volume Up:** Tap and hold the **right** earbud.
- **Volume Down:** Tap and hold the **left** earbud.

6.2 Call Management

The integrated omnidirectional microphone allows for clear hands-free communication.

- **Answer/End Call:** Tap once on either earbud.
- **Reject Call:** Tap and hold on either earbud.

Commandes tactiles




▶|| **play / volume / pistes de lecture**

Manage music playback, volume, and calls directly from the earbuds using intuitive touch controls.



Microphone intégré : appels clairs

The integrated microphone allows for clear hands-free calls.



The T'nB Shiny TWS earbuds are designed for active use, providing a secure and comfortable fit during activities like running.

7. MAINTENANCE AND CARE

To ensure the longevity and optimal performance of your earbuds, follow these care guidelines:

- Regularly clean the earbuds and charging case with a soft, dry, lint-free cloth.
- Avoid exposure to extreme temperatures, direct sunlight, moisture, and corrosive substances.
- Store the earbuds in their charging case when not in use to protect them and keep them charged.
- Do not attempt to disassemble or modify the earbuds or charging case, as this will void the warranty.

8. TROUBLESHOOTING

If you encounter issues with your T'nB Shiny TWS earbuds, refer to the following common solutions:

- **No Sound:**
 - Ensure the earbuds are properly paired and connected to your device.
 - Check the volume level on both your device and the earbuds.

- Recharge the earbuds and the charging case.

- **Pairing Issues:**

- Ensure Bluetooth is enabled on your device.
- Place the earbuds back into the charging case, close the lid, then open it again to re-enter pairing mode.
- On your device, 'forget' or 'unpair' 'T'nB Shiny' from your Bluetooth device list and attempt to re-pair.
- Ensure the earbuds are sufficiently charged.

- **Charging Issues:**

- Verify that the micro USB cable is securely connected to both the charging case and the power source.
- Check if the power source is functional.
- Clean the charging contacts on both the earbuds and inside the charging case with a dry cotton swab.

9. SPECIFICATIONS

Model Number	EBSHINYWH
Wireless Technology	Bluetooth 5.0
Earbud Type	Semi In-Ear, Intraaural
Control Type	Touch Control
Microphone	Integrated, Omnidirectional
Total Playtime	Up to 19 hours (with charging case)
Impedance	32 Ohms
Sensitivity	105 dB
Weight	80 Grams (Earbuds + Case)
Material	Plastic
Charging Port	Micro USB
Compatible Devices	Smartphones, Tablets, Laptops, Computers, Smart Speakers

10. WARRANTY AND SUPPORT

For warranty information, technical support, or service inquiries, please refer to the contact details provided by the manufacturer or your retailer at the time of purchase. Please retain your proof of purchase for any warranty claims.